

Electone® **STAGEA**®

ELS-03G

ELS-03X

ELS-03XR

ELS-03XF

Data List

Registration Menu List	2
Voice List	8
Super Articulation Voice Supplementary List	18
VA Voice List (ELS-03X/ELS-03XR/ELS-03XF)	26
Rhythm List	28
Preset Keyboard Percussion Kit List	34
User Keyboard Percussion Kit List	72
Rhythm Pattern Program Kit List	100
Effect Type List	158
Chorus Type List	160
Variation Effect Type List	161
Reverb Type List	163
Vocal Harmony Type List	164

* Some models may not be available depending on your area.

© 2026 Yamaha Corporation
Published 09/2026
MW-B0

Registration Menu List

The Page numbers in this list correspond to the page numbers shown on the Electone display.

[01] tab

Category	Page	Registration Name
KIDS	1	Simple 8Beat 1
		Simple 8Beat 2
		Light Step
		Sunny Pop
		Kids March 1
		Kids March 2
		Kids March 3
		Synth Rock
		SymphonicMarch 1
		SymphonicMarch 2
		Bluegrass
		Sea Carnival
	2	Basic Waltz
		Brass Ensemble
		Pure Waltz
		Rococo Ensemble
		Pop Cha Cha
		Comical Rumba
		Comical Samba
		Toy Orchestra
		Charleston
		Winter Swing
		Snow Waltz 1
		Snow Waltz 2
	3	Alpine Polka*A
		Alpine Polka*B
		Alpine Polka*C
		Alpine Polka*D
		Dream Ballad*A
		Dream Ballad*B
		Dream Ballad*C
		Dream Ballad*D
		Pops Orchestra*A
		Pops Orchestra*B
		Pops Orchestra*C
		Pops Orchestra*D
	4	Kids On Stage*A
		Kids On Stage*B
		Kids On Stage*C
		Kids On Stage*D
		Galaxy March*A
		Galaxy March*B
		Galaxy March*C
		Galaxy March*D
		SE*A
		SE*B
		SE*C
		SE*D
	5 Available only on: ELS-01C ELS-01X ELS-02C ELS-02X ELS-03X ELS-03XR ELS-03XF	Bright 16Beat*A
		Bright 16Beat*B
		Bright 16Beat*C
		Bright 16Beat*D
		Mystery Theme*A
		Mystery Theme*B
		Mystery Theme*C
		Mystery Theme*D
		Powerful Swing*A
		Powerful Swing*B
		Powerful Swing*C
		Powerful Swing*D

Category	Page	Registration Name
POPS & ROCK	1	Dynamic 8Beat
		NY Ballad
		British Pop
		8Beat Modern
		Rock Band
		Detroit Pop
		Techno Pop
		Reef Reggae
		Rock&Roll
		Power Rock
		60s Guitar Rock
		Unplugged
	2	Motor City
		Lovely Shuffle
		Gospel Shuffle
		Happy Gospel
		Power Soul
		Soul
		Gospel
		6/8 Soul
		Hit Pop
		New Country
		Eternal Pop
		Ground Beat
	3	Bounce Pop*A
		Bounce Pop*B
		Bounce Pop*C
		Bounce Pop*D
		Blues Jam*A
		Blues Jam*B
		Blues Jam*C
		Blues Jam*D
		EvergreenWaltz*A
		EvergreenWaltz*B
		EvergreenWaltz*C
		EvergreenWaltz*D
	4	16Beat Pop*A
		16Beat Pop*B
		16Beat Pop*C
		16Beat Pop*D
		Top Gear Rock*A
		Top Gear Rock*B
		Top Gear Rock*C
		Top Gear Rock*D
		Southern Pop*A
		Southern Pop*B
		Southern Pop*C
		Southern Pop*D
	5 Available only on: ELS-01C ELS-01X ELS-02C ELS-02X ELS-03X ELS-03XR ELS-03XF	Funk*A
		Funk*B
		Funk*C
		Funk*D
		WestCoast Rock*A
		WestCoast Rock*B
		WestCoast Rock*C
		WestCoast Rock*D
		6/8 Enka*A
		6/8 Enka*B
		6/8 Enka*C
		6/8 Enka*D

Category	Page	Registration Name
DANCE & BALLAD	1	Organ Ballad
		Dramatic Ballad
		Love Ballad
		Smooth Lead
		Pop Ballad
		Guitar Ballad
		Acoustic Ballad
		Healing Guitar
		Chillout
		Sweetheart 1
		Sweetheart 2
		Slow&Easy
	2	Euro Trance
		6/8 Trance
		Cool Hip Hop
		Latin House
		Dance Beat
		Euro Dance Pop
		UK Pop
		Jive
		Disco Queen
		Disco Soul
		Pop Disco
		Hot Disco
	3	Ibiza*A
		Ibiza*B
		Ibiza*C
		Ibiza*D
		Power House*A
		Power House*B
		Power House*C
		Power House*D
		Dance Latino*A
		Dance Latino*B
		Dance Latino*C
		Dance Latino*D
	4	Twilight Disco*A
		Twilight Disco*B
		Twilight Disco*C
		Twilight Disco*D
		Love Song*A
		Love Song*B
		Love Song*C
		Love Song*D
		Movie Ballad*A
		Movie Ballad*B
		Movie Ballad*C
		Movie Ballad*D
	5 Available only on: ELS-01C ELS-01X ELS-02C ELS-02X ELS-03X ELS-03XR ELS-03XF	Hip Hop Pop*A
		Hip Hop Pop*B
		Hip Hop Pop*C
		Hip Hop Pop*D
		Fusion Shuffle*A
		Fusion Shuffle*B
		Fusion Shuffle*C
		Fusion Shuffle*D
		Whole Ballad*A
		Whole Ballad*B
		Whole Ballad*C
		Whole Ballad*D

Category	Page	Registration Name
JAZZ & LATIN	1	Blow On Sax
		Sax Ensemble
		Moonlight
		Big Band
		Clarinet Swing
		Jazz Combo
		Medium Jazz
		Organ Session
		Guitar Combo
		Tender Ballad
		Jazz Waltz
		Five-Four
	2	Big Band Samba
		Mambo Brass
		Mambo Tenor
		Montuno
		Bossa Nova
		Pop Bossa
		Sweet Rumba
		Beguine
		Cha Cha Cha
		Mellow Groove
		Modern R&B
		Dixieland Jazz
	3	Jungle Drum*A
		Jungle Drum*B
		Jungle Drum*C
		Jungle Drum*D
		Jazz Club*A
		Jazz Club*B
		Jazz Club*C
		Jazz Club*D
		Afro Session*A
		Afro Session*B
		Afro Session*C
		Afro Session*D
	4	ChaCha Grandee*A
		ChaCha Grandee*B
		ChaCha Grandee*C
		ChaCha Grandee*D
		3/4 Fast Jazz*A
		3/4 Fast Jazz*B
		3/4 Fast Jazz*C
		3/4 Fast Jazz*D
		Twilight Sax*A
		Twilight Sax*B
		Twilight Sax*C
		Twilight Sax*D
	5 Available only on: ELS-01C ELS-01X ELS-02C ELS-02X ELS-03X ELS-03XR ELS-03XF	Organ Bossa*A
		Organ Bossa*B
		Organ Bossa*C
		Organ Bossa*D
		Afro Cuban*A
		Afro Cuban*B
		Afro Cuban*C
		Afro Cuban*D
		Midnight Jazz*A
		Midnight Jazz*B
		Midnight Jazz*C
		Midnight Jazz*D

Category	Page	Registration Name
SYMPHONY & WORLD	1	Fanfare
		String Orchestra
		Romantic Violin
		Baroque
		Flute&Harp
		Serenade
		Fast March
		Wild West
		Vienna Waltz
		Polka
		Chanson Club
		Theatre Organ
	2	Flamenco
		Pop Flamenco
		Mexican Dance
		Mariachi
		Celtic Dance
		Folk Step
		Italiano
		Musette
		Country
		Hawaiian
		Chinese Nocturne
		Japanese Sound
	3	OrchestraMarch*A
		OrchestraMarch*B
		OrchestraMarch*C
		OrchestraMarch*D
		Pasodoble*A
		Pasodoble*B
		Pasodoble*C
		Pasodoble*D
		Tango*A
		Tango*B
		Tango*C
		Tango*D
	4	Show Time*A
		Show Time*B
		Show Time*C
		Show Time*D
		Majestic Sound*A
		Majestic Sound*B
		Majestic Sound*C
		Majestic Sound*D
		OrchestraSwing*A
		OrchestraSwing*B
		OrchestraSwing*C
		OrchestraSwing*D
	5 Available only on: ELS-01C ELS-01X ELS-02C ELS-02X ELS-03X ELS-03XR ELS-03XF	Orchestra 3001*A
		Orchestra 3001*B
		Orchestra 3001*C
		Orchestra 3001*D
		Wedding Song*A
		Wedding Song*B
		Wedding Song*C
		Wedding Song*D
		Fantasy*A
		Fantasy*B
		Fantasy*C
		Fantasy*D

[02] tab

Category	Page	Registration Name
SIMPLE	1	SimpleReg Strs 1
		SimpleReg Strs 2
		SimpleReg Orch 1
		SimpleReg Orch 2
		SimpleReg Orch 3
		SimpleReg Pops 1
		SimpleReg Pops 2
		SimpleReg Latin
		SimpleReg Jazz 1
		SimpleReg Jazz 2
		SimpleReg Jazz 3
		SimpleReg Organ
	2	BrassBandMarch*A
		BrassBandMarch*B
		Orchestra March
		6/8 MarchingBand
		6/8 MarchingKids
		Light Waltz
		OrchestraWaltz*A
		OrchestraWaltz*B
		OrchestraWaltz*C
		OrchestraWaltz*D
	3	8Beat Synth Pop
		8Beat Pop
		Pop Shuffle
		R&B Shuffle
		Rock
		Rock Shuffle
		Rock Pop Ballad
		Funk
	4	Dance Pop
		Disco Pop
		R&B EP Ballad
		R&B Piano Ballad
		8Beat Ballad
		8Beat OrchBallad
		3/4 Pop Ballad
	5	6/8 Pop Ballad
		Big Band King*A
		Big Band King*B
		Big Band King*C
		Big Band Swing
		Jazz Session
		Fusion Samba
		Pop Samba
		Simple BossaNova
		Mambo
		Rumba
	6	Cls Organ Chapel
		Cls Organ Hall
		RockOrganBallad
		R&B Rock Organ
		Organ Combo
		6/8 Organ Ballad
		Soul Jazz Organ
		Pop Organ 60s
		Toy Organ
		Theatre Organ NY
		Nostalgic Organ

Category	Page	Registration Name
POPS & ROCK	1	70s Easy Pop
		BoysGuitarBallad
		Soul Pop
		70s Top Duo
		60s ChartShuffle
		Oldies Pop
		EuroPop Folklore
		Discotheque Rock
		Slow Hand Ballad
		Sweet AC Ballad
		70s PrimeTimeTV
		Crossover Funk
	2	Happy Gospel#2
		Gospel Groove
		Worship Shuffle
		Worship 16Beat
		Soulful Shuffle
		Lovely&Soulful
		Danceable Funk
		Bright Pop Rock
		AmericanHardRock
		Power Rock 80s
	3	USA RockStandard
		Seaside Rock
		70s Folk Rock
		Alternative Rock
		Alternative6/8Rk
		Highway Rock
		Funky Rock&Roll
		Synth Pop Rock
		Power Synth Rock
		RockGuitarBallad
	4	Pop Rock&Roll
		Back To The 60s
		Dancing Boogie
		6/8 Shuffle Rock
		ShuffleBoysRock
		Shuffle Pop Rock
		Shuffle Rock Bld
		Pop Rock Band
		ShufflePopPiano
		Contemp Country
	5	Smooth Country
		Xmas Shuffle
		Snowy Christmas
		Pretty Rock
		Ultra Rock
		Energetic Rock
		Casual Rock
		Rookie Rock
		Happy Rock
		J-Pop Idol Rock
		J-Pop Band Rock
		4Pieces Pop Rock
		Sweet Love Pop
		Summer Pop
		Shaky Dance

Category	Page	Registration Name
POPS & ROCK	6	J-Pop Piano Band
		J-Pop Boys
		J-PopShuffleBeat
		J-Pop BandBallad
		Breezy Ballad
		HeroRanger Theme
		Sunset Pop
		Funky Anime*A
		Funky Anime*B
		SpaceshipMarch*A
		SpaceshipMarch*B
	7	J-Pop Anime*A
		J-Pop Anime*B
		70s Anime Theme
		70s Hero
		90sHeroesAnime*A
		90sHeroesAnime*B
		90sHeroesAnime*C
		90sHeroesAnime*D
DANCE & BALLAD	1	R&B Pop Ballad
		R&B Soul Ballad
		R&B Cool Ballad
		Cool AC
		Sweet Chart Hits
		SweetSlowBallad
		YourPiano Ballad
		Sweet EP Ballad
		J-Pop EasyBallad
		Sweet Sax Ballad
		Sweet R&B Ballad
		Lovers R&B
	2	Sentimental Bld
		Tears Ballad
		Glory Ballad
		Unplugged Ballad
		SentimentalMovie
		BeautyCinemaBld
		CinemaSymphoBld
	3	Enka Ballad
		6/8 Enka Shuffle
		Christmas Ballad
		Disco Hits 70s
		70s Disco Night
		Euro Pop Disco
		Synth Disco
		Ballroom Disco
		SynDancePop 80s
		Dirty Dance Beat
		Girls Disco Tune
		GirlsCheerPop*A
		GirlsCheerPop*B
		Shiny Girls Pop
		Sky Pop Dance

Category	Page	Registration Name
DANCE & BALLAD	4	DanceAndRhythm*A
		DanceAndRhythm*B
		DanceAndRhythm*C
		DanceAndRhythm*D
		Girls Techno
		Candy Pop Techno
		Dancing Platform
		Dance Beat Dream
		Club Beat
		Electronica Beat
		Kool Garage
		Electronic Dance
	5	New Age Chillout
		Eurobeat Party
		Ibiza Trance
		Casual Trance
		Trance Party
		WonderTranceShfl
JAZZ & LATIN	1	Big Band Tutti
		Alto Sax Combo
		Jazz Combo Fast
		OrganJazzGroove
		The Big Band*A
		The Big Band*B
		GuitarJazzCombo
		The Swing Jazz
		New Orleans Jazz
		Ragtime Band
		Funky Cat Groove
		Afro Cuban Jazz
	2	GuitarJazzWaltz
		Sax Jazz Waltz
		Swing Steps
		Swing Chorus
		Relax Swing
		Urban Lounge
		Broadway Tap
	3	Brazilian Bossa
		Lounge BossaNova
		8Beat Bossa Nova
		Pop Bossa Nova
		Tiny Bossa Nova
		Cafe Samba
		BitterSweetLatin
		Latin Rock
		DanceBeatLatin*A
		DanceBeatLatin*B
		Pop Accordion
		Sweet Bomba
	4	Orquesta Salsa
		New Flamenco
		Jammin' Reggae
		Movie Rumba
		French Caribbean
		Caribbean Sea

Category	Page	Registration Name
SYMPHONY & WORLD	1	Orch Full Unit
		String Classic
		Sweet Pizzicato
		Baroque Symphony
		Nostalgic Green
		New Year March
		Soft Wind Orch
		BrassBand Parade
		Choral No.9
		Angel Voices
		Beat Classic
		Can Can Pop
	2	Elegant Waltz
		Chorus Waltz
		Love Waltz
		Fantasy World
		Movie Pirates
		Chorus Symphony
		Hollywood Sound
		Super Showtune
		TV Drama Track*A
		TV Drama Track*B
		Movie Symphonic
		Movie Soundtrack
	3	Yoo-Hoo Polka
		Pop Polka
		Funny Polka
		Casual Polka
		Country Town
		Tango Band
		Turkish Pops
		Eastern Dance
		Celtic Beat
		Celtic Waltz
	4	Trad Irish Pipe
		Irish Ballad
		ChinaSweetBallad
		ChinaRomanticBld
		China Dance Beat
		China Kung Fu
		China Trad Song
		China Trad Dance

[03] tab

Category	Page	Registration Name
SIMPLE	1	StringEnsemble 1
		StringEnsemble 2
		Woodwind&Strings
		Brass&Strings
		Orchestra 1
		Orchestra 2
		Soundtrack
		Wind Orchestra
		Classic Organ
		8Beat Pop
		16Beat Shuffle
		Ballad
	2	Rock
		Fusion
		Jazz 1
		Jazz 2
		Jazz 3
		Jazz 4
		Latin 1
		Latin 2
		Latin 3
	3	Simple 1 St/St
		Simple 2 St/Hr
		Simple 3 Cl/St
		Simple 4 Cl/Hr
		Simple 5 Tp/St
		Simple 6 Tp/Hr
		Simple 7 Ob/St
		Simple 8 Ob/Bsn
		Simple 9 Fl/St
		Simple 10 Fl/Cl
		Simple 11 Cl/Cl
		Simple 12 Cl/Bsn
POPS & ROCK	1	90s Soft Pop
		Sunny Guitar Pop
		90s Cheering Pop
		Skipping Shuffle
		Dance Floor Pop
		J-Heartwarming
		Dramatic Strings
		70s Cheerful Pop
		Groovy Urban Pop
		Urban City Jazz
		AC Shuffle
		80s AC Shuffle
	2	Love City Pop
		Smooth City Pop
		City Pop Shuffle
		80s ChristmasPop
		Funky Night Diva
		J-Soul Groove
		Soul Waltz
		Chill Reggae Pop
		J-Sunny Reggae
		US ModernCountry
		Folk Country
		Slow CountryFolk

Category	Page	Registration Name	
POPS & ROCK	3	Power Stage Pop	
		20s Anime Rock	
		80sAnimeSynthPop	
		Iconic Pop Rock	
		90sAnimeAnthem*A	
		90sAnimeAnthem*B	
		LuminousAnimePop	
		90s J-Drama Rock	
		Energy Rock	
		DesktopVocalRock	
		EmotionalHitRock	
		Circuit Fusion	
	4	90s Grunge Rock	
		Clap&Stomp	
		Funky Rock	
		Orchestral Rock	
		Passionate Rock	
		Casual Rock Shfl	
		Twist Dance Rock	
		5	EmotionalRockBld
	Passion-Farewell		
	Boys Rock Ballad		
	Powerful LoveBld		
	Bittersweet Rock		
Victory Rock			
DANCE & BALLAD			10s Epic 6/8 Bld
			1
Fall in Love Bld			
Youth Soft Bld			
GuitarSinger Bld			
PowerBallad Diva			
Everlasting Song			
Hopeful Ballad			
J-Smile Soul			
20s J-Viral Hit			
80s Melancholy			
Sweet 6/8 Ballad			
6/8 Sad Enka Bld			
2	Novel Piano Pop		
	90s Winter Queen		
	70s Disco Pop		
	Lazy Disco		
	Legend TechnoPop		
	90s Dance Group		
	90s Groovy Unit		
	90s Winter Hits		
	Shiny Dance Pop		
	Groovy Boy Disco		
	Tight Beat Pop		
	SkippingDancePop		

Category	Page	Registration Name
DANCE & BALLAD	3	Energy IdolGroup
		Jump Up Dance
		Bright SynthTune
		Club Trap Beat
		10s Upbeat Dance
		Cutie Smile Pop
		Electro Riddim
		Anime Trap Hit
		Rapid ElectroPop
		Girls Signal Pop
		Girl Cyber Dance
		Smooth Girls Pop
	4	Odd Hip Hop
		Beatbox Dance
		Groovy Beatbox
		Edgy Crush Heart
		Chill Choir
		Eternal Time
		Angel Choir
		Chill Spring Pop
		Tropical IdolPop
		Happy Shuffle
JAZZ & LATIN	1	Singing Big Band
		OldiesBandLeader
		FantasyFilmSwing
		Jumping Big Band
		Trp Slow Blues
		SymphonicJazzBld
		Cool JazzCombo 1
		Cool JazzCombo 2
		Cool Organ Combo
		Groovy OrganJazz
		TwoNotes Drawbar
		Cool OrganBallad
	2	Moody Jazz Combo
		Warm Happiness
		Retro PianoSwing
		Hawaiian Swing
		French Club Jazz
		Electro Combo
		Pop Violin Theme
		20s Anime Jazz
	3	J-Golden Show
		Smooth OrgLounge
		Chill OrganBossa
		Lounge Sax Bossa
		Nostalgic Bossa
		60s Upbeat Samba
		J-Light Samba
		FascinatingDance
	4	Hot Wind Salsa
		Passionate Rumba
		Moody Rumba
		Romantic Rumba
		Pop Mambo Number
		Pop Wind Cha Cha
		Caribbean Sea#2
		Ohana Paradise
		Cuban Groovy Pop

Category	Page	Registration Name
SYMPHONY & WORLD	1	Glorious March
		Spanish Prelude
		Romantic Orch
		MelancholicWaltz
		Fantasy Waltz
		Dreamy MoodWaltz
		50s Cinema Waltz
		Wind FusionSamba
		Standard Winds*A
		Standard Winds*B
		Standard Winds*C
		Standard Winds*D
	2	Sea Adventure
		Winter Fantasy
		Symphonic World
		Historic Chinese
		Victory Legend*A
		Victory Legend*B
		TV Drama Track#2
		Silent PowerSong
		Power Pop Anthem
		Dramatic DivaBld
		Symphonic Ballad
	3	Quickstep Show
		Feel Good Pop
		French Pop Swing
		Brass Hymn
		Folk Song Waltz
		Alpen Whistle
		Fancy Kids March
		Kids Christmas

Voice List

The numbers on the left side of each column in this list correspond to the page numbers shown on the Electone display. Voices whose names begin with the prefix “S-” are referred to as “Super Articulation Voices.” For information about what sound is produced when you play these Voices, see the “Super Articulation Voice Supplementary List” on [page 18](#).

*1 The Sustain setting for this Voice takes effect only when Sustain Length is set to HOLD. No effect is produced when a value of 0–12 is set.

*2 When the Sustain Length is set to HOLD and this Voice is played on the Pedalboard, previously played notes continue to sound without being cut off, regardless of the Mono/Poly setting.

*3 The Lead Slide effect cannot be applied to this Voice.

STRINGS/VIOLIN

1	Strings 1	
	Strings 2	
	Strings 3	
	Strings 4	
	Strings 5	
	Strings 6	
	Strings 7	
	Strings 8	
	Strings 9	
	Strings 10	
	Strings 11	
	Strings 12	
	Strings 13	
	Strings 14	
	Strings 15	
	Strings 16	
2	S-Strings 1	*2
	S-Strings 2	*2
	S-Strings 3	*2
	S-Strings 4	*2
	S-Strings 5	*2
	S-Strings 6	*2
	Slow Strings 1	
	Slow Strings 2	
	Slow Strings 3	
	Slow Strings 4	
	S-Slow Strings 1	*2
	S-Slow Strings 2	*2
	S-Slow Strings 3	*2
	S-Slow Strings 4	*2
3	Cinematic Strs 1	
	Cinematic Strs 2	
	Cinematic Strs 3	
	Cinematic Strs 4	
	Cinematic Strs 5	
4	Chamber Strs 1	
	Chamber Strs 2	
	Chamber Strs 3	
	Chamber Strs 4	
	Chamber Strs 5	
	Chamber Strs 6	
5	Violin Section	
	S-Violin Sect 1	*2
	S-Violin Sect 2	*2
	S-Violin Sect 3	*2
	Viola Section	
	S-Viola Sect 1	*2
	S-Viola Sect 2	*2
	Cello Section	
	S-Cello Sect 1	*2
	S-Cello Sect 2	*2
	S-Cello Sect 3	*2

5	S-Strs Vn&Vc	*2
	S-Strs Vn&Va&Vc	*2
	S-Strs Quartet	*2
6	Pizzicato Strs 1	
	Pizzicato Strs 2	
	Pizzicato Strs 3	
	Pizzicato Strs 4	
	Pizzicato Strs 5	
	Pizzicato Oct	
	Pizz&Glocken	
7	Spiccato Strs 1	
	Spiccato Strs 2	
	Spiccato Strs 3	
	Spiccato Strs 4	
	Spiccato Strs 5	
	Strings Fall	
	Spicc Violins 1	
	Spicc Violins 2	
	Spicc Violas 1	
	Spicc Violas 2	
	Spicc Cellos 1	
	Spicc Cellos 2	
8	Tremolo Strs 1	
	Tremolo Strs 2	
	Tremolo Strs 3	
	Tremolo Strs 4	
	Tremolo Strs 5	
	Tremolo Strs Oct	
	S-Tremolo Strs	*2
	S-TremoloViolins	*2
	S-Tremolo Violas	*2
	S-Tremolo Cellos	*2
9	Strings1&7	
	Strings2&Viola	
	Strings3&4	
	Strings7&Violin5	
	Violin5&Cello	
	Octave Strings 1	
	Octave Strings 2	
	Octave Strings 3	
	Octave Strings 4	
	S-Octave Strs 1	*2
	S-Octave Strs 2	*2
10	Violin 1	
	Violin 2	
	Violin 3	
	Violin 4	
	Violin 5	
	Violin 6	
	Violin 7	
	Violin 8	
	S-Violin 1	*1,*2,*3
	S-Violin 2	*1,*2,*3

10	S-Violin 3	*2
	S-Violin 4	*2
	Pizzicato Violin	
11	Viola	
	S-Viola	*2
	Cello 1	
	Cello 2	
	S-Cello 1	*2
	S-Cello 2	*1,*2,*3
	S-Cello 3	*1,*2,*3

CONTRABASS

1	Contrabass 1	
	Contrabass 2	
	Contrabass 3	
	Contrabass 4	
	Contrabass 5	
	Contrabass 6	
	Contrabass 7	
	S-Contrabass 1	*2
	S-Contrabass 2	*2
	S-Cb Tremolo	*2
2	Pizzicato Bass 1	
	Pizzicato Bass 2	
	Pizz Bass Oct	
	Spiccato Bass 1	
	Spiccato Bass 2	
3	Acoustic Bass 1	
	Acoustic Bass 2	
	Acoustic Bass 3	
	Acoustic Bass 4	
	Acoustic Bass 5	
	Acoustic Bass 6	
	Bass&Cymbal	
	S-AcousticBass 1	*2
	S-AcousticBass 2	*2
	S-AcousticBass 3	*2
	S-AcousticBass 4	*2
	S-AcousticBass 5	*2
	S-AcousticBass 6	*2
4	Aco Bass Slap	
	S-Aco Bass Slap	*2
	Aco Bass Mute	

BRASS/TRUMPET

1	Brass Section 1	
	Brass Section 2	
	Brass Section 3	
	Brass Section 4	
	Brass Section 5	
	Brass Section 6	
	Brass Section 7	
	Brass Section 8	
	Brass Section 9	
2	Concert Tutti 1	
	Concert Tutti 2	
	Concert Mutes	
	Power Brass 1	
	Power Brass 2	
	Power Brass 3	
	Power Brass 4	
	Power Brass 5	
3	Soft Brass 1	
	Soft Brass 2	
	Soft Brass 3	
	Soft Brass 4	
	Soft Brass 5	
	Soft Brass 6	
	S-BrsSect Legato	*2
	S-BrsSect Fall	*2
	S-BrsSect Up	*2
4	Brass Fall	
	Brass Shake	
	TromboneSect 1	
	TromboneSect 2	
	TromboneSect 3	
	TromboneSect 4	
	TromboneSect 5	
	TromboneSect 6	
5	TromboneSect 7	
	TromboneSect 8	
	TromboneSect 9	
	TromboneSect 10	
	Brass 1 & Trp 6	
	Brass 2 & Trp 6	
	Horn 1&4	
	Trumpet&Cornet	
	Trps&Trbs 1	
6	Trps&Trbs 2	
	Horns&Trbs	
	Octave Brass 1	
	Octave Brass 2	
	Octave Brass 3	
	Octave Brass 4	
	Octave Brass 5	
	Octave Brass 6	
7	Octave Brass 7	
	Octave Brass 8	
	Octave Brass 9	
	Octave Brass 10	
	Octave Brass 11	
	Octave Brass 12	
	Octave Brass 13	
7	Trumpet 1	
	Trumpet 2	
	Trumpet 3	
	Trumpet 4	
	Trumpet 5	
	Trumpet 6	
	Trumpet 7	
	Trumpet 8	
	Trumpet 9	

7	Trumpet 10	
	Trumpet 11	
	Trumpet 12	
	Trumpet 13	
	Trumpet 14	
	Trumpet Shake	
8	S-Trumpet 1	*1,*2,*3
	S-Trumpet 2	*1,*2,*3
	S-Trumpet 3	*1,*2,*3
	S-Trumpet 4	*1,*2,*3
	S-Trumpet Fall	*2
	S-Trumpet Shake	*2
	Muted Trumpet 1	
	Muted Trumpet 2	
	Muted Trumpet 3	
	Muted Trumpet 4	
	S-Muted Trumpet	*1,*2,*3
9	Cornet	
	Muted Cornet	
	Flugelhorn 1	
	Flugelhorn 2	
	S-Flugelhorn	*1,*2,*3
10	Trombone 1	
	Trombone 2	
	Trombone 3	
	Trombone 4	
	Trombone 5	
	Trombone 6	
	Trombone 7	
	S-Trombone 1	*1,*2,*3
	S-Trombone 2	*1,*2,*3
	Muted Trombone 1	
11	Muted Trombone 2	
	S-Bass Trb 1	*1,*2,*3
	S-Bass Trb 2	*1,*2,*3
	Horn 1	
	Horn 2	
	Horn 3	
	Horn 4	
	Horn 5	
	Horn 6	
12	Horn 7	
	Horn 8	
	Horn 9	
	Horn 10	
	S-Horn 1	*1,*2,*3
	S-Horn 2	*1,*2,*3
	Horn Section 1	
	Horn Section 2	
	Horn Section 3	
13	Horn Section 4	
	Horn Section 5	
	Horn Section 6	
	S-Horn Section	*2
	Muted Horn 1	
	Muted Horn 2	
	S-Muted Horn	*2
	Baritone Horn	
	Bar Horn Stacc	
13	Tuba 1	
	Tuba 2	
	Tuba 3	
	Euphonium	
	Brass Bass 1	
	Brass Bass 2	
	Brass Bass 3	
	Brass Bass 4	

WOODWIND/FLUTE

1	Flute 1	
	Flute 2	
	Flute 3	
	Flute 4	
	Flute 5	
	Flute 6	
	Flute 7	
	Flute 8	
	S-Flute	*1,*2,*3
	S-Flute Flutter	*1,*2,*3
2	Piccolo 1	
	Piccolo 2	
	S-Piccolo 1	*1,*2,*3
	S-Piccolo 2	*1,*2,*3
	Recorder 1	
	Recorder 2	
	Ocarina	
	Whistle 1	
	Whistle 2	
3	S-Whistle 1	*2
	S-Whistle 2	*2
	S-Whistle 3	*2
	Clarinet 1	
	Clarinet 2	
	Clarinet 3	
	Clarinet 4	
	Clarinet 5	
	Clarinet 6	
4	Clarinet 7	
	S-Clarinet 1	*1,*2,*3
	S-Clarinet 2	*1,*2,*3
	Bass Clarinet	
	Oboe 1	
	Oboe 2	
	Oboe 3	
	Oboe 4	
	Oboe 5	
5	Oboe 6	
	Oboe 7	
	S-Oboe 1	*1,*2,*3
	S-Oboe 2	*1,*2,*3
	S-Oboe 3	*2
	English Horn 1	
	English Horn 2	
	Bassoon 1	
	Bassoon 2	
6	Bassoon 3	
	Bassoon 4	
	S-Bassoon 1	*1,*2,*3
	S-Bassoon 2	*1,*2,*3
	Alto Sax 1	
	Alto Sax 2	
	Alto Sax 3	
	Alto Sax 4	
	S-Alto Sax 1	*1,*2,*3
6	S-Alto Sax 2	*2
	S-Alto Sax 3	*2
	S-Alto Sax Growl	*1,*2,*3

7	Tenor Sax 1	
	Tenor Sax 2	
	Tenor Sax 3	
	Tenor Sax 4	
	Tenor Sax 5	
	Tenor Sax 6	
	S-Tenor Sax 1	*1,*2,*3
	S-Tenor Sax 2	*1,*2,*3
	S-Tenor Sax 3	*1,*2,*3
	S-Tenor Sax 4	*1,*2,*3
	S-TenorSax Growl	*1,*2,*3
8	Soprano Sax 1	
	Soprano Sax 2	
	S-Soprano Sax	*1,*2,*3
	S-SprnoSax Growl	*1,*2,*3
	Baritone Sax 1	
	Baritone Sax 2	
	S-Baritone Sax 1	*1,*2,*3
	S-Baritone Sax 2	*1,*2,*3
	S-Baritone Sax 3	*1,*2,*3
9	Sax Ens 1	
	Sax Ens 2	
	Sax Ens 3	
	Sax Ens 4	
	Sax Ens 5	
	Sax Ens 6	
	S-Sax Ens 1	*2
	S-Sax Ens 2	*2
	S-Sax Ens 3	*2
	S-Sax Ens 4	*2
10	Woodwind Ens 1	
	Woodwind Ens 2	
	Woodwind Ens 3	
	Woodwind Ens 4	
	Woodwind Ens 5	
	Woodwind Ens 6	
	Woodwind Ens 7	
	Woodwind Ens 8	
	Clarinet&Flutes	
	Clarinet&Oboe	
	Flutes&Oboes	
	Flute Section	
	Wdwind&Xylophone	
	Wdwind&Glocken 1	
	Wdwind&Glocken 2	

TUTTI

1	Strings&Winds 1	
	Strings&Winds 2	
	Strings&Brass 1	
	Strings&Brass 2	
	Strings&Brass 3	
	Strings&Horn 1	
	Strings&Horn 2	
	Strings&Choir 1	
	Strings&Choir 2	
2	Trumpets&Winds 1	
	Trumpets&Winds 2	
	Horns&Winds	
	Orchestra&Oboe	
	TheatreOrchestra	
	Symphonic Unison	
	Full Orchestra	
	Choir&Organ	
	Orchestra Bass 1	
	Orchestra Bass 2	
	Orchestra Bass 3	
3	Brass&Sax 1	
	Brass&Sax 2	
	Brass&Sax 3	
	Brass&Sax 4	
	Brass&Sax 5	
	Brass&Sax 6	
	Brass&Sax Oct	
	Brass&Sax Unis	
	Brass&Winds 1	
	Brass&Winds 2	
4	Section Horns 1	
	Section Horns 2	
	Section Horns 3	
	Sect Horns Mute	
	Sect Horns Fall	
	Sect Horns Up	
	Sect Horns Shake	
	S-Sect Horns	*2
	S-SectHorns Fall	*2
	S-SectHorns Up	*2
	S-SectHorns Shk	*2
5	Pop Horns	
	Pop Horns Fall	
	Pop Horns Up	
	Pop Horns Shake	
	S-PopHorns Fall	*2
	S-PopHorns Up	*2
	S-PopHorns Shake	*2
6	Orchestra Hit 1	
	Orchestra Hit 2	
	Orchestra Hit 3	
	Orchestra Hit 4	

CHOIR

1	Choir 1	
	Choir 2	
	Choir 3	
	Choir 4	
	Choir 5	
	Choir 6	
	Choir 7	
	Choir 8	
	Choir 9	
	Choir 10	
	Choir 11	
	Choir 12	
	Choir 13	
	Choir 14	
	Choir Tutti	
2	Vocal Ohh 1	
	Vocal Ohh 2	
	Vocal Ahh 1	
	Vocal Ahh 2	
	S-ComeOnLetsGo 1	*2
	S-ComeOnLetsGo 2	*2
	S-IWantYouBack 1	*2
	S-IWantYouBack 2	*2
	S-Dn'tBrkMyHrt 1	*2
	S-Dn'tBrkMyHrt 2	*2
3	S-ChoirSoft Aah	*2
	S-ChoirBoys Aah	*2
	S-ChoirSoft Ooh	*2
	S-ChoirBoys Ooh	*2
4	Gospel Choir 1	
	Gospel Choir 2	
	Gospel Choir 3	
	Gospel Choir 4	
	Gospel Choir 5	
	S-GsplChr Hmm	*2
	S-GsplChr Hm/Ah	*2
	S-GsplChr Wow	*2
5	S-GsplChr W/Hey	*2
	S-GsplChr Hey	*2
	PopVocals Haa 1	
	PopVocals Haa 2	
	PopVocals Ooh 1	
	PopVocals Ooh 2	
	PopVocals Ooh 3	
	PopVocals Aah	
	PopVocals Baa	
	PopVocals Bee	
6	PopVocals Daa	
	PopVocals Doo	
	PopVocals Mmh	
	PopVocals Wah	
	PopVocals Yoo	
	S-ShoBeDoBa/Hmm	*2
	S-ShoBeDoBa/Wah	*2
	S-ShoBeDoBa/Doo	*2
	S-ShoBaDoBa/Daa	*2
	S-DoBaBe/Shoo	*2
	S-DoBeDoBe/Wah	*2
	S-DoBeBaDa/DoWe	*2
	S-BaDaYah/Doo	*2
	S-YaBaDaBa/Doo	*2
	S-WahHoo/Doo	*2

7	S-Scat/Doo	*2
	S-Scat/DoWe	*2
	S-Scat/SFX 1	*2
	S-Scat/SFX 2	*2
	S-Scat/SFX 3	*2
8	S-WhtShouldWeDo	*2
	S-WhoAreYou/Wee	*2
	S-DoWeYouBe/Wah	*2
	S-HaaVibrato/SFX	*2
	S-OohVibrato/SFX	*2
	S-OohBoysVib/SFX	*2
	S-OhGirlsVib/SFX	*2
	S-DooVibrato/SFX	*2
	S-DooBoys/SFX	*2
	S-DooGirls/SFX	*2
	S-DaaVibrato/SFX	*2
	S-BaaVibrato/SFX	*2
	S-WahVibrato/SFX	*2
	S-Wah Soft/SFX	*2
	S-YooVibrato/SFX	*2

PAD

1	Smooth Pad 1	
	Smooth Pad 2	
	Smooth Pad 3	
	Smooth Pad 4	
	Smooth Pad 5	
	Smooth Pad 6	
	Smooth Pad 7	
	Smooth Pad 8	
	Smooth Pad 9	
	Smooth Pad 10	
	Smooth Pad 11	
	Smooth Pad 12	
	Smooth Pad 13	
2	Resonance Pad 1	
	Resonance Pad 2	
	Resonance Pad 3	
	Resonance Pad 4	
	Resonance Pad 5	
	Resonance Pad 6	
	Resonance Pad 7	
	Resonance Pad 8	
	Resonance Pad 9	
	Resonance Pad 10	
	Resonance Pad 11	
	Resonance Pad 12	
3	Bell Pad 1	
	Bell Pad 2	
	Bell Pad 3	
	Bell Pad 4	
	Bell Pad 5	
	Bell Pad 6	
	Bell Pad 7	
	Bell Pad 8	
	Bell Pad 9	
	Bell Pad 10	
	Bell Pad 11	
	Bell Pad 12	
	Bell Pad 13	
	Bell Pad 14	
	Bell Pad 15	
4	BellHeavenPad 1	
	BellHeavenPad 2	
	BellHeavenPad 3	

4	Glass Pad 1	
	Glass Pad 2	
	Glass Pad 3	
	Glass Pad 4	
	Glass Pad 5	
	Glass Pad 6	
	Glass Pad 7	
5	Space Pad 1	
	Space Pad 2	
	Space Pad 3	
	Space Pad 4	
	Space Pad 5	
	Space Pad 6	
	Space Pad 7	
	Space Pad 8	
	Space Pad 9	
	Space Pad 10	
	Space Pad 11	
	Space Pad 12	
	Space Pad 13	
6	Galaxy Pad 1	
	Galaxy Pad 2	
	Galaxy Pad 3	
	Galaxy Pad 4	
	Galaxy Pad 5	
	Galaxy Pad 6	
	Bright Pad 1	
	Bright Pad 2	
	Bright Pad 3	
	Bright Pad 4	
	Bright Pad 5	
	Bright Pad 6	
	Bright Pad 7	
7	Noisy Pad 1	
	Noisy Pad 2	
	Noisy Pad 3	
	Noisy Pad 4	
	Noisy Pad 5	
	Noisy Pad 6	
	Noisy Pad 7	
	Noisy Pad 8	
8	Ambi Pad 1	
	Ambi Pad 2	
	Ambi Pad 3	
	Ambi Pad 4	
	Ambi Pad 5	
	Ambi Pad 6	
	Ambi Pad 7	
9	Warm Pad 1	
	Warm Pad 2	
	Warm Pad 3	
	Warm Pad 4	
	Warm Pad 5	
	Warm Pad 6	
	Warm Pad 7	
	Warm Pad 8	
	Warm Pad 9	
	Warm Pad 10	
10	Dark Pad 1	
	Dark Pad 2	
	Dark Pad 3	
	Dark Pad 4	
	Dark Pad 5	
	Dark Pad 6	
	Dark Pad 7	
	Dark Pad 8	
	Dark Pad 9	
	Dark Pad 10	

10	Dark Pad 11	
	Dark Pad 12	
	Dark Pad 13	
11	Vox Pad 1	
	Vox Pad 2	
	Vox Pad 3	
	Vox Pad 4	
	Vox Pad 5	
	Vox Pad 6	
	Vox Pad 7	
	Vox Pad 8	
	Vox Pad 9	
	Vox Pad 10	
	Vox Pad 11	
	Vox Pad 12	
	Vox Pad 13	
12	Sweep Pad 1	
	Sweep Pad 2	
	Sweep Pad 3	
	Sweep Pad 4	
	Sweep Pad 5	
	Sweep Pad 6	
	Sweep Phase	
	Sweep Flanger 1	
	Sweep Flanger 2	
	Sweep Flanger 3	
13	Metallic Pad 1	
	Metallic Pad 2	
	Metallic Pad 3	
	SFX Pad 1	
	SFX Pad 2	
	SFX Pad 3	

SYNTH

1	Synth Lead 1		6	Vintage Lead 11		13	Synth Brass 5	
	Synth Lead 2			Vintage Lead 12			Synth Brass 6	
	Synth Lead 3			Vintage Lead 13			Synth Brass 7	
	Synth Lead 4			Vin Lead Oct 1			Synth Brass 8	
	Synth Lead 5			Vin Lead Oct 2			Synth Brass 9	
	Synth Lead 6			Vin Lead Oct 3			Synth Brass 10	
	Synth Lead 7		7	Dance Chords 1			Synth Brass 11	
	Synth Lead 8			Dance Chords 2			Synth Brass 12	
	Synth Lead 9			Dance Chords 3			Synth Brass 13	
	Synth Lead 10			Dance Chords 4			Synth Brass 14	
	Synth Lead 11			Dance Chords 5		14	FatSynthBrass 1	
	Synth Lead 12			Dance Chords 6			FatSynthBrass 2	
	Synth Lead 13			Dance Chords 7			FatSynthBrass 3	
2	Fat Saw Lead 1			Dance Chords 8			FatSynthBrass 4	
	Fat Saw Lead 2			Dance Chords 9			FatSynthBrass 5	
	Fat Saw Lead 3			Dance Chords 10			FatSynthBrass 6	
	Fat Saw Lead 4		8	Club Chords 1			FatSynthBrass 7	
	Fat Saw Lead 5			Club Chords 2			FatSynthBrass 8	
	Fat Saw Lead 6			Club Chords 3			FatSynthBrass 9	
3	Filter Lead 1			Club Chords 4			FatSynthBrass 10	
	Filter Lead 2			Club Chords 5			DetunedSawBrs 1	
	Filter Lead 3			Club Chords 6			DetunedSawBrs 2	
	Filter Lead 4			Club Chords 7			DetunedSawBrs 3	
	Filter Lead 5		9	Club Lead 1			DetunedSawBrs 4	
	Filter Lead 6			Club Lead 2		15	Soft Syn Brass 1	
	Filter Lead 7			Club Lead 3			Soft Syn Brass 2	
	Filter Lead 8			Club Lead 4			Soft Syn Brass 3	
	Filter Lead 9			Club Lead 5			PWM Brass Slow 1	
	Filter Lead 10			Club Lead 6			PWM Brass Slow 2	
	Filter Lead 11			Club Lead 7			PWM Brass Fast 1	
	Filter Lead 12			Club Lead 8			PWM Brass Fast 2	
	Filter Lead 13			Club Lead 9			PWM Picks	
	Filter Lead 14			Club Lead 10		16	Funky Analog	
	Filter Lead 15			Club Lead 11			Synth Strings 1	
4	Soft Lead 1		10	Club Lead 12			Synth Strings 2	
	Soft Lead 2			Club Lead 13			Synth Strings 3	
	Soft Lead 3			Pop Lead 1			Synth Strings 4	
	Soft Lead 4			Pop Lead 2			Synth Strings 5	
	Soft Lead 5			Pop Lead 3			Synth Strings 6	
	Soft Lead 6			Pop Lead 4			Synth Strings 7	
	Soft Lead 7			Pop Lead 5			Synth Strings 8	
	Soft Lead 8			Pop Lead 6			Synth Strings 9	
	Soft Lead 9		11	Pop Lead 7			Synth Strings 10	
	Soft Lead 10			Pop Lead 8			Synth Strings 11	
	Soft Lead 11			Synth Cla 1			Synth Strings 12	
	Soft Lead 12			Synth Cla 2		17	Synth Strings 13	
	Soft Lead 13			Synth Cla 3			Light Syn Strs 1	
5	Early Lead 1			Synth Cla 4			Light Syn Strs 2	
	Early Lead 2			Synth Cla 5			Light Syn Strs 3	
	Early Lead 3			Synth Cla 6			Light Syn Strs 4	
	PWM Lead 1			Synth Cla 7			Light Syn Strs 5	
	PWM Lead 2			Synth Cla 8			Light Syn Strs 6	
	ChorusSawLead 1			Synth Cla 9			Movin Syn Strs 1	
	ChorusSawLead 2			Synth Cla 10			Movin Syn Strs 2	
	ChorusSawLead 3			Synth Cla 11		18	Fat Syn Strs 1	
	ChorusSawLead 4			Synth Cla 12			Fat Syn Strs 2	
	ChorusSawLead 5		12	Synth Cla 13			Fat Syn Strs 3	
6	Vintage Lead 1			Synth Cla 14			Fat Syn Strs 4	
	Vintage Lead 2			Synth Sax			Fat Syn Strs 5	
	Vintage Lead 3			Synth Trumpet 1			Fat Syn Strs 6	
	Vintage Lead 4			Synth Trumpet 2			Oct Syn Strs 1	
	Vintage Lead 5			Synth Violin			Oct Syn Strs 2	
	Vintage Lead 6			Synth Whistle 1			Oct Syn Strs 3	
	Vintage Lead 7		13	Synth Whistle 2		19	Synth Bell 1	
	Vintage Lead 8			Synth Brass 1			Synth Bell 2	
	Vintage Lead 9			Synth Brass 2			Synth Bell 3	
	Vintage Lead 10			Synth Brass 3			Synth Bell 4	
				Synth Brass 4			Synth Bell 5	

19	Synth Bell 6	
	Synth Bell 7	
	Synth Bell 8	
	Synth Bell 9	
	Synth Bell 10	
20	Sky Bell 1	
	Sky Bell 2	
	Sky Bell 3	
	Sky Bell 4	
	Vox Bell 1	
	Vox Bell 2	
	Pop Synth Bell 1	
	Pop Synth Bell 2	
	Pop Synth Bell 3	
	Pop Synth Bell 4	
	Pop Synth Bell 5	
	Pop Synth Bell 6	
21	Synth Decay 1	
	Synth Decay 2	
	Synth Decay 3	
	Synth Decay 4	
	Synth Decay 5	
	Synth Decay 6	
	Synth Pluck 1	
	Synth Pluck 2	
	Synth Pluck 3	
	Synth Pluck 4	
	Synth Pluck 5	
	Synth Pluck 6	
	Synth Pluck 7	
	Synth Pluck 8	
22	Synth Seq 1	
	Synth Seq 2	
	Synth Seq 3	
	Synth Seq 4	
	Synth Seq 5	
	Synth Seq 6	
	Synth Seq 7	
	Synth Seq 8	
	Trance Seq 1	
	Trance Seq 2	
	Trance Seq 3	
	Trance Seq 4	
	Trance Seq 5	
	Trance Seq 6	
	Trance Seq 7	
	Trance Seq 8	
23	PercussiveSeq 1	
	PercussiveSeq 2	
	PercussiveSeq 3	
	PercussiveSeq 4	
	PercussiveSeq 5	
	PercussiveSeq 6	
	PercussiveSeq 7	
	PercussiveSeq 8	
	PercussiveSeq 9	
	PercussiveSeq 10	
	PercussiveSeq 11	
	PercussiveSeq 12	
24	Retro SynComp 1	
	Retro SynComp 2	
	Retro SynComp 3	
	Retro SynComp 4	
	Retro SynComp 5	
	Retro SynComp 6	
	Retro SynComp 7	
	Retro SynComp 8	
	Retro SynComp 9	

24	Retro SynComp 10	
	Retro SynComp 11	
	Retro SynComp 12	
	Retro SynComp 13	
	Retro SynComp 14	
25	Synth Comp 1	
	Synth Comp 2	
	Synth Comp 3	
	Synth Comp 4	
	Synth Comp 5	
	Synth Comp 6	
	Synth Comp 7	
26	SFX Synth 1	
	SFX Synth 2	
	SFX Synth 3	
	SFX Synth 4	
	SFX Synth 5	
	Pitch Fall	
	Noise 1	
	Noise 2	

ORGAN

1	Pipe Organ 1	
	Pipe Organ 2	
	Pipe Organ 3	
	Pipe Organ 4	
	Pipe Organ 5	
	Pipe Organ 6	
	Pipe Organ 7	
	Pipe Organ 8	
	Pipe Organ 9	
	Pipe Organ 10	
2	Chapel Organ 1	
	Chapel Organ 2	
	Chapel Organ 3	
	Chapel Organ 4	
	Chapel Organ 5	
	Concert Organ 1	
	Concert Organ 2	
	Concert Organ 3	
3	Theatre Organ 1	
	Theatre Organ 2	
	Theatre Organ 3	
	Theatre Organ 4	
	Theatre Organ 5	
	Theatre Organ 6	
	Theatre Organ 7	
	Theatre Organ 8	
	Theatre Organ 9	
	Theatre Organ 10	
4	Thtr Tibia Full	
	Thtr Tibia 8&4	
	Thtr Tibia 16&4	
	Thtr Tp&Kinura	
	Thtr Vox&Tibia	
	Thtr Tp 16&8	
	Thtr Tibia&Vox	
	Thtr Open Tibias	
	Thtr Organ Mix 1	
	Thtr Organ Mix 2	
	Thtr Organ Mix 3	
	Thtr Organ Mix 4	
	Thtr Organ Mix 5	
	Thtr Flute	

4	Thtr Strings	
	Thtr Fl&Chrysolt	
5	Thtr Org&Piano	
	Euro Organ 1	
	Euro Organ 2	
	Euro Organ 3	
	Home Organ 1	
	Home Organ 2	
	Home Org Trb	
	Home Org Cla	
	Home Org Cornet	
	Home Org Horn	
6	Home Org Kinura	
	Home Org Violin	
	Home Org Cello	
	Harmonica 1	
	Harmonica 2	
	Harmonica 3	
	Harmonica 4	
	Blues Harmonica	
	S-Harmonica	*1,*2,*3
	S-BluesHarmonica	*1,*2,*3
7	Reed Organ 1	
	Reed Organ 2	
	Bandoneon 1	
	Bandoneon 2	
	Accordion 1	
	Accordion 2	
	Accordion 3	
	Accordion 4	
	Accordion 5	
	Accordion 6	
8	Accordion 7	
	Accordion 8	
	Accordion 9	
	Accordion 10	
	Accordion 11	
	Accordion 12	
	Accordion 13	
	Accordion 14	
	Accordion 15	
	AccordionMuset 1	
9	AccordionMuset 2	
	AccordionMuset 3	
	AccordionMuset 4	
	Accordion Full	
	Accordion Bass 1	
	Accordion Bass 2	
	Accordion Bass 3	
	Accordion Bass 4	
	Jazz Organ 1	
	Jazz Organ 2	
10	Jazz Organ 3	
	Jazz Organ 4	
	Jazz Organ 5	
	Jazz Organ 6	
	Jazz Organ 7	
	Jazz Organ 8	
	Jazz Organ 9	
	Jazz Organ 10	
	Jazz Organ 11	
	Jazz Organ 12	
	Jazz Organ 13	
	JazzOrgan Slow 1	
	JazzOrgan Slow 2	
	JazzOrgan Slow 3	
	JazzOrgan Fast 1	
	JazzOrgan Fast 2	

10	Vintage Organ	
	Vin Organ Slow 1	
	Vin Organ Slow 2	
	Vin Organ Fast 1	
	Vin Organ Fast 2	
	Vin Organ Fast 3	
11	TonewheelOrgan 1	
	TonewheelOrgan 2	
	TonewheelOrgan 3	
	TonewheelOrgan 4	
	TonewheelOrgan 5	
	TonewheelOrgan 6	
	TonewheelOrgan 7	
	TonewheelOrgan 8	
12	Pop Organ 1	
	Pop Organ 2	
	Pop Organ 3	
	Pop Organ 4	
	Pop Organ 5	
	Pop Organ 6	
	Pop Organ 7	
	Pop Organ Fast 1	
	Pop Organ Fast 2	
	Pop Organ Fast 3	
	Combo Organ 1	
	Combo Organ 2	
	Combo Organ 3	
	Combo Organ 4	
13	Rock Organ 1	
	Rock Organ 2	
	Rock Organ 3	
	Rock Organ 4	
	RockOrgan Slow 1	
	RockOrgan Slow 2	
	RockOrgan Slow 3	
	RockOrgan Slow 4	
	RockOrgan Slow 5	
	RockOrgan Slow 6	
	RockOrgan Slow 7	
	RockOrgan Slow 8	
	RockOrgan Fast 1	
	RockOrgan Fast 2	
14	Organ Bass 1	
	Organ Bass 2	
	Organ Bass 3	
	Organ Bass 4	
	Organ Bass 5	
	Organ Bass 6	

PIANO

1	Piano 1	
	Piano 2	
	Piano 3	
	Piano 4	
	Piano 5	
	Piano 6	
	S-Piano 1	*3
	S-Piano 2	*3
	S-Piano 3	*3
	S-Piano 4	*3
	S-Piano 5	*3
	S-Piano 6	*3
	S-Piano 7	*3
2	S-Character Gd 1	*3
	S-Character Gd 2	*3
	Upright Piano 1	

2	Upright Piano 2	
	Upright Piano 3	
	Upright Piano 4	
	Felt Piano	
	HonkytonkPiano 1	
	HonkytonkPiano 2	
3	S-Honkytonk	*3
	Octave Piano 1	
	Octave Piano 2	
	Octave Piano 3	
	S-Octave Piano 1	*3
	S-Octave Piano 2	*3
	S-Octave Piano 3	*3
	S-Octave Piano 4	*3
	S-Oct Upright 1	*3
	S-Oct Upright 2	*3
	S-Cocktail Grand	*3
4	S-Piano&DX EP 1	*3
	S-Piano&DX EP 2	*3
	S-Piano&DX EP 3	*3
	S-Piano&Strs	*3
	Piano&Pad	
	S-Piano&Pad 1	*3
	S-Piano&Pad 2	*3
	S-Piano&Pad 3	*3
	S-Piano&Pad 4	*3
5	Harpsichord 1	
	Harpsichord 2	
	Harpsichord 3	
	Harpsichord 4	
	S-Harpsichord	*2
6	Clavichord	
	DX E.Piano 1	
	DX E.Piano 2	
	DX E.Piano 3	
	DX E.Piano 4	
	DX E.Piano 5	
	DX E.Piano 6	
	DX EP Sweet 1	
	DX EP Sweet 2	
	DX EP Sweet 3	
7	Galaxy EP	
	DX EP Dynamics	
	S-DX E.Piano	*3
8	TX E.Piano	
	DX E.Piano&Pad 1	
	DX E.Piano&Pad 2	
	DX E.Piano&Pad 3	
	Stage E.Piano 1	
	Stage E.Piano 2	
	Stage E.Piano 3	
	Stage E.Piano 4	
	Stage E.Piano 5	
	Stage E.Piano 6	
	Stage E.Piano 7	
	Stage E.Piano 8	
	Stage E.Piano 9	
9	Stage E.Piano 10	
	Stage E.Piano 11	
	Stage E.Piano 12	
	Stage E.Piano 13	
	S-StageE.Piano 1	*2
	S-StageE.Piano 2	*2
	S-StageE.Piano 3	*2
	S-StageE.Piano 4	*2
	S-StageE.Piano 5	*2
	S-StageE.Piano 6	*2
	S-StageE.Piano 7	*2

9	S-StageE.Piano 8	*2
	S-StageE.Piano 9	*2
	S-StageE.Piano10	*2
	S-StageE.Piano11	*2
	S-StageE.Piano12	*2
	S-StageE.Piano13	*2
	S-StageE.Piano14	*2
	S-StageE.Piano15	*2
10	E.Piano&Pad	
	S-EP&FeltPiano	*3
	Stack E.Piano 1	
	Stack E.Piano 2	
	Stack E.Piano 3	
	E.Grand CP80	
	S-E.Grand CP80 1	*2
	S-E.Grand CP80 2	*2
	S-E.Grand CP80 3	*3
	S-E.Grand CP80 4	*3
11	Clavi 1	
	Clavi 2	
	Clavi 3	
	Clavi 4	
	S-Clavi 1	*2
	S-Clavi 2	*2
	S-Clavi 3	*2
	S-Muted Clavi	*2

GUITAR

1	Nylon Guitar 1	
	Nylon Guitar 2	
	Nylon Guitar 3	
	Nylon Guitar 4	
	Nylon Guitar 5	
	Nylon Guitar 6	
	Nylon Guitar 7	
	Nylon Gt Slide 1	
	Nylon Gt Slide 2	
2	S-Nylon Guitar 1	*2
	S-Nylon Guitar 2	*2
	S-Nylon Guitar 3	*2
	S-Nylon Guitar 4	*2
	S-Nylon Gt Amp 1	*2
	S-Nylon Gt Amp 2	*2
	Flamenco Guitar	
	FlamencoGt Slide	
	S-Flamenco Gtr 1	*2
	S-Flamenco Gtr 2	*2
3	S-Flamenco Gtr 3	*2
	Steel Guitar 1	
	Steel Guitar 2	
	Steel Guitar 3	
	Steel Guitar 4	
	Steel Guitar 5	
	Steel Gtr Twin 1	
	Steel Gtr Twin 2	
	Steel Gtr Slide	
	Steel Gtr Mute	
4	S-Steel Guitar 1	*2
	S-Steel Guitar 2	*2
	S-Steel Guitar 3	*2
	S-Steel Guitar 4	*2
	S-Steel Guitar 5	*2
	S-Steel Guitar 6	*2
	S-SteelGt Amp 1	*2
	S-SteelGt Amp 2	*2
	S-SteelGt Amp 3	*2

4	S-SteelGt Amp 4	*2
	S-SteelGt Strum1	*2
	S-SteelGt Strum2	*2
5	12 Str Guitar 1	
	12 Str Guitar 2	
	S-12Str Guitar 1	*2
	S-12Str Guitar 2	*2
	S-12Str Gt Twin	*2
	18 String Guitar	
6	Jazz Guitar 1	
	Jazz Guitar 2	
	Jazz Guitar 3	
	Jazz Guitar 4	
	JazzGuitar Slide	
	Jazz Guitar Oct	
	DX Jazz Guitar	
	S-Jazz Guitar 1	*2
	S-Jazz Guitar 2	*2
	S-Jazz Guitar 3	*2
	S-Jazz Guitar 4	*2
	S-Jazz Guitar 5	*2
7	S-ElectroAco 1	*2
	S-ElectroAco 2	*2
	S-Ukulele	*2
	S-Ukulele Strum	*2
8	ElectricGuitar 1	
	ElectricGuitar 2	
	ElectricGuitar 3	
	ElectricGuitar 4	
	ElectricGuitar 5	
9	Clean Guitar 1	
	Clean Guitar 2	
	Clean Guitar 3	
	Clean Guitar 4	
	Clean Guitar 5	
	Clean Guitar 6	
	Clean Guitar 7	
	Clean Guitar 8	
	Clean Guitar 9	
	Clean Guitar 10	
	Clean Guitar 11	
	Clean Guitar 12	
	Clean Guitar 13	
	Clean Gtr Slide	
10	E.Guitar Amp 1	
	E.Guitar Amp 2	
	E.Guitar Amp 3	
	E.Guitar Amp 4	
	E.Guitar Amp 5	
	E.Guitar Amp 6	
	E.Guitar Amp 7	
	Muted Guitar 1	
	Muted Guitar 2	
	Muted Guitar 3	
	Muted Guitar 4	
	Muted Guitar 5	
11	S-Clean Solid 1	*2
	S-Clean Solid 2	*2
	S-Clean Solid 3	*2
	S-Clean Solid 4	*2
	S-Clean Solid 5	*2
12	S-Clean Guitar 1	*2
	S-Clean Guitar 2	*2
	S-Clean Guitar 3	*2
	S-Clean Guitar 4	*2
	S-Clean Guitar 5	*2
	S-Clean Guitar 6	*2
	S-Clean Finger 1	*2

12	S-Clean Finger 2	*2
	S-Clean Finger 3	*2
	S-Clean Finger 4	*2
13	S-CleanVintage 1	*2
	S-CleanVintage 2	*2
	S-CleanVintage 3	*2
	S-CleanVintage 4	*2
	S-CleanVintage 5	*2
	S-CleanVintage 6	*2
	S-CleanVintage 7	*2
14	DistortionGtr 1	
	DistortionGtr 2	
	DistortionGtr 3	
	DistortionGtr 4	
	DistortionGtr 5	
	DistortionGtr 6	
	DistortionGtr 7	
	DistortionGtr 8	
	DistortionGtr 9	
	DistortionGtr 10	
	DistortionGtr 11	
	DistortionGtr 12	
	DistortionGtr 13	
15	S-Dist Solid 1	*2
	S-Dist Solid 2	*2
	S-Dist Solid 3	*2
	S-Dist Solid 4	*2
	S-Dist Solid 5	*2
	S-Dist Solid 6	*2
	S-Dist Solid 7	*2
	S-Dist Solid 8	*2
	S-DistVintage 1	*2
	S-DistVintage 2	*2
	S-DistVintage 3	*2
	S-DistVintage 4	*2
	S-DistVintage 5	*2
	S-DistVintage 6	*2
16	S-DistVintage 7	*2
	S-Dist Crunch 1	*2
	S-Dist Crunch 2	*2
	S-Dist Crunch 3	*2
	S-Dist Crunch 4	*2
	S-Dist Finger 1	*2
	S-Dist Finger 2	*2
	S-Dist Finger 3	*2
	S-Dist Finger 4	*2
17	Dist Gtr Mute 1	
	Dist Gtr Mute 2	
	S-Dist Mute 1	*2
	S-Dist Mute 2	*2
	S-Dist Mute 3	*2
	S-Dist Mute 4	*2
	S-Dist Mute 5	*2
	S-Dist Mute 6	*2
18	S-Dist Mute 7	*2
	Banjo 1	
	Banjo 2	
	Mandolin 1	
	Mandolin 2	
	Mandolin Slide	
	S-Mandolin	*2
19	S-Mandolin Mute	*2
	Pedal Steel Gt 1	
	Pedal Steel Gt 2	
	Pedal Steel Gt 3	
	Pedal Steel Gt 4	
	S-PedalSteelGt 1	*2
	S-PedalSteelGt 2	*2

19	Harp 1	
	Harp 2	
	Harp 3	
	Harp 4	
	Harp 5	
	Harp 6	

PERCUSSION

When the User button is pressed, "PERCUSSION/TIMPANI" is displayed.

1	Vibraphone 1	
	Vibraphone 2	
	Vibraphone 3	
	Vibraphone 4	
	Vibraphone 5	
	Vibraphone 6	
	Marimba 1	
	Marimba 2	
	Marimba 3	
	Marimba 4	
2	Marimba 5	
	Xylophone 1	
	Xylophone 2	
	Xylophone 3	
	Xylophone 4	
	Glockenspiel 1	
	Glockenspiel 2	
	Glockenspiel 3	
3	Glockenspiel 4	
	Celesta 1	
	Celesta 2	
	Celesta 3	
	Music Box 1	
	Music Box 2	
	Chime 1	
	Chime 2	
	Chime 3	
	Chime 4	
	Chime 5	
	Chime 6	
4	Thtr Xylophone	
	Thtr Wooden Harp	
	ThtrOrg Glocken	
	Thtr Chrysoglott	
	ThtrOrg Chime	

TIMPANI

When the User button is pressed, "PERCUSSION/TIMPANI" is displayed. In this case, the TIMPANI Voices are available on page 5.

1	Timpani 1	
	Timpani 2	
	Timpani 3	
	Timpani 4	
	Timpani 5	
	Timpani 6	
	Timpani 7	
	Timpani Roll 1	
	Timpani Roll 2	
	Timpani Roll 3	
	Timpani Roll 4	
	Timpani Roll 5	
	S-Timpani Roll	*2
	S-TimpaniRoll fp	*2

ELECTRIC BASS

1	Fingered Bass 1	
	Fingered Bass 2	
	Fingered Bass 3	
	Fingered Bass 4	
	Fingered Bass 5	
	Fingered Bass 6	
	Fingered Bass 7	
	Fingered Bass 8	
	Fingered Bass 9	
	Fingered Bass 10	
	Fingered Bass 11	
	Fingered Bass 12	
	Fingered Bass 13	
2	S-Fingerd Bass 1	*2
	S-Fingerd Bass 2	*2
	S-Fingerd Bass 3	*2
	S-Fingerd Bass 4	*2
	S-Fingerd Bass 5	*2
	S-Fingerd Bass 6	*1,*2,*3
	S-Fingerd Bass 7	*1,*2,*3
	S-Fingerd Bass 8	*1,*2,*3
	S-Fingerd Bass 9	*1,*2,*3
	Fingered Mute 1	
	Fingered Mute 2	
3	Slap Bass 1	
	Slap Bass 2	
	Slap Bass 3	
	Slap Bass 4	
	Slap Bass 5	
	Slap Bass 6	
	Slap Bass 7	
	Slap Bass 8	
	S-Slap Bass 1	*2
	S-Slap Bass 2	*2
4	Picked Bass 1	
	Picked Bass 2	
	Picked Bass 3	
	Picked Bass 4	
	Picked Bass 5	
	Picked Bass 6	
	Picked Bass 7	
	Picked Bass 8	
	Picked Bass 9	
	Picked Bass 10	

4	Picked Bass 11	
	Picked Bass 12	
	PickedBassMute 1	
	PickedBassMute 2	
5	Fretless Bass 1	
	Fretless Bass 2	
	Fretless Bass 3	
	Fretless Bass 4	
	S-Fretless Bass	*2
	Violin Bass Open	
	Violin Bass Mute	

SYNTH BASS

1	Funk Bass 1	
	Funk Bass 2	
	Funk Bass 3	
	Funk Bass 4	
	Funk Bass 5	
	Funk Bass 6	
	Funk Bass 7	
	Funk Bass 8	
	Funk Bass 9	
	Funk Bass 10	
	Funk Bass 11	
	Funk Bass 12	
	Funk Bass 13	
2	Dance Bass 1	
	Dance Bass 2	
	Dance Bass 3	
	Dance Bass 4	
	Dance Bass 5	
	Dance Bass 6	
	Dance Bass 7	
	Dance Bass 8	
	Dance Bass 9	
	Dance Bass 10	
	Dance Bass 11	
	Dance Bass 12	
	Dance Bass 13	
	Dance Bass 14	
	Dance Bass 15	
	Dance Bass 16	
3	Electro Bass 1	
	Electro Bass 2	
	Electro Bass 3	
	Electro Bass 4	
	Electro Bass 5	
	Electro Bass 6	
	Electro Bass 7	
	Electro Bass 8	
	Electro Bass 9	
	Electro Bass 10	
	Electro Bass 11	
	Electro Bass 12	
4	Club Bass 1	
	Club Bass 2	
	Club Bass 3	
	Club Bass 4	
	Club Bass 5	
	Club Bass 6	
	Club Bass 7	
	Club Bass 8	
	Club Bass 9	
	Club Bass 10	
	Club Bass 11	
	Club Bass 12	

4	Club Bass 13	
5	Smooth Bass 1	
	Smooth Bass 2	
	Smooth Bass 3	
	Smooth Bass 4	
	Smooth Bass 5	
	Smooth Bass 6	
	Smooth Bass 7	
	Smooth Bass 8	
	Smooth Bass 9	
	Smooth Bass 10	
	Smooth Bass 11	
	Smooth Bass 12	
	Smooth Bass 13	
	Smooth Bass 14	
	Smooth Bass 15	
6	Deep Bass 1	
	Deep Bass 2	
	Deep Bass 3	
	Deep Bass 4	
	Deep Bass 5	
	Deep Bass 6	
	Deep Bass 7	
	Deep Bass 8	
7	Fat Bass 1	
	Fat Bass 2	
	Fat Bass 3	
	Fat Bass 4	
	Fat Bass 5	
	Fat Bass 6	
	Fat Bass 7	
	Fat Bass 8	
	Fat Bass 9	
	Fat Bass 10	
8	Fat Low Bass 1	
	Fat Low Bass 2	
	Fat Low Bass 3	
	Fat Low Bass 4	
	Fat Low Bass 5	
	Fat Low Bass 6	
	Fat Low Bass 7	
	Fat Low Bass 8	
	Fat Low Bass 9	
	Fat Low Bass 10	
	Fat Low Bass 11	
	Fat Low Bass 12	
	Fat Low Bass 13	
	Fat Low Bass 14	
	Fat Low Bass 15	
9	Vocal Bass 1	
	Vocal Bass 2	

WORLD

1	Pan Flute 1	
	Pan Flute 2	
	Pan Flute 3	
	Pan Flute 4	
	S-Pan Flute 1	*1,*2,*3
	S-Pan Flute 2	*1,*2,*3
	S-Celtic Flute 1	*1,*2,*3
	S-Celtic Flute 2	*1,*2,*3
	S-Celtic Flute 3	*1,*2,*3
	S-Celtic Flute 4	*1,*2,*3
	S-Duduk 1	*1,*2,*3
	S-Duduk 2	*1,*2,*3
2	S-Irish Pipe 1	*1,*2,*3
	S-Irish Pipe 2	*1,*2,*3
	Bagpipe	
	Dulcimer 1	
	Dulcimer 2	
	Dulcimer 3	
3	Zither	
	Shakuhachi	
	S-Shakuhachi 1	*1,*2,*3
	S-Shakuhachi 2	*1,*2,*3
	Yokobue	
	Shamisen 1	
	Shamisen 2	
	Shamisen 3	
	Koto 1	
	Koto 2	
	Taisho Koto	
4	Er Hu 1	
	Er Hu 2	
	Er Hu 3	
	Er Hu 4	
	Er Hu 5	
	Er Hu Ensemble	
	Ban Hu	
	Gao Hu	
	Jing Hu	
	Ma Tou Qin 1	
	Ma Tou Qin 2	
5	Pi Pa 1	
	Pi Pa 2	
	S-Pi Pa 1	*2
	S-Pi Pa 2	*2
	Pi Pa Ensemble	
	Liu Qin 1	
	Liu Qin 2	
	S-Liu Qin	*2
	Zhong Ruan	
	S-Zhong Ruan	*2
	San Xian 1	
	San Xian 2	
	S-San Xian	*2
6	Gu Zheng 1	
	Gu Zheng 2	
	Gu Zheng 3	
	S-Gu Zheng	*2
	S-Gu Qin 1	*2
	S-Gu Qin 2	*2
	Yang Qin 1	
	Yang Qin 2	
	Yang Qin 3	
	Tan Bo Ensemble	

7	Di Zi 1	
	Di Zi 2	
	Xiao	
	Xun	
	Suo Na 1	
	Suo Na 2	
	Guan Zi	
	Sheng 1	
	Sheng 2	
	Sheng 3	
	Hu Lu Si 1	
	Hu Lu Si 2	
	Tsuur	
	S-Tsuur	*2
8	Kamanche	
	Nay	
	Surnay	
	Oud	
	Sitar 1	
	Sitar 2	
	Sitar 3	
	Kalimba	
	Log Drum	
	Steel Drum	
	S-Steel Drum	*2

Super Articulation Voice Supplementary List

This list describes the effects that are produced by playing the Super Articulation Voices (having names beginning with the prefix “S-”). Explanations of the column titles are as follows:

•Super Articulation

Describes performance effects that can be produced by playing the keyboard without having to change the Voice settings. “(AEM)” in this column indicates that Yamaha’s proprietary AEM (Articulation Element Modeling) technology is used. During performance, the most appropriate sound samples are selected in sequence in real time, from huge quantities of sampled data. They are smoothly joined and reproduced—as would naturally occur on an actual acoustic instrument. “Key-off Samples” refers to the special, characteristic sound which results when releasing the key.

•AUTO

Describes the effects produced by playing the keyboard when setting AUTO to ON in the [CONDITION 1] tab of the Voice Condition display. An effect marked with “(octave)” will be produced only when you play intervals of minor 7th, major 7th or octave in legato.

•ART.1 / ART.2 / ART.3

Describes the effects obtained by assigning Articulation 1–3 to a Footswitch and pressing the Footswitch while playing the keyboard.

An effect with the two indications “****/****” means: (1) the effect that is produced when pressing a key while holding the Footswitch, and (2) the effect produced when releasing a key while holding the Footswitch.

For example, “Grace Note/Bend Down” indicates that the Grace Note is added by pressing a key while holding the Footswitch while the Bend Down effect is applied by releasing a key while holding the Footswitch. An effect indicated by “Sound Effect” is applied when you just simply press the Footswitch. An effect having other indications is applied when you press a key while turning on the Footswitch.

•Type

Lists one of the five types A – E, each of which is determined by the conditions under which the Voice is played.

TypeA: When either ART.1 or ART.2 is selected, pressing the Footswitch will produce a sound effect.

TypeB: When ART.1 is selected, pressing and holding the Footswitch while playing the keyboard reproduces instrument-specific articulations.

TypeC: Depending on the Voice, repeatedly playing a key may switch the articulation or cause the sound to change naturally. For some Voices, selecting ART.1 or ART.2 and operating the Footswitch switches among instrument-specific articulations or produces a sound effect.

TypeD: When ART.1, ART.2, or ART.3 is selected, pressing and holding the Footswitch while playing the keyboard switches among instrument-specific articulations between key press and key release. For some Voices, setting AUTO to ON automatically reproduces instrument-specific articulations according to your performance.

TypeE: Pitch bend is applied only to the lowest note of a chord.

Category	Voice Name	SUPER ARTICULATION	AUTO	ART.1	ART.2	ART.3	Type
STRINGS/ VIOLIN	S-Strings 1	Legato	-	-	-	-	-
	S-Strings 2	Legato	-	-	-	-	-
	S-Strings 3	Legato	-	-	-	-	-
	S-Strings 4	Key-off Samples, Legato	-	-	-	-	-
	S-Strings 5	Legato	-	-	-	-	-
	S-Strings 6	Legato	-	-	-	-	-
	S-Slow Strings 1	Key-off Samples, Legato	-	-	-	-	-
	S-Slow Strings 2	Key-off Samples, Legato	-	-	-	-	-
	S-Slow Strings 3	Legato	-	-	-	-	-
	S-Slow Strings 4	Legato	-	-	-	-	-
	S-Violin Sect 1	Key-off Samples, Legato	-	-	-	-	-
	S-Violin Sect 2	Legato	-	-	-	-	-
	S-Violin Sect 3	Legato	-	-	-	-	-
	S-Viola Sect 1	Key-off Samples, Legato	-	-	-	-	-
	S-Viola Sect 2	Legato	-	-	-	-	-

Category	Voice Name	SUPER ARTICULATION	AUTO	ART.1	ART.2	ART.3	Type
STRINGS/ VIOLIN	S-Cello Sect 1	Key-off Samples, Legato	-	-	-	-	-
	S-Cello Sect 2	Key-off Samples, Legato	-	-	-	-	-
	S-Cello Sect 3	Legato	-	-	-	-	-
	S-Strs Vn&Vc	Key-off Samples, Legato	-	-	-	-	-
	S-Strs Vn&Va&Vc	Key-off Samples, Legato	-	-	-	-	-
	S-Strs Quartet	Legato	-	-	-	-	-
	S-Tremolo Strs	Key-off Samples, Legato	-	-	-	-	-
	S-TremoloViolins	Key-off Samples, Legato	-	-	-	-	-
	S-Tremolo Violas	Key-off Samples, Legato	-	-	-	-	-
	S-Tremolo Cellos	Key-off Samples, Legato	-	-	-	-	-
	S-Octave Strs 1	Key-off Samples, Legato	-	-	-	-	-
	S-Octave Strs 2	Key-off Samples, Legato	-	-	-	-	-
	S-Violin 1	Key-off Samples, Legato (AEM)	Bend Up, Bend Down, Portamento (Octave)	Bend Up / Bend Down	Grace Note / Bend Down	-	D
	S-Violin 2	Key-off Samples, Legato (AEM)	Portamento (Octave)	Grace Note / Bend Down	Bend Up / Bend Down	-	D
	S-Violin 3	Legato	-	-	-	-	-
	S-Violin 4	Legato	-	-	-	-	-
	S-Viola	Legato	-	-	-	-	-
	S-Cello 1	Legato	-	-	-	-	-
	S-Cello 2	Key-off Samples, Legato (AEM)	-	Grace Note / Bend Down	Tremolo	Pizzicato	D
	S-Cello 3	Key-off Samples, Legato (AEM)	Grace Note	Bend Up / Bend Down	Staccato	Pizzicato	D
CONTRABASS	S-Contrabass 1	Key-off Samples, Legato	-	-	-	-	-
	S-Contrabass 2	Legato	-	-	-	-	-
	S-Cb Tremolo	Key-off Samples, Legato	-	-	-	-	-
	S-AcousticBass 1	Legato	-	Sound Effect	Sound Effect	-	A
	S-AcousticBass 2	Legato	-	Sound Effect	Sound Effect	-	A
	S-AcousticBass 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-AcousticBass 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-AcousticBass 5	Key-off Samples, Cycle	-	Bend Up	-	-	C
	S-AcousticBass 6	Key-off Samples	-	Sound Effect	Sound Effect	-	A
	S-Aco Bass Slap	Key-off Samples	-	Sound Effect	Sound Effect	-	A
BRASS/ TRUMPET	S-BrsSect Legato	Legato	-	-	-	-	-
	S-BrsSect Fall	-	-	Fall Down	-	-	B
	S-BrsSect Up	-	-	Glissando Up	-	-	B
	S-Trumpet 1	Legato (AEM)	Bend Up, Bend Down, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Trumpet 2	Legato (AEM)	Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Trumpet 3	Key-off Samples, Legato (AEM)	Bend Up, Bend Down, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	Tremolo	D
	S-Trumpet 4	Key-off Samples, Legato (AEM)	Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	Grace Note / Bend Down	D
	S-Trumpet Fall	-	-	Glissando Up	-	-	B
	S-Trumpet Shake	-	-	Shake	-	-	B
	S-Muted Trumpet	Key-off Samples, Legato (AEM)	Bend Down, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	Grace Note / Bend Down	D
	S-Flugelhorn	Key-off Samples, Legato (AEM)	Grace Note, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	Tremolo	D
	S-Trombone 1	Legato (AEM)	Bend Up, Bend Down, Glissando (Octave)	Bend Up (Fast) / Bend Down	Bend Up (Slow) / Glissando Down	-	D
	S-Trombone 2	Key-off Samples, Legato (AEM)	Bend Up, Bend Down, Glissando (Octave)	Bend Up (Slow) / Bend Down	Glissando Up / Glissando Down	Bend Up (Fast) / Bend Down	D
	S-Bass Trb 1	Key-off Samples, Legato (AEM)	Bend Up, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	Staccato	D

Category	Voice Name	SUPER ARTICULATION	AUTO	ART.1	ART.2	ART.3	Type
BRASS/ TRUMPET	S-Bass Trb 2	Key-off Samples, Legato (AEM)	Bend Up, Glissando (Octave)	Bend Down&Up / Bend Down	Bend Up (Fast) / Bend Down	Bend Up (Slow) / Glissando Down	D
	S-Horn 1	Key-off Samples, Legato (AEM)	Glissando (Octave)	Grace Note / Glissando Down	Glissando Up / Glissando Down	Trill	D
	S-Horn 2	Key-off Samples, Legato (AEM)	Glissando (Octave)	Grace Note / Glissando Down	Glissando Up / Glissando Down	Staccato	D
	S-Horn Section	Legato	-	-	-	-	-
	S-Muted Horn	Legato	-	-	-	-	-
WOODWIND/ FLUTE	S-Flute	Key-off Samples, Legato (AEM)	-	Grace Note / Bend Down	Glissando Up / Glissando Down	-	D
	S-Flute Flutter	Key-off Samples, Legato (AEM)	Grace Note, Glissando (Octave)	Grace Note / Bend Down	Glissando Up / Glissando Down	-	D
	S-Piccolo 1	Key-off Samples, Legato (AEM)	Glissando (Octave)	Grace Note / Glissando Down	Trill	Staccato	D
	S-Piccolo 2	Key-off Samples, Legato (AEM)	Glissando (Octave)	Grace Note / Glissando Down	Glissando Up / Glissando Down	Trill	D
	S-Whistle 1	Cycle	-	Sound Effect	Sound Effect	-	C
	S-Whistle 2	Cycle	-	Sound Effect	Sound Effect	-	C
	S-Whistle 3	Cycle	-	Sound Effect	Sound Effect	-	C
	S-Clarinet 1	Legato (AEM)	Grace Note, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Clarinet 2	Legato (AEM)	Bend Up, Bend Down, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Oboe 1	Key-off Samples, Legato (AEM)	-	Grace Note / Glissando Down	Trill	Staccato	D
	S-Oboe 2	Key-off Samples, Legato (AEM)	Grace Note, Glissando (Octave)	Grace Note / Glissando Down	Glissando Up / Glissando Down	Staccato	D
	S-Oboe 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Bassoon 1	Key-off Samples, Legato (AEM)	-	Grace Note / Glissando Down	Trill	Staccato	D
	S-Bassoon 2	Key-off Samples, Legato (AEM)	Grace Note, Glissando (Octave)	Grace Note / Glissando Down	Glissando Up / Glissando Down	Staccato	D
	S-Alto Sax 1	Key-off Samples, Legato (AEM)	Bend Up, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Alto Sax 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Alto Sax 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Alto Sax Growl	Key-off Samples, Legato (AEM)	Bend Up, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Tenor Sax 1	Key-off Samples, Legato (AEM)	Bend Up, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Tenor Sax 2	Legato (AEM)	Bend Up, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Tenor Sax 3	Legato (AEM)	Bend Up, Bend Down, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Tenor Sax 4	Key-off Samples, Legato (AEM)	-	Bend Up (Slow) / Bend Down (Fast)	Glissando Up / Glissando Down	Bend Up (Fast) / Bend Down (Slow)	D
	S-TenorSax Growl	Key-off Samples, Legato (AEM)	Bend Up, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Soprano Sax	Key-off Samples, Legato (AEM)	Grace Note, Glissando (Octave)	Grace Note / Bend Down (Fast)	Bend Up / Bend Down (Slow)	-	D
	S-SprnoSax Growl	Key-off Samples, Legato (AEM)	Bend Up, Glissando (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Baritone Sax 1	Key-off Samples, Legato (AEM)	Bend Up, Glissando (Octave)	Bend Up (Slow) / Bend Down (Fast)	Glissando Up / Glissando Down	Bend Up (Fast) / Bend Down (Slow)	D
	S-Baritone Sax 2	Key-off Samples, Legato (AEM)	-	Bend Up (Fast) / Bend Down	Bend Up (Slow) / Glissando Down	Growl	D
	S-Baritone Sax 3	Key-off Samples, Legato (AEM)	-	Bend Up (Slow) / Bend Down (Fast)	Glissando Up / Glissando Down	Bend Up (Fast) / Bend Down (Slow)	D
	S-Sax Ens 1	Legato	-	Sound Effect	Sound Effect	-	A
	S-Sax Ens 2	Legato	-	Sound Effect	Sound Effect	-	A
	S-Sax Ens 3	Legato	-	Sound Effect	Sound Effect	-	A
	S-Sax Ens 4	Legato	-	Sound Effect	Sound Effect	-	A
TUTTI	S-Sect Horns	Legato	-	-	-	-	-
	S-SectHorns Fall	-	-	Fall Down	-	-	B
	S-SectHorns Up	-	-	Glissando Up	-	-	B
	S-SectHorns Shk	Key-off Samples	-	Shake	-	-	B
	S-PopHorns Fall	-	-	Fall Down	-	-	B
	S-PopHorns Up	-	-	Glissando Up	-	-	B
	S-PopHorns Shake	-	-	Shake	-	-	B

Category	Voice Name	SUPER ARTICULATION	AUTO	ART.1	ART.2	ART.3	Type
CHOIR	S-ComeOnLetsGo 1	Cycle	-	-	-	-	C
	S-ComeOnLetsGo 2	Cycle	-	-	-	-	C
	S-IWantYouBack 1	Cycle	-	-	-	-	C
	S-IWantYouBack 2	Cycle	-	-	-	-	C
	S-Dn'tBrkMyHrt 1	Cycle	-	-	-	-	C
	S-Dn'tBrkMyHrt 2	Cycle	-	-	-	-	C
	S-ChoirSoft Aah	Legato	-	-	-	-	-
	S-ChoirBoys Aah	Legato	-	-	-	-	-
	S-ChoirSoft Ooh	Legato	-	-	-	-	-
	S-ChoirBoys Ooh	Legato	-	-	-	-	-
	S-GsplChr Hmm	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-GsplChr Hm/Ah	-	-	"Aah"	-	-	B
	S-GsplChr Wow	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-GsplChr W/Hey	-	-	"Hey"	-	-	B
	S-GsplChr Hey	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-ShoBeDoBa/Hmm	Cycle	-	"Hmm"	-	-	C
	S-ShoBeDoBa/Wah	Cycle	-	"Wah"	-	-	C
	S-ShoBeDoBa/Doo	Cycle	-	"Doo"	-	-	C
	S-ShoBaDoBa/Daa	Cycle	-	"Daa"	-	-	C
	S-DoBaBe/Shoo	Cycle	-	"Shoo"	-	-	C
	S-DoBeDoBe/Wah	Cycle	-	"Wah"	-	-	C
	S-DoBeBaDa/DoWe	Cycle	-	"DoWe"	-	-	C
	S-BaDaYah/Doo	Cycle	-	"Doo"	-	-	C
	S-YaBaDaBa/Doo	Cycle	-	"Doo"	-	-	C
	S-WahHoo/Doo	Cycle	-	"Doo"	-	-	C
	S-Scat/Doo	Cycle	-	"Doo"	-	-	C
	S-Scat/DoWe	Cycle	-	"DoWe"	-	-	C
	S-Scat/SFX 1	Legato	-	Sound Effect	Sound Effect	-	A
	S-Scat/SFX 2	Legato	-	Sound Effect	Sound Effect	-	A
	S-Scat/SFX 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-WhtShouldWeDo	Cycle	-	"Wah"	-	-	C
	S-WhoAreYou/Wee	Cycle	-	"Wee"	-	-	C
	S-DoWeYouBe/Wah	Cycle	-	"Wah"	-	-	C
	S-HaaVibrato/SFX	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-OohVibrato/SFX	Legato	-	Sound Effect	Sound Effect	-	A
	S-OohBoysVib/SFX	Legato	-	Sound Effect	Sound Effect	-	A
	S-OhGirlsVib/SFX	Legato	-	Sound Effect	Sound Effect	-	A
	S-DooVibrato/SFX	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DooBoys/SFX	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DooGirls/SFX	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DaaVibrato/SFX	Legato	-	Sound Effect	Sound Effect	-	A
	S-BaaVibrato/SFX	Legato	-	Sound Effect	Sound Effect	-	A
	S-WahVibrato/SFX	Legato	-	Sound Effect	Sound Effect	-	A
	S-Wah Soft/SFX	Legato	-	Sound Effect	Sound Effect	-	A
	S-YooVibrato/SFX	Legato	-	Sound Effect	Sound Effect	-	A
ORGAN	S-Harmonica	Legato (AEM)	Grace Note, Bend Down, Legato (Octave)	Bend Up / Bend Down (Fast)	Grace Note / Bend Down (Slow)	-	D
	S-BluesHarmonica	Legato (AEM)	Grace Note, Bend Down, Legato (Octave)	Bend Up / Bend Down (Fast)	Grace Note / Bend Down (Slow)	-	D

Category	Voice Name	SUPER ARTICULATION	AUTO	ART.1	ART.2	ART.3	Type
PIANO	S-Piano 1	Key-off Samples	-	-	-	-	-
	S-Piano 2	Key-off Samples	-	-	-	-	-
	S-Piano 3	Key-off Samples	-	-	-	-	-
	S-Piano 4	Key-off Samples	-	-	-	-	-
	S-Piano 5	Key-off Samples	-	-	-	-	-
	S-Piano 6	Key-off Samples	-	-	-	-	-
	S-Piano 7	Key-off Samples	-	-	-	-	-
	S-Character Gd 1	Key-off Samples	-	-	-	-	-
	S-Character Gd 2	Key-off Samples	-	-	-	-	-
	S-Honkytonk	Key-off Samples	-	-	-	-	-
	S-Octave Piano 1	Key-off Samples	-	-	-	-	-
	S-Octave Piano 2	Key-off Samples	-	-	-	-	-
	S-Octave Piano 3	Key-off Samples	-	-	-	-	-
	S-Octave Piano 4	Key-off Samples	-	-	-	-	-
	S-Oct Upright 1	Key-off Samples	-	-	-	-	-
	S-Oct Upright 2	Key-off Samples	-	-	-	-	-
	S-Cocktail Grand	Key-off Samples	-	-	-	-	-
	S-Piano&DX EP 1	Key-off Samples	-	-	-	-	-
	S-Piano&DX EP 2	Key-off Samples	-	-	-	-	-
	S-Piano&DX EP 3	Key-off Samples	-	-	-	-	-
	S-Piano&Strs	Key-off Samples	-	-	-	-	-
	S-Piano&Pad 1	Key-off Samples	-	-	-	-	-
	S-Piano&Pad 2	Key-off Samples	-	-	-	-	-
	S-Piano&Pad 3	Key-off Samples	-	-	-	-	-
	S-Piano&Pad 4	Key-off Samples	-	-	-	-	-
	S-Harpsichord	Key-off Samples	-	-	-	-	-
	S-DX E.Piano	-	-	-	-	-	-
	S-StageE.Piano 1	Key-off Samples	-	-	-	-	-
	S-StageE.Piano 2	Key-off Samples	-	-	-	-	-
	S-StageE.Piano 3	Key-off Samples	-	-	-	-	-
	S-StageE.Piano 4	Key-off Samples	-	-	-	-	-
	S-StageE.Piano 5	Key-off Samples	-	-	-	-	-
	S-StageE.Piano 6	Key-off Samples	-	-	-	-	-
	S-StageE.Piano 7	Key-off Samples	-	-	-	-	-
	S-StageE.Piano 8	Key-off Samples	-	-	-	-	-
	S-StageE.Piano 9	Key-off Samples	-	-	-	-	-
	S-StageE.Piano10	Key-off Samples	-	-	-	-	-
	S-StageE.Piano11	Key-off Samples	-	-	-	-	-
	S-StageE.Piano12	Key-off Samples	-	-	-	-	-
	S-StageE.Piano13	Key-off Samples	-	-	-	-	-
	S-StageE.Piano14	Key-off Samples	-	-	-	-	-
	S-StageE.Piano15	Key-off Samples	-	-	-	-	-
	S-EP&FeltPiano	Key-off Samples	-	-	-	-	-
	S-E.Grand CP80 1	Key-off Samples	-	-	-	-	-
	S-E.Grand CP80 2	Key-off Samples	-	-	-	-	-
	S-E.Grand CP80 3	Key-off Samples	-	-	-	-	-
	S-E.Grand CP80 4	Key-off Samples	-	-	-	-	-
	S-Clavi 1	Key-off Samples	-	-	-	-	-
	S-Clavi 2	Key-off Samples	-	-	-	-	-
	S-Clavi 3	Key-off Samples	-	-	-	-	-
	S-Muted Clavi	Key-off Samples	-	-	-	-	-

Category	Voice Name	SUPER ARTICULATION	AUTO	ART.1	ART.2	ART.3	Type
GUITAR	S-Nylon Guitar 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Nylon Guitar 2	Key-off Samples	-	Harmonics	-	-	B
	S-Nylon Guitar 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Nylon Guitar 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Nylon Gt Amp 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Nylon Gt Amp 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Flamenco Gtr 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Flamenco Gtr 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Flamenco Gtr 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Steel Guitar 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Steel Guitar 2	Key-off Samples	-	Harmonics	-	-	B
	S-Steel Guitar 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Steel Guitar 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Steel Guitar 5	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Steel Guitar 6	Key-off Samples, Legato, Cycle	-	Sound Effect	Sound Effect	-	C
	S-SteelGt Amp 1	Key-off Samples	-	Mute, Slap	-	-	B
	S-SteelGt Amp 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-SteelGt Amp 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-SteelGt Amp 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-SteelGt Strum1	Key-off Samples, Cycle	-	Sound Effect	Sound Effect	-	C
	S-SteelGt Strum2	Key-off Samples, Cycle	-	Sound Effect	Sound Effect	-	C
	S-12Str Guitar 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-12Str Guitar 2	Key-off Samples, Cycle	-	Grace Note	-	-	C
	S-12Str Gt Twin	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Jazz Guitar 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Jazz Guitar 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Jazz Guitar 3	Key-off Samples	-	Octave Playing	-	-	B
	S-Jazz Guitar 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Jazz Guitar 5	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-ElectroAco 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-ElectroAco 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Ukulele	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Ukulele Strum	Key-off Samples, Cycle	-	Sound Effect	Sound Effect	-	C
	S-Clean Solid 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Solid 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Solid 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Solid 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Solid 5	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Guitar 1	Key-off Samples	-	Harmonics	-	-	B
	S-Clean Guitar 2	Key-off Samples	-	Harmonics	-	-	B
	S-Clean Guitar 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Guitar 4	-	-	Sound Effect	Sound Effect	-	A

Category	Voice Name	SUPER ARTICULATION	AUTO	ART.1	ART.2	ART.3	Type
GUITAR	S-Clean Guitar 5	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Guitar 6	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Finger 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Finger 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Finger 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Clean Finger 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-CleanVintage 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-CleanVintage 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-CleanVintage 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-CleanVintage 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-CleanVintage 5	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-CleanVintage 6	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-CleanVintage 7	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Solid 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Solid 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Solid 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Solid 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Solid 5	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Solid 6	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Solid 7	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Solid 8	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DistVintage 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DistVintage 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DistVintage 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DistVintage 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DistVintage 5	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DistVintage 6	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-DistVintage 7	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Crunch 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Crunch 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Crunch 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Crunch 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Finger 1	-	-	Grace Note	-	-	B
	S-Dist Finger 2	-	-	Grace Note	-	-	B
	S-Dist Finger 3	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Finger 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Dist Mute 1	Key-off Samples	-	Sound Effect	Sound Effect	-	A
	S-Dist Mute 2	Key-off Samples	-	Sound Effect	Sound Effect	-	A
	S-Dist Mute 3	Key-off Samples	-	Sound Effect	Sound Effect	-	A
	S-Dist Mute 4	Key-off Samples	-	Sound Effect	Sound Effect	-	A

Category	Voice Name	SUPER ARTICULATION	AUTO	ART.1	ART.2	ART.3	Type
GUITAR	S-Dist Mute 5	Key-off Samples	-	Sound Effect	Sound Effect	-	A
	S-Dist Mute 6	-	-	Sound Effect	Sound Effect	-	A
	S-Dist Mute 7	-	-	Sound Effect	Sound Effect	-	A
	S-Mandolin	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Mandolin Mute	Legato	-	Sound Effect	Sound Effect	-	A
	S-PedalSteelGt 1	Key-off Samples, Pitch Bend (Only Lowest Note)	-	-	-	-	E
	S-PedalSteelGt 2	Pitch Bend (Only Lowest Note)	-	-	-	-	E
TIMPANI	S-Timpani Roll	Key-off Samples	-	-	-	-	-
	S-TimpaniRoll fp	Key-off Samples	-	-	-	-	-
ELECTRIC BASS	S-Fingerd Bass 1	Key-off Samples	-	Sound Effect	Sound Effect	-	A
	S-Fingerd Bass 2	Key-off Samples	-	Sound Effect	Sound Effect	-	A
	S-Fingerd Bass 3	Key-off Samples	-	Sound Effect	Sound Effect	-	A
	S-Fingerd Bass 4	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Fingerd Bass 5	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Fingerd Bass 6	Key-off Samples, Legato (AEM)	-	Glissando Up / Glissando Down	Glissando Down (Shot)	Mute	D
	S-Fingerd Bass 7	Key-off Samples, Legato (AEM)	-	Grace Note / Glissando Down	Trill	Mute	D
	S-Fingerd Bass 8	Key-off Samples, Legato (AEM)	-	Glissando Up / Glissando Down	Slap	Glissando Up&Down (Shot)	D
	S-Fingerd Bass 9	Key-off Samples, Legato (AEM)	Glissando (Octave)	Grace Note / Glissando Down	Glissando Down (Shot)	Harmonics	D
	S-Slap Bass 1	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Slap Bass 2	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Fretless Bass	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
WORLD	S-Pan Flute 1	Legato (AEM)	Bend Up, Glissando Up (Octave)	Bend Up (Fast) / Bend Down	Bend Up (Slow) / Bend Down	-	D
	S-Pan Flute 2	Legato (AEM)	Bend Up, Glissando Up (Octave)	Bend Up / Bend Down	Glissando Up / Glissando Down	-	D
	S-Celtic Flute 1	Key-off Samples, Legato (AEM)	Bend Up, Bend Down	Bend Up (Fast) / Bend Down (Fast)	Grace Note / Bend Down (Slow)	Bend Up (Slow) / Bend Down (Slow)	D
	S-Celtic Flute 2	Key-off Samples, Legato (AEM)	Bend Down	Bend Up (Fast) / Bend Down (Fast)	Grace Note / Bend Down (Slow)	Bend Up (Slow) / Bend Down (Slow)	D
	S-Celtic Flute 3	Key-off Samples, Legato (AEM)	Grace Note	Bend Up (Fast) / Bend Down (Fast)	Grace Note / Bend Down (Slow)	Bend Up (Slow) / Bend Down (Slow)	D
	S-Celtic Flute 4	Key-off Samples, Legato (AEM)	Grace Note	Bend Up (Fast) / Bend Down (Fast)	Grace Note / Bend Down (Slow)	Bend Up (Slow) / Bend Down (Slow)	D
	S-Duduk 1	Key-off Samples, Legato (AEM)	Bend Up	Grace Note / Bend Down	Grace Note / Bend Down	Tremolo	D
	S-Duduk 2	Key-off Samples, Legato (AEM)	Bend Up	Grace Note / Bend Down	Grace Note / Bend Down	Tremolo	D
	S-Irish Pipe 1	Legato, Grace Note (AEM)	Bend Up, Bend Down, Grace Note (Octave)	Bend Up / Bend Down	Grace Note / Bend Down	-	D
	S-Irish Pipe 2	Legato, Grace Note (AEM)	Grace Note, Bend Down	Bend Up / Bend Down	Grace Note / Bend Down	-	D
	S-Shakuhachi 1	Key-off Samples, Legato (AEM)	-	Grace Note / Bend Down (Fast)	Bend Up / Bend Down (Slow)	Flutter	D
	S-Shakuhachi 2	Key-off Samples, Legato (AEM)	-	Bend Up / Bend Down (Fast)	Grace Note / Bend Down (Slow)	Trill	D
	S-Pi Pa 1	Key-off Samples	-	-	-	-	-
	S-Pi Pa 2	-	-	Harmonics	-	-	B
	S-Liu Qin	Key-off Samples	-	Harmonics	-	-	B
	S-Zhong Ruan	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-San Xian	Key-off Samples, Legato	-	-	-	-	-
	S-Gu Zheng	-	-	Sound Effect	Sound Effect	-	A
	S-Gu Qin 1	Legato	-	Sound Effect	Sound Effect	-	A
	S-Gu Qin 2	-	-	Harmonics	-	-	B
	S-Tsuur	Key-off Samples, Legato	-	Sound Effect	Sound Effect	-	A
	S-Steel Drum	Cycle	-	-	-	-	C

VA Voice List (ELS-03X/ELS-03XR/ELS-03XF)

The ELS-03X, ELS-03XR, and ELS-03XF are equipped with Voices created with a VA (Virtual Acoustic) tone generator. These Voices can be selected only when the User button for Lead Voice 2 is pressed.

The Page numbers in this list correspond to the page numbers shown on the Electone display.

NOTE

- Voices that do not have a specified ideal note range (as indicated by "---" in the chart below) can be played in any range and result in optimum sound with stable pitch.
- Each acoustic instrument has its own ideal note range. Keep in mind that playing outside of the range may create unexpected and unrealistic sounds.
- Voices marked with an asterisk (*) in the rightmost column sound one octave lower than other Voices when a FEET (Length) setting is specified on the [CONDITION 1] tab of the Voice Condition display.

Page	Voice Name	Range	Description	*
1	V-Flute 1	G2–A6	Flute with breath and other noises, which may squeak in the higher registers. Setting the Touch Tone (After) higher and applying keyboard pressure can recreate flutter tonguing.	
	V-Flute 2	C2–C6	Flute ideal for legato playing. Setting the User Vibrato depth to higher values creates a nice effect.	
	V-Ocarina	C3–C6	Soft ocarina.	
	V-Oboe	C3–F5	Wider dynamic range with the Touch Tone effect.	
	V-Clarinet	D2–F5	Playing pianissimo creates breath noises, while playing fortissimo creates a brighter sound with slightly lower pitch.	
	V-Soprano Sax	A#2–D5	Rounder and softer soprano saxophone.	
	V-Alto Sax 1	D#2–G4	A bright alto saxophone for contemporary music. You can make the sound 'break up' as if overblowing the instrument by setting After Touch to maximum and applying pressure to the key.	
	V-Alto Sax 2	C2–E4	Alto saxophone ideal for fusion music. Playing legato creates squeaky attack sounds and high After Touch settings produce an overblowing effect.	
	V-Tenor Sax 1	A#2–C4	Multi-purpose tenor saxophone. Soft in pianissimo and brighter in fortissimo.	
	V-Tenor Sax 2	C1–G4	Soft tenor saxophone ideal for jazz. Playing Legato creates squeaky attack sounds.	
	V-Breath Sax 1	A#2–C4	Soft, breathy tenor saxophone ideal for slow tempo music.	
	V-Breath Sax 2	C2–E4	Brighter, breathy tenor saxophone ideal for jazz.	
2	V-Trumpet 1	A#2–A#4	Soft trumpet. Slides and glissandos can be created with Horizontal Touch.	
	V-Trumpet 2	C2–C5	Trumpet with characteristic attack sound. Lip slurs can be created by changing the pitch.	
	V-Trumpet 3	G2–C5	Soft trumpet. Applying slight keyboard pressure produces breath noise.	
	V-Muted Trumpet	A#2–A#4	Cup-muted trumpet.	
	V-Trombone	E1–G3	Slides and glissandos can be created with Horizontal Touch. Also, high After Touch settings produce an overblowing effect.	
	V-High Trombone	C2–C5	Brighter trombone ideal for high notes.	
	V-Shakuhachi	---	Higher Touch Tone (After) setting increases breath noise and also squeaking sounds.	
	V-Erhu	---	Playing with softer touch produces hoarse sounds.	
	V-Sitar	---	Playing with harder touch squeaks the sounds.	
3	V-Pan Pipe 1	E2–G5	Setting the Touch Tone (After) higher and applying keyboard pressure can result in flutter tonguing.	
	V-Pan Pipe 2	C1–C6	Panpipe flute sound. After and Initial Touch affect the pitch and timbre.	
	V-Bamboo	C1–C6	Bamboo panpipe sound with breath noise. After Touch changes the pitch dynamically.	
	V-Bottle	C1–C6	Sound of blowing over a bottle top. Playing trills over a wide interval range creates a squeaky attack sound.	
	V-Floboe	F2–C7	A hybrid sound combining oboe and saxophone.	
	V-Alt Kwek	C3–C7	A hybrid sound grafting an oboe reed onto a piccolo, with a distinctive pitch change in the low registers.	
	V-Tin Whistle	C2–C7	Sound of a small flute. Playing with softer touch produces breath noise.	
	V-India	---	Percussive sitar sound.	
	V-East	G1–C5	Sitar with resonance and reverberation.	
	V-Zag	---	Simulation of a bowed ethnic instrument. Playing legato brings out higher octave sounds.	
4	V-Asian Pluck	C1–G6	Plucked ethnic instrument. Using Initial Touch brings out higher octave sounds.	
	V-Air Reed 1	A2–C5	A hybrid sound grafting an oboe reed onto a saxophone. High After Touch settings produce an overblowing effect.	
	V-Air Reed 2	E2–C5	A hybrid sound combining a conventional flute with panpipes.	
	V-Airphone	A2–C5	A hybrid sound grafting an oboe reed onto a soprano saxophone.	
	V-Thin Reed	E2–G5	A hybrid sound grafting a clarinet mouthpiece onto a flute. High After Touch settings produce an overblowing effect.	
	V-Harmophone	G1–G5	A hybrid sound combining a harmonica and saxophone. Depending on the use of Touch Tone, both breath noise and a bright clear sound can be produced.	
	V-Saxonica	G2–G5	Harmonica sound resembling an alto saxophone. Playing with soft touch results in a high-pitched sound.	
	V-Grass Reed	E2–G5	A hybrid sound grafting a bassoon reed onto a brass wind instrument. After Touch changes the pitch.	
	V-Soft Reed 1	A2–G5	A hybrid sound grafting a clarinet mouthpiece to a brass wind instrument.	
	V-Soft Reed 2	C1–C6	A hybrid sound grafting a bassoon reed onto a soprano saxophone; includes breath noise.	
	V-Tropo	E1–C6	Thick bassoon sound. After Touch changes the pitch dynamically, and applying keyboard pressure more produces wind noise.	

Page	Voice Name	Range	Description	*
5	V-Buzz String	A2–F5	Simulation of a hybrid bowed-wind instrument.	
	V-Bow String	E1–E6	Artificial synthesized strings sound.	
	V-String Bow	C1–C6	Simulation of a slow-attacked violin bowed with something other than a violin bow. Playing trills over a wide interval range creates a squeaky attack sound.	
	V-Cosmosis	C1–G5	Bowed strings. Initial Touch affects the attack sound.	
	V-E.Violin	C1–C6	Synth violin.	
	V-Bowe	C1–C5	Simulation of a hybrid bowed-saxophone sound.	
	V-Claviolin	G2–G5	A hybrid sound combining a violin with a wind instrument.	
	V-Air Bow	C2–G5	A bowed instrument sound with noise.	
	V-Waspy Horn	C1–G4	A hybrid sound grafting a brass wind instrument mouthpiece to a wind instrument. After Touch affects the muted condition. Lip-slide can be created with Horizontal Touch.	
	V-Mizu Horn	C1–C6	A hybrid sound combining a harmonica and trumpet.	
	V-Cosmo Mute	C1–C5	Simulation of a distorted brass wind instrument. After and Initial Touch affect the muted condition.	
	V-Fago	F1–C7	Simulated deep bassoon sound. Playing with soft touch produces breath noise with a high tone range.	
6	V-Jazz Guitar	E1–E5	Soft and warm jazz guitar sound.	
	V-Picked Guitar	E1–E5	Hard-attack guitar played with a pick.	
	V-Simple Bass	---	Voice ideal for bass phrases. After and Initial touch affect the resonance effect.	*
	V-Bass Attack	---	Voice ideal for bass phrases. Initial touch affects the muted condition.	*
	V-Thumb Bass	C1–E4	Bass sounds played with the thumb.	*
	V-Fretless	C1–C5	Fretless bass.	*
	V-Saw Lead	C1–C5	Multi-purpose lead sounds. After Touch affects the filter changes.	
	V-Edge Lead	C1–C4	Synth bass sound with a sharp attack portion. After Touch affects the filter changes.	
	V-Dist Lead	G1–C5	Distorted lead sounds. Setting the Touch Tone (After) higher and applying keyboard pressure raises the pitch.	
	V-Woody Lead	C2–G5	Lead sound with woody quality.	
	V-Muted Lead	C2–C5	Lead sound with wah-wah effect. After Touch heightens the wah-wah effect.	
	V-Talken Lead	C1–C5	Human voice-like lead sound. Setting the Touch Tone (After) higher and applying keyboard pressure allows creation of vocal humming.	
7	V-Mad Tube	---	Distorted synth lead with long release sound. High After Touch settings produce an overblowing effect.	*
	V-Mob	---	Distorted lead sound played with pick. Setting the Touch Tone (After) higher and applying keyboard pressure raises the pitch by an octave.	*
	V-Transylva	C1–C6	Softly distorted lead sounds.	*
	V-Destiny	---	Wah guitar with a sharp attack.	
	V-Igneous	C1–C4	Lead sound with full feedback effects. After Touch affects the degree of feedback.	
	V-Wurlli Lead	C1–C5	Simple synth lead with a sharp attack. High After Touch settings produce an overblowing effect.	
	V-Fifty Fifty	---	Analog synthesizer with simple square wave sound.	
	V-Ana Wave	---	Analog synthesizer. Initial touch and the length of holding down a key changes the filter effect.	
	V-Lyric Off	C1–C6	Wind synth sound created with square wave.	
	V-Ossyncro	C1–C6	Lead sound with dynamic pitch change.	*
	V-Wahman	C1–A3	Wah-wah lead voice with pitch change in the attack.	
	V-Q. Klav	C1–G5	Funky electric clav sound. Initial touch affects the timbre.	*
8	V-SFX 1	---	Simulated hand-tapping of the open end of a pipe.	
	V-SFX 2	---	Simulated scraping of a metallic plate. After Touch affects the degree of scraping.	
	V-SFX 3	---	Simulated hitting of a metallic plate with a wood block. Initial Touch changes the apparent hardness of the wood block.	
	V-SFX 4	---	Soft playing results in wind sounds. Applying keyboard pressure (After Touch) produces a distorted guitar sound.	
	V-SFX 5	---	Jet noise. Applying keyboard pressure produces lead sound.	
	V-SFX 6	---	Simulation of metallic plates colliding.	
	V-SFX 7	---	Initial touch affects the resonance effect.	
	V-SFX 8	---	Cry of a strange animal.	
	V-SFX 9	---	Simulation of a thick and long hose.	
	V-SFX 10	---	Trumpet with loop feedback sound.	
	V-SFX 11	---	Initial touch produces the sound of hitting metal, and After Touch increases the noise.	
	V-SFX 12	---	Initial touch produces the sounds of footsteps, and After Touch creates a windy sound.	
	V-SFX 13	---	The sound of a soprano saxophone played in the distance. Playing with softer touch produces only breath noise.	
	V-SFX 14	---	Lead sound with After Touch-produced pitch change.	
	V-SFX 15	---	Initial touch produces the sound of metal being scraped, and After Touch creates noise.	
	V-SFX 16	---	Cry/roar of an animal.	

Rhythm List

The numbers on the left side of each column in this list correspond to the page numbers shown on the Electone display.

*1 Cannot be selected for creating a Rhythm Pattern Program.

*2 Contains a Section with no Auto Bass part. Such a Section does not produce any bass sound even if A.B.C. is turned on.

*3 Contains a Section with no Drum part. When playing such a Section, make sure to turn Accompaniment on.

*4 Use the [EFFECT] setting in the [DRUM SETUP] tab of the RHYTHM PATTERN PROGRAM display to turn the preset effect for the Main Drum part on or off for each percussion instrument.

*5 Use the [EFFECT] setting in the [DRUM SETUP] tab of the RHYTHM PATTERN PROGRAM display to turn the preset effect for the Add Drum part on or off for each percussion instrument.

MARCH

1	Simple March	*2
	Simple 6/8 March	*2
	Marching Band 1	
	Marching Band 2	*2
	Marching Band 3	
	German March	
	6/8 March 1	
	6/8 March 2	
	6/8 Kids 1	
	6/8 Kids 2	*5
2	Orch March 1 +	*1
	Orch March 2	
	Anime Fantasy +	*1
	Galaxy Ship	
	SF March 1	
	SF March 2 +	*1
	SF March 3 +	*1
	Blockbuster 1	
	Blockbuster 2	*5
3	Broadway	*2
	Showtune +	*1
	Wild West	
	Desert Adventure	*4
	Orch Adventure	*4, *5
	Pop Classics +	*1, *2
	French 50s	
	Alpine March	
	6/8 Organ March	*3
4	Pub Piano	
	Sing-a-longPiano	
	Piano March	*2, *3
	Piano 6/8 March	*2, *3
	Piano Musical	*2, *3
	Baroque	*3
	Baroque Air	*3
	Baroque Concerto	*3
5	Strings Adagio	*3
	Strings Concerto	*3
	ClassicalSerenad	*3
	Orch Prelude	
	Choral Symphony	*3
	Romantic Ballet	*2, *3
	BrassBand Hymn +	*1, *3
	Pop Wind Orch	

WALTZ

1	Waltz 1	*2
	Waltz 2	*4, *5
	Simple Waltz	*3
	Orch Waltz 1	
	Orch Waltz 2	
	Orch Waltz 3 +	*1
	Vienna Waltz 1	
	Vienna Waltz 2	
	Vienna Waltz 3	
2	Gentle Waltz 1	
	Gentle Waltz 2	
	Classic Waltz	
	Slow Waltz 1	
	Slow Waltz 2	*5
	Slow Waltz 3	
	Slow Waltz 4 +	*1, *2
	Pop Waltz 1	
	Pop Waltz 2	
	Modern Waltz	
3	Country Waltz 1	
	Country Waltz 2	*5
	Country Waltz 3	*5
	Jazz Waltz 1	
	Jazz Waltz 2	
	Jazz Waltz 3	
	Jazz Waltz 4	
	Jazz Waltz Med	
	Jazz Waltz Fast	
4	Mariachi	
	Banda Vals	
	Snow Waltz	
	Vocal Waltz	
	Alpine Waltz	
	Alpen Land 3/4	
	Scand Hambo	
	Stubnmusi Waltz	*3, *4, *5
	Highland Waltz	
5	Musette	
	Swinging Musette	*5
	Italian Mazurka	
	Italian Waltz	
	French Waltz	
	Wonder Waltz	*5
	Schlager Waltz	*5
	Hawaiian Waltz	

6	Movie Soundtrack	
	Choir Soundtrack	
	Orch Bolero +	*1
	Romantic Waltz	*3
	Classical Menuet	*3
	Green Fantasia	*2, *3
	Guitar Serenade	*2, *3
	Piano Jazz Waltz	*2, *3

SWING & JAZZ

1	Simple Big Band	*2
	Simple ComboJazz	*2
	Simple Swing	
	Big Band 1	
	Big Band 2	
	Big Band 3	
	Big Band 4	
	Big Band 5	
	Big Band 6	
	Big Band 7	
2	Orch Big Band 1	
	Orch Big Band 2	
	Big Band Jazz	
	Big Band Crooner	
	Big Band Fast 1	
	Big Band Fast 2	*5
	Classic Big Band	
	30s Big Band	
	40s BandLdrSwing	*5
	Smokin' Big Band	*5
3	Modern Big Band	
	Mod BigBand Shfl	
	Big Band Ballad	*5
	Big Band Bop	
	Big Band Blues	*5
	Movie Mystery	
	Jungle Drum	
	JPN Fast JazzPop	
	Medium Jazz 1	
	Medium Jazz 2	
	Acoustic Jazz 1	
	Acoustic Jazz 2	

4	Fast Jazz	
	Combo Swing	
	Cool Combo	
	Light Swing	
	Jazz Quartet	*4, *5
	French Jazz	*5
	InstrumentalJazz	
	Manhattan Swing	
	Jazz Club 1	
	Jazz Club 2	*4, *5
5	Bebop	
	Five-Four	
	Trad Piano Jazz	
	Piano Trio	
	Cool Piano Jazz	*5
	Saloon Piano	*5
	Jazz Ballad 1	
	Jazz Ballad 2	
	Midnight Swing	
6	Slow Jazz 1	
	Slow Jazz 2	*5
	Moonlight 1	
	Moonlight 2	
	Dreamy Ballad	
	Winter Song 1	
	Winter Song 2	
	ChristmasShuffle	
	Christmas Bld +	*1
7	Movie Swing 1	
	Movie Swing 2	
	Guitar Swing	
	Afro Cuban 1	
	Afro Cuban 2	
	Afro Cuban 3	
	Foxtrot 1	
	Foxtrot 2	
	Slowfox 1	
	Slowfox 2	
8	Dixieland 1	
	Dixieland 2	
	Dixieland Jazz 1	
	Dixieland Jazz 2	*3
	Ragtime 1	
	Ragtime 2	
	Charleston	
	Electro Swing	*4, *5
	Quickstep 1	
	Quickstep 2	*5
9	Orchestra Swing	
	Jazz Singers	
	Tap Dance Swing	
	Organ Groove	
	Organ Swing	*5
	Drawbar Swing	
	JazzOrganGrinder	*3
	JazzOrganBallad	*5
	Piano Swing	*2, *3
	Piano JazzBallad	*2, *3
	Piano Stride	*2, *3

POPS

1	Simple 8Beat Pop	*2
	Simple 3/4 Pop	*2
	Simple Shfl Pop	*2
	8Beat Light 1	
	8Beat Light 2	
	8Beat Light 3	
	8Beat Light 4	
	Simple Shuffle 1	
	Simple Shuffle 2	
	Simple Shuffle 3	
2	16Beat 1	
	16Beat 2	
	16Beat 3	
	16Beat 4	
	British 16Beat 1	
	British 16Beat 2	
	Guitar Pop	
	Classic 16Beat	
	16Beat Shuffle 1	
	16Beat Shuffle 2	
3	Fusion Shuffle 1	
	Fusion Shuffle 2	
	Fusion Shuffle 3	
	Fusion Shuffle 4	*4
	Folk Rock 1	*2
	Folk Rock 2	
	SingerSongWriter	
	Easy Pop	
	US Folk Pop	*2, *4
	UK Folk Pop	*2
4	Jangle Folk Pop	*4
	Chart Guitar Pop	*2
	90s Guitar Pop	*4
	90s ChartBoyBand	*4, *5
	80s Boy Band	
	70s US Pop Duo	
	60s 8Beat	
	Surfin' 8Beat	
	Heart Beat	
	Finger Pickin'	
5	BritishSunnyPop	*4, *5
	Jazz Pop	
	Funky Pop	*5
	Eurovision Pop	
	British Pop	
	Pop Shuffle	
	90s Pop Shuffle	*5
	Kool Shuffle 1	
	Kool Shuffle 2	
	Unplugged 1	*2
6	Unplugged 2	
	Unplugged 3	
	UK Soul Pop	
	JPN Pop Shuffle	
	JPN Idol Hits	
	JPN 70s Anime +	*1
	JPN Anime Anthem	*4, *5
	Cute Pop	
	The 3rd Funk	
	Sunset DECA	
JPN Soundtrack 1		
	JPN Soundtrack 2	

7	JPN Groovy Pop	*4, *5
	JPN 20s SynthPop	*4, *5
	City Pop 1	
	City Pop 2	*4, *5
	00s Standard Pop	
8	00s Epic Pop	
	Throwback Pop	*5
	Sweet Pop	*2, *4, *5
	Diva Power Pop	*4, *5
	Brit Pop Diva	
	Boy Band Pop	*3, *4, *5
	Nashville Pop	*4, *5
	Nash Break Pop	*2, *4, *5
	EasySouthernPop	
	90s Brit Pop	
9	90s Mainstream	*4
	90s US Teen Pop	*4
	Cinematic Pop	*5
	Classical Pop	*2, *4
	Jolly Beat	
	Zouk Love	*4, *5
	Ranch Pop	
	Boxing Legend	
	US 70s TV Theme	
	70sTV Adventure+	*1
10	80s Pop Diva	*4, *5
	80s Funk Icon	*4, *5
	80s 8Beat	*4, *5
	80s SuaveBritPop	*4, *5
	80s All Time Pop	*4, *5
	Scand 80s Beat	
	80s Classic 6/8	
	80s Christmas	
	Christmas Schlgr	*5
11	70s 8Beat	
	70s Country Pop	
	70s ChartCountry	*2
	Country Brothers	
	CntryFolkUpbeat	
	MainstreamCowboy	*2, *4, *5
	Country Star	*4, *5
	Country 8Beat	*5
	70s CntryFolkPop	*5
	60s Country Pop	*4
12	Danish Shuffle	*4, *5
	60s Big Hit	
	60s US King Pop	*2
	60s Piano Pop	
	Sweet 60s Pop	
	60s Super Group	
	60s Crime Caper	*5
	60s VintageRumba	
	Schlager Reggae	*2, *4
	Asian Pops	
13	8Beat Adria	
	Scand Shuffle	
	Sing Along	
	Jersey Pop	
	60s Vintage Pop	
	Bubblegum Pop	
	Tijuana	
	60s Chart Swing	
	Easy Swing	
	Ukulele Swing	*4
	Ukulele Pop	*2

14	Euro Pop Organ	
	Euro Fox	
	Euro Pop	
	Euro Pop Mambo	*2, *5
	70s French Hit	*4
	Piano 8Beat	*2, *3

R&B

1	Simple Funk	*2
	Simple R&B Bld	*2
	Simple R&B Shfl	*2
	Soul 1	
	Soul 2	
	16Beat Soul 1	
	16Beat Soul 2	
	16Beat Soul 3	
	16Beat Soul 4	
2	Soul Brothers	
	Live Soul Band +	*1
	70s Chart Soul	
	Pop Legend	*4
	Power Soul 1	
	Power Soul 2	*4
	Smokin' Soul	*4
	Retro Soul	
	Schlager Soul	*4, *5
	Slow Soul Jam	*5
3	Soul Swing	
	Swing Soul	
	60s Soul	*4
	6/8 Soul	
	60s BlueEyedSoul	*5
	70s Soul Ballad	*5
	R&B Pop Diva	
	90s Pop Groove	*4
	60s Pop R&B	*5
4	Amazing Gospel 1	
	Amazing Gospel 2	
	Amazing Gospel 3	*2
	Gospel Brothers	
	Gospel Sisters	
	Hollywood Gospel	
	Gospel Party	
	New Gospel	
	Gospel Shuffle	
5	Gospel Funk 1	
	Gospel Funk 2	
	Funk Beat 1	
	Funk Beat 2	
	Jazz Funk	
	Kool Funk	
	Let's Funk	
	Funky Shuffle	
	Funk Pop	
	Jazz Groove	
	Super Groove	*4, *5
	80s Funky Soul	*4, *5
	80s Funk	*4, *5
	Motor City 1	
	Motor City 2	
	Detroit Pop 1	
	Detroit Pop 2	
	Blues Rock	
	Blueberry Blues	
	Cool Blues	
	Slow Blues	

7	The Blues	
	Guitar Blues	
	Acoustic Blues	*2, *4, *5
	Texas Blues	
	60s Rhythm&Blues	*5
	Blues Shuffle 1	*2
	Blues Shuffle 2	
	6/8 Blues	
8	Lovely Shuffle	
	Modern Shuffle	
	Cool R&B	
	70s Scat Legend	
	Soul Shuffle	
	Hello Shuffle	*4, *5
	Acoustic Shuffle	
9	PianoSwingBlues	
	60s LoveAffSwing	
	Swing Schlager	
	Modern R&B 1	
	Modern R&B 2	
	Soul R&B	
	New R&B	
	Worship Medium	
	Worship Fast	
	WorshipPowerBld	*2
	Piano Blues 1	*2, *3
	Piano Blues 2	*2, *3

LATIN

1	Simple BossaNova	*2
	Simple Samba	*2
	Simple Mambo	*2
	Simple Rumba	*2
	Bossa Nova 1	
	Bossa Nova 2	
	Bossa Nova 3	
	Bossa Nova 4	
	Pop Bossa 1	
	Pop Bossa 2	
2	Organ Bossa 1	
	Organ Bossa 2	*4
	Bossa Brazil	
	Lounge Bossa	
	Bossa Rio	*2
	Slow Bossa	*5
	Samba 1	
	Samba 2	
	Big Band Samba	
	Samba Fast	*4
3	Light Samba 1	
	Light Samba 2	
	Pop Samba 1	
	Pop Samba 2	
	80s BrazilianPop	*4
	Jazz Samba	
	Samba Rio	*2, *5
	Samba 60s	*4, *5
	JPN Golden Stage	*5
	JPN 00s TV Theme	*2, *4, *5

4	Mambo 1	
	Mambo 2	
	Big Band Mambo	
	Lounge Rumba	*5
	Rumba 1	
	Rumba 2	*5
	Pop Rumba 1	
	Pop Rumba 2	
	Fast Rumba	
	Rumba Flamenco	
5	Spanish Rumba	*5
	Rumba Island	
	Guitar Rumba 1	*3
	Guitar Rumba 2	
	Piano Rumba	*2, *3
	Piano Cha Cha	*2, *3
	Cha Cha Cha	
	Big Band Cha Cha	
	Cha-Cha	*5
	Cuban Cha-Cha	
6	Pop Cha Cha 1	
	Pop Cha Cha 2	
	Pop Cha Cha 3	*4, *5
	Salsa 1	
	Salsa 2	
	Salsa 3	
	SalsaGranCiclón	
	Montuno	
	Calypso	
	Guaguanco	
7	Danzon	
	Guajira	
	Cuban Bolero	
	Cuban Son	*4, *5
	Bomba 1	
	Bomba 2	
	Steel Band Soca	*4, *5
	Bachata	*4, *5
	Pop Latin	*2
	Latin Party Pop	
8	10s Cuban Pop	*2, *4, *5
	Latin Soul	*5
	Reggaeton Pop	*4
	Pop Merengue	*5
	Live Merengue	*4, *5
	Beguine 1	
	Beguine 2	
	Tango 1	
	Tango 2	
	Tango 3	
	Tango 4	
	Tango Orchestra	
	Tango Milonga	
	Italian Tango	

WORLD MUSIC

1	Bolero	
	Flamenco	
	Pop Flamenco 1	*2
	Pop Flamenco 2	*4, *5
	Pasodoble	
	Tarantella	
	Sirtaki	
	Scand Schottis	
	Hawaiian	
	Mexican Dance	*3
	Enka	
2	Polka 1	
	Polka 2	
	Banda Polka	*3
	Orchestral Polka	
	Zither Polka	
	Italian Polka	
	Scottish Polka	
	Oberkrainer Polka	
	Party Polka	
	Euro Polka	
	Polka Pop	
	Oldies Schlgr Polk	*4, *5
3	Irish Dance	
	Irish Hymn	*2
	Celtic Dance	
	Celtic Dance 3/4	
	Celtic Christmas	
	Scottish Reel	
	Scottish Jig	*5
	Alpen Land	*5
4	Reggae	
	Happy Reggae	
	Reef Reggae 1	
	Reef Reggae 2	
	Shuffle Reggae	
	Sunny Reggae	*4, *5
	Caribbean	
	Zouk	
5	Hully Gully	
	Hoedown 1	*3
	Hoedown 2	
	Texas Hoedown	*4
	Bluegrass 1	
	Bluegrass 2	
	Modern Bluegrass	
	Country Band	
	Country Shuffle	
	Country 2/4	
6	Pickin' Swing	
	Military 2 Step	*5
	Singalong Dance	*5
	Modern Dangdut	*5
7	Ethereal Voices	*2, *3
	CHN Pop Ballad 1	*2
	CHN Pop Ballad 2	
	Chinese Pop 6/8	
	Chinese Ballad 1	
	Chinese Ballad 2	
	Chinese Ballad 3	
	Chinese Ballad 4	
	CHN 16BeatSlow 1	
	CHN 16BeatSlow 2	*4, *5

8	Chinese Pop Rock	*5
	West China Pop	
	CHN Pop Country	*5
	CHN 16BeatRock 1	
	CHN 16BeatRock 2	
	CHN 16BeatRock 3	
	Chinese Funk	*5
	Chinese Opera R&B	
	Chinese Reggae	*5
9	Chinese Dance 1	
	Chinese Dance 2	
	Chinese Dance 3	
	Chinese Dance 4	
	CHN Pop Dance 1	
	CHN Pop Dance 2	
	Kung Fu 1	
	Kung Fu 2	*5
10	CHN Soundtrack	*4, *5
	Chinese Trad 1	
	Chinese Trad 2	*2
	Chinese Trad 3	*4, *5

BALLAD

1	Simple 8Beat Bld	*2
	Simple Rock Bld	*2
	8Beat Ballad	
	Acoustic 8Beat Bld	*2
	8Beat Modern	
	16Beat Ballad 1	
	16Beat Ballad 2	
	16Beat Ballad 3	
	16Beat Ballad 4	
2	6/8 Ballad	
	6/8 Slow Rock 1	
	6/8 Slow Rock 2	
	6/8 Slow Rock 3	
	6/8 Orchestral 1	
	6/8 Orchestral 2	
	Schlager 6/8	
	Moonlight 6/8	
	Euro Slow Rock	
	Acoustic Ballad	
3	Big Rock Ballad	
	90s Rock Ballad	
	90s HardRock Bld	
	Nashville Ballad	*2, *4, *5
	Orch Rock Bld 1 +	*1, *2
	Orch Rock Bld 2	
	Power Ballad	
	Easy Ballad	
	Romantic Ballad	
	Love Song	
4	Songwriter Ballad	*2, *4
	Unplugged Ballad	*5
	6/8 EuroPop Ballad	*2
	12/8 Pop Ballad	*2, *4, *5
	90s Pop Ballad	*5
	90s Ultimate Bld	*2, *4
	90s Brit Pop Bld	*4, *5
	90s Uplifting Bld	*2, *4
	90s US Chart Bld	
	Power Pop Ballad	*4
	Brit Pop Anthem	*2, *5
	Boy Band Ballad	

5	Epic Ballad +	*1
	Epic Diva Ballad	*2, *5
	Epic Drama Ballad	*2
	90s Epic Ballad +	*1, *2
	Epic Euro Ballad	*5
	Animation Ballad	
	Secret Service	
	70s Cool Ballad	
	80s Smooth Ballad	
	90s Cool Ballad	
6	Pop Evergreen	
	Vocal Pop Ballad +	*1, *2
	70s Pop Duo 1	
	70s Pop Duo 2	
	70s Glam Piano	
	70s Piano Pop Bld	*5
	70s Sofa Ballad	*4, *5
	Dramatic Ballad	*3
7	80s Love Song	
	80s Analog Ballad	*2, *4
	80s DX Ballad	*2
	80s 6/8 DX Ballad	*4, *5
	80s Electro Bld	*4
	80s Groove Ballad	*5
	Light Ballad	*2, *3, *5
8	Movie Ballad 1	
	Movie Ballad 2	
	80s Movie Ballad	
	Big Screen Classic	
	Icy Ballad	*2, *5
	Broadway Prod	*5
	6/8 Chart Ballad	*2, *5
	JPN Orch Ballad	*2, *4, *5
9	Chart Ballad	
	Analog Ballad	
	Pop Ballad	
	Modern Pop Ballad	*2
	New R&B Ballad	
	R&B Soul Ballad	
	R&B Slow Ballad	*2
	Gospel Ballad	
10	Smooth Latin Bld	*5
	Country Rock Bld	
	Easy Country	
	Easy Country Bld	*5
	Gentle Folk Bld	
	Slow&Easy 1	
	Slow&Easy 2	
	Organ Ballad 1	
	Organ Ballad 2	
	Chillout 1	*2
11	Chillout 2	*4, *5
	Chillout Cafe	*4, *5
	Chill Performer	*2, *3, *5
	JPN Romantic Bld	
	JPN Folk Pop Duo	
	JPN Dance Ballad	*2
	JPN R&B Ballad	
	JPN TV Soundtrack	*2
	On Broadway	*2, *3
	Coudy Bay	*3
	Night Walk	*2, *3, *4
	Play 4 Sofa	*2, *3, *5
	Angel Sun	*2, *3, *4

12	Guitar Ballad 1	
	Guitar Ballad 2	
	Guitar Ballad 3	
	Pop GuitarBallad	
	Piano Ballad	
	ClassicPianoBld	*3
	E.Piano Ballad	
	Pop Piano Ballad	*2
	Piano8BeatBallad	*2,*3
	Piano Slow Rock	*2,*3
	PianoOrchBallad	*3

ROCK

1	Simple Rock	*2
	Simple Shfl Rock	*2
	Hard Rock 1	
	Hard Rock 2	
	Hard Rock 3	
	Tears Rock 1	
	Tears Rock 2	
	British Rock	*2
	Soft Rock	
2	Power Rock 1	
	Power Rock 2	*5
	Stadium Rock +	*1
	ContemporaryRock	
	Standard Rock	
	Acoustic Rock	
	Brit Rock Pop	
	German Rock	
	Funk Pop Rock	
3	Canadian Rock	*5
	Nashville Rock	*4, *5
	High Road Rock	*2, *5
	Indie Rock	*4, *5
	Grunge Rock	*2, *4, *5
	Rockabilly	
	UK Soft Rock	*2, *5
	Diva Chart Punk	*2, *4, *5
	Rock Party King	*2, *4, *5
	Wrangler Rock	*4, *5
4	Glam Piano Rock	*4, *5
	00s Boy Band	
	10s 8Beat Rock	*2, *4, *5
	Chart Rock Shfl	
	Chart Piano Shfl	*5
	US Rock Shuffle	*5
	Beach Rock	
	Surf Rock	
	60s Rock 1	
	60s Rock 2	
5	60s Rock 3	
	60s Rock 4	
	70s Rock	
	70s Orch Rock	*4, *5
	70s Dutch Rock	
	70s US Cls Rock	
	70s US BluesRock	*4
	80s Power Rock	
	80s Synth Rock	
	80s Pop Rock	
	80s Guitar Pop	

6	80s Rock Anthem	*4, *5
	80s Majesty Rock	*4
	80s Classic Rock	*4, *5
	80s Soft Rock	*5
	80s Rock Beat	*4
	80s Piano Rock	*5
	80s PL BluesRock	*5
	80s Rock Ballad	*4, *5
	80s 6/8 SoftRock	*5
	90s Alt Rock	*4, *5
7	90sAltGrungeRock	*5
	90s German Rock	*4
	Rock Shuffle 1	
	Rock Shuffle 2	
	Rock Shuffle 3	
	70s Rock Shuffle	
	Rock&Roll 1	
	Rock&Roll 2	
	Rock&Roll 3	
	6/8 Rock	
8	60s Rock&Roll	
	60s US Rock&Roll	*5
	60sRock&RollBand	
	Rock&Roll Shfl	*3
	Jive	
	Swingin' Jive	*5
	Skiffle	
	60s Rock Rebel	*4
	60s Raga Rock	*2, *4
	60s PsychdlcRock	
9	60s Underground	*4
	50sFlorFillerPop	*4, *5
	Boogie Woogie 1	
	Boogie Woogie 2	
	Swingin' Boogie	
	Oldies Rock&Roll	
	Croco Twist	
	Southern Rock	
	Cowboy Rock	
	Scand Bugg	
10	Country Rock 1	
	Country Rock 2	
	Country Blues	
	New Country	*2
	CountryPopRock 1	
	CountryPopRock 2	*4, *5
	Country Strum	
	Irish Rock	
	Irish Pop Rock	*2, *5
	60s Rising Pop	*2
11	60s Folk Rock	
	Alpen Rock	
	Caribbean Rock 1	
	Caribbean Rock 2	
	Disco Fox Rock	*2
	Schlager Rocker	*4
	TeenRckPopSchlgr	*4
	JPN Light Rock 1	
	JPN Light Rock 2	
	JPN Pop Rock 1	
12	JPN Pop Rock 2	
	JPN Fresh Rock	*4, *5
	80s Dreamy Rock	
	JPN Band Rock 1	
	JPN Band Rock 2	
	JPN Lovely Rock	*4, *5

13	JPN Rock Duo +	*1
	JPN Idol Rock	
	JPN Kids Hero	
	Dragon Rock	
	JPN UpliftingRck	*4, *5
	JPN Upbeat Rock	*4, *5
	Miracle Rock	*2
	Pretty Cute	
	Happy Pop	
	JPN Fusion	*4, *5

DANCE

1	SimpleDancePop +	*1, *2
	Simple Disco	*2
	Ibiza 1	
	Ibiza 2	
	Ibiza 3	*3
	Trance Pop	
	Euro Trance 1	
	Euro Trance 2	*2
	6/8 Trance 1	
	6/8 Trance 2	
2	EDM Anthem	*4, *5
	Chart EDM	*4, *5
	Mega Hit	*4, *5
	Minimal Electro	*4, *5
	Big Room	*4
	Club Mix DJ	*4, *5
	Club Riddim	*4, *5
	Hard Trance	*4, *5
	Hard Club	*2, *4, *5
3	Sky Pop	*2, *4, *5
	Dancehall Pop	*2, *4, *5
	10s MidTempoPop	*2, *4, *5
	10s Electro Pop	*5
	10s Dream Dance	*4, *5
	US Electro Pop	*2, *4, *5
	Dance Beat	*4, *5
4	Club Dance 1	*2
	Club Dance 2	*2, 5
	Club Dance 3	
	Global DJ's	
	Dancefloor 1	*2
	Dancefloor 2	*4, *5
	Dream Dance	
	80s Dance	
	Techno Party	
	Club House	
5	Swing House	
	Funky House	
	90s House Dance	*4, *5
	90s Dream House	*4, *5
	Electro House	*2, *5
	TropHouseSchlgr	*2
	Dirty Pop	
	Mallorca Party	*2
	Party Arena	
	Apres Ski Hit	
	20sDanceSchlager	*2, *4, *5
	20s Fox Beat	*4, *5
	Volks Dance	*2, *5
	MallorcaShflPrty	*2, *4, *5

6	Disco Rock	*2
	Disco Fox	
	Mallorca Disco	*2
	Disco Palace	
	Disco Philly 1	
	Disco Philly 2	
	Disco Teens 1	*2
	Disco Teens 2	
	Disco Funk 1	
	Disco Funk 2	
	70s Soul Disco	
	Dance Pop	
7	70s Disco Funk	*4, *5
	70s Funky Disco	
	70s ClassicDisco	
	Disco Revival	*2
	Disco Drama 1	
	Disco Drama 2	
	US Disco	
	Disco Fever	
	70s Disco 1	
	70s Disco 2	
	70s Disco 3	
8	Disco Pop Jam	*2, *4, *5
	90s Disco	
	Retro Dance	
	Danger Dance	*4
	Swiss Schlager	*4, *5
	Disco Fox King	*4, *5
	Sing It Disco	*4
	80s Chintzy Pop	
	80s Retro Disco	*4, *5
	80s Teen Disco	*4
9	80s Exotic Pop	*4, *5
	80s Pop Queen	*2, *4, *5
	80s Dance Pop	*4
	80s Catchy Pop	*4, *5
	Synth Electro	*5
	Slow'n' Swingin'	*4, *5
	Breakout Electro	*2, *4, *5
	Trip Hop	*2
10	Chart Pop 1	
	Chart Pop 2	
	Chart Synth Pop	*4, *5
	Chart Dance Pop	
	Ground Beat	
	US Pop	
	UK Pop	
	Synth Pop	
	Synth Pop Duo +	*1
	10s Dance Pop	*2
	90s Dance Pop	*4, *5
	BritishDancePop	*5
11	Pop Beat 1	
	Pop Beat 2	
	Funky Dance	
	Dancehall	
	Garage 1	
	Garage 2	*5
	Electronica +	*1
	Latin DJ's	
	Club Latin	
	Latin Disco 1	
	Latin Disco 2	

12	Reggaeton	*2, *4, *5
	Reggaeton DJ	*4, *5
	Reggaeton Groove	*4, *5
	ReggaetonSlowJam	*2, *4, *5
	Reggaeton Schlgr	*5
	10s Spain Pop	*4, *5
	90s Euro Reggae	*2, *4, *5
	Turkish Eurobeat	*2
	Eastern Pop	
13	US Hip Hop 1	
	US Hip Hop 2	*2, *4
	Euro Hip Hop 1	
	Euro Hip Hop 2	
	Hip Hop Pop	
	Hip Hop Light	
	Hip Hop Groove	
	Classic Hip Hop	
	Modern Hip Hop	*5
	Nature Hip Hop	*2, *5
	Hip Hop	*4, *5
14	Pop R&B	
	Street Beatbox	*4, *5
	Rock Ya Beatbox	*4, *5
	JPN RetroTechPop	*4, *5
15	JPN Idol Pop 1 +	*1
	JPN Idol Pop 2	
	JPN Idol Pop 3	
	JPN 90s DancePop	*4, *5
	JPN Dance Pop 1	
	JPN Dance Pop 2	
	JPN Dance Pop 3	*4, *5
	JPN Dance Pop 4	*2, *4, *5
	JPN 80s AnimeHit	
	JPN 90s AnimeHit	*5
	Cute Techno	
16	Dance Police	
	20s Disco Pop	*4, *5
	20s Boys Dance	*4
	20s Girls Pop	*4, *5
	10s Sweet Dance	*4, *5
	10s Girl Crush	
	20s Light Dance	*5
	20s Girl Crush	*4, *5

3	Cowbell 2/4 +	*1, *2
	Cowbell 3/4 +	*1, *2
	Cowbell 4/4 +	*1, *2
	Cowbell 6/8 +	*1, *2
	Cowbell 9/8 +	*1, *2
	Cowbell 12/8 +	*1, *2
	Cowbell 5/4 +	*1, *2
	Cowbell 7/4 +	*1, *2
	Cowbell 8/4 +	*1, *2
4	Wood Block 2/4 +	*1, *2
	Wood Block 3/4 +	*1, *2
	Wood Block 4/4 +	*1, *2
	Wood Block 6/8 +	*1, *2
	Wood Block 9/8 +	*1, *2
	Wood Block 12/8 +	*1, *2
	Wood Block 5/4 +	*1, *2
	Wood Block 7/4 +	*1, *2
	Wood Block 8/4 +	*1, *2

METRONOME


1	Metronome 2/4 +	*1, *2
	Metronome 3/4 +	*1, *2
	Metronome 4/4 +	*1, *2
	Metronome 6/8 +	*1, *2
	Metronome 9/8 +	*1, *2
	Metronome 12/8 +	*1, *2
	Metronome 5/4 +	*1, *2
	Metronome 7/4 +	*1, *2
	Metronome 8/4 +	*1, *2
2	Click 2/4 +	*1, *2
	Click 3/4 +	*1, *2
	Click 4/4 +	*1, *2
	Click 6/8 +	*1, *2
	Click 9/8 +	*1, *2
	Click 12/8 +	*1, *2
	Click 5/4 +	*1, *2
	Click 7/4 +	*1, *2
	Click 8/4 +	*1, *2

Preset Keyboard Percussion Kit List

			EL Kit			Standard Kit 1		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Bass Drum Heavy		-	Kick	
			-	SD Brush Roll		Surdo Mute	Side Stick	
D1	D#1		-	Snare Drum Heavy		Surdo Open	Snare	
			Claves	SD Brush Shot 1		Hi Q	Hand Clap	
E1			-	SD Reverb 1		Whip Slap	Snare Tight	
			-	Snare Drum Light		Scratch H	Floor Tom L	
F1	F#1		Synth Tom 3	Tom 3		Scratch L	Hi-Hat Closed	
			Concert BD	Snare Drum Rim 1		Finger Snap	Floor Tom H	
G1	G#1		Synth Tom 2	Tom 2		Click Noise	Hi-Hat Pedal	
			Bass Drum Heavy	Hi-Hat Closed		Metronome Click	Low Tom	
A1	A#1		Synth Tom 1	Tom 1		Metronome Bell	Hi-Hat Open	
			Bass Drum Light	Hi-Hat Open		Seq Click L	Mid Tom L	
C2	C#2	-	Snare Drum Heavy	Ride Cymbal 1	-	Seq Click H	Mid Tom H	
		-	SD Brush Roll	Synth Tom 3	-	Brush Tap	Crash Cymbal 1	
D2	D#2	-	Snare Drum Heavy	Crash Cymbal 1	-	Brush Swirl	High Tom	
		-	SD Brush Shot 1	Synth Tom 2	-	Brush Slap	Ride Cymbal 1	
E2		-	SD Reverb 1	Orchestra Cymbal	-	Brush Tap Swirl	China Cymbal	
		-	Snare Drum Light	-	-	Snare Roll	Ride Cymbal Cup	
F2	F#2	-	Tom 3	Synth Tom 1	-	Castanet	Tambourine	
		-	Snare Drum Rim 1	-	-	Snare Soft	Splash Cymbal	
G2	G#2	-	Tom 2		-	Sticks		
		-	Hi-Hat Closed		-	Kick Soft		
A2	A#2	-	Tom 1		-	Open Rim Shot		
		-	Hi-Hat Open		-	Kick Tight		
C3	C#3	-	Ride Cymbal 1		Bongo H	Kick		
		-	Orch Snare Drum		Bongo L	Side Stick		
D3	D#3	-	Crash Cymbal 1		Conga H Mute	Snare		
		-	Snare Drum Roll		Conga H Open	Hand Clap		
E3		-	Orchestra Cymbal		Conga L	Snare Tight		
		-	Orch Cymbal Roll		Timbale H	Floor Tom L		
F3	F#3	-	Triangle Mute		Timbale L	Hi-Hat Closed		
		-	Tambourine		Agogo H	Floor Tom H		
G3	G#3	-	Triangle Open		Agogo L	Hi-Hat Pedal		
		-	Castanet		Cabasa	Low Tom		
A3	A#3	-	Cowbell 1		Maracas	Hi-Hat Open		
		-	Timbale 1 Low		Samba Whistle H	Mid Tom L		
C4	C#4	-	Timbale 1 High		Samba Whistle L	Mid Tom H		
		-	Wood Block Low		Guiro Short	Crash Cymbal 1		
D4	D#4	-	Conga Low		Guiro Long	High Tom		
		-	Wood Block High		Claves	Ride Cymbal 1		
E4		-	Conga High		Wood Block H	China Cymbal		
		-	Bongo Low		Wood Block L	Ride Cymbal Cup		
F4	F#4	-	Agogo Low		Cuica Mute	Tambourine		
		-	Bongo High		Cuica Open	Splash Cymbal		
G4	G#4	-	Agogo High		Triangle Mute	Cowbell		
		-	Cuica Low		Triangle Open	Crash Cymbal 2		
A4	A#4	-	Hand Claps		Shaker	Vibraslap		
		-	Cuica High		Jingle Bells	Ride Cymbal 2		
B4		-	Shaker		Wind Chimes	-		
		-	-		-	-		
C5	C#5	-	-		-	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Standard Kit 2			Hit Kit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick Short		-	Kick Tight H	
			Surdo Mute	Side Stick Light		Surdo Mute	Stick Ambient	
D1	D#1		Surdo Open	Snare Short		Surdo Open	Snare Ambient	
			Hi Q	Hand Clap		Hi Q	Hand Clap	
E1			Whip Slap	Snare Tight H		Whip Slap	Snare Tight 2	
			Scratch H	Floor Tom L		Scratch H	Hybrid Tom 1	
F1	F#1		Scratch L	Hi-Hat Closed		Scratch L	Hi-Hat Closed 2	
			Finger Snap	Floor Tom H		Finger Snap	Hybrid Tom 2	
G1	G#1		Click Noise	Hi-Hat Pedal		Click Noise	Hi-Hat Pedal 2	
			Metronome Click	Low Tom		Metronome Click	Hybrid Tom 3	
A1	A#1		Metronome Bell	Hi-Hat Open		Metronome Bell	Hi-Hat Open 2	
			Seq Click L	Mid Tom L		Seq Click L	Hybrid Tom 4	
C2	C#2	-	Seq Click H	Mid Tom H	-	Seq Click H	Hybrid Tom 5	
		-	Brush Tap	Crash Cymbal 1	-	Brush Tap	Crash Cymbal 1	
D2	D#2	-	Brush Swirl	High Tom	-	Brush Swirl	Hybrid Tom 6	
		-	Brush Slap	Ride Cymbal 1	-	Brush Slap	Ride Cymbal 1	
E2		-	Brush Tap Swirl	China Cymbal	-	Brush Tap Swirl	China Cymbal	
		-	Snare Roll	Ride Cymbal Cup	-	Snare Roll	Ride Cymbal Cup	
F2	F#2	-	Castanet	Tambourine	-	Castanet	Tambourine Light	
		-	Snare Soft 2	Splash Cymbal	-	Snare Electro	Splash Cymbal	
G2	G#2	-	Sticks		-	Sticks		
		-	Kick Soft		-	Kick Tight L		
A2	A#2	-	Open Rim Shot H		-	Snare Pitched		
		-	Kick Tight		-	Kick Wet		
C3	C#3	Bongo H	Kick Short		Bongo H	Kick Tight H		
		Bongo L	Side Stick Light		Bongo L	Stick Ambient		
D3	D#3	Conga H Mute	Snare Short		Conga H Mute	Snare Ambient		
		Conga H Open	Hand Clap		Conga H Open	Hand Clap		
E3		Conga L	Snare Tight H		Conga L	Snare Tight 2		
		Timbale H	Floor Tom L		Timbale H	Hybrid Tom 1		
F3	F#3	Timbale L	Hi-Hat Closed		Timbale L	Hi-Hat Closed 2		
		Agogo H	Floor Tom H		Agogo H	Hybrid Tom 2		
G3	G#3	Agogo L	Hi-Hat Pedal		Agogo L	Hi-Hat Pedal 2		
		Cabasa	Low Tom		Cabasa	Hybrid Tom 3		
A3	A#3	Maracas	Hi-Hat Open		Maracas	Hi-Hat Open 2		
		Samba Whistle H	Mid Tom L		Samba Whistle H	Hybrid Tom 4		
C4	C#4	Samba Whistle L	Mid Tom H		Samba Whistle L	Hybrid Tom 5		
		Guiro Short	Crash Cymbal 1		Guiro Short	Crash Cymbal 1		
D4	D#4	Guiro Long	High Tom		Guiro Long	Hybrid Tom 6		
		Claves	Ride Cymbal 1		Claves	Ride Cymbal 1		
E4		Wood Block H	China Cymbal		Wood Block H	China Cymbal		
		Wood Block L	Ride Cymbal Cup		Wood Block L	Ride Cymbal Cup		
F4	F#4	Cuica Mute	Tambourine		Cuica Mute	Tambourine Light		
		Cuica Open	Splash Cymbal		Cuica Open	Splash Cymbal		
G4	G#4	Triangle Mute	Cowbell		Triangle Mute	Cowbell		
		Triangle Open	Crash Cymbal 2		Triangle Open	Crash Cymbal 2		
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap		
		Jingle Bells	Ride Cymbal 2		Jingle Bells	Ride Cymbal 2		
C5	C#5	Wind Chimes	-		Bell Tree	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Room Kit			Rock Kit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick		-	Kick Gate	
			Surdo Mute	Side Stick		Surdo Mute	Side Stick	
D1	D#1		Surdo Open	Snare Snappy		Surdo Open	Snare Rock	
			Hi Q	Hand Clap		Hi Q	Hand Clap	
E1			Whip Slap	Snare Tight Snap		Whip Slap	Snare Rock Tight	
			Scratch H	Tom Room 1		Scratch H	Tom Rock 1	
F1	F#1		Scratch L	Hi-Hat Closed		Scratch L	Hi-Hat Closed	
			Finger Snap	Tom Room 2		Finger Snap	Tom Rock 2	
G1	G#1		Click Noise	Hi-Hat Pedal		Click Noise	Hi-Hat Pedal	
			Metronome Click	Tom Room 3		Metronome Click	Tom Rock 3	
A1	A#1		Metronome Bell	Hi-Hat Open		Metronome Bell	Hi-Hat Open	
			Seq Click L	Tom Room 4		Seq Click L	Tom Rock 4	
C2	C#2	-	Seq Click H	Tom Room 5	-	Seq Click H	Tom Rock 5	
		-	Brush Tap	Crash Cymbal 1	-	Brush Tap	Crash Cymbal 1	
D2	D#2	-	Brush Swirl	Tom Room 6	-	Brush Swirl	Tom Rock 6	
		-	Brush Slap	Ride Cymbal 1	-	Brush Slap	Ride Cymbal 1	
E2		-	Brush Tap Swirl	China Cymbal	-	Brush Tap Swirl	China Cymbal	
		-	Snare Roll	Ride Cymbal Cup	-	Snare Roll	Ride Cymbal Cup	
F2	F#2	-	Castanet	Tambourine	-	Castanet	Tambourine	
		-	Snare Soft	Splash Cymbal	-	Snare Noisy	Splash Cymbal	
G2	G#2	-	Sticks		-	Sticks		
		-	Kick Soft		-	Kick Soft		
A2	A#2	-	Open Rim Shot		-	Open Rim Shot		
		-	Kick Tight		-	Kick 2		
C3	C#3	Bongo H	Kick		Bongo H	Kick Gate		
		Bongo L	Side Stick		Bongo L	Side Stick		
D3	D#3	Conga H Mute	Snare Snappy		Conga H Mute	Snare Rock		
		Conga H Open	Hand Clap		Conga H Open	Hand Clap		
E3		Conga L	Snare Tight Snap		Conga L	Snare Rock Tight		
		Timbale H	Tom Room 1		Timbale H	Tom Rock 1		
F3	F#3	Timbale L	Hi-Hat Closed		Timbale L	Hi-Hat Closed		
		Agogo H	Tom Room 2		Agogo H	Tom Rock 2		
G3	G#3	Agogo L	Hi-Hat Pedal		Agogo L	Hi-Hat Pedal		
		Cabasa	Tom Room 3		Cabasa	Tom Rock 3		
A3	A#3	Maracas	Hi-Hat Open		Maracas	Hi-Hat Open		
		Samba Whistle H	Tom Room 4		Samba Whistle H	Tom Rock 4		
C4	C#4	Samba Whistle L	Tom Room 5		Samba Whistle L	Tom Rock 5		
		Guiro Short	Crash Cymbal 1		Guiro Short	Crash Cymbal 1		
D4	D#4	Guiro Long	Tom Room 6		Guiro Long	Tom Rock 6		
		Claves	Ride Cymbal 1		Claves	Ride Cymbal 1		
E4		Wood Block H	China Cymbal		Wood Block H	China Cymbal		
		Wood Block L	Ride Cymbal Cup		Wood Block L	Ride Cymbal Cup		
F4	F#4	Cuica Mute	Tambourine		Cuica Mute	Tambourine		
		Cuica Open	Splash Cymbal		Cuica Open	Splash Cymbal		
G4	G#4	Triangle Mute	Cowbell		Triangle Mute	Cowbell		
		Triangle Open	Crash Cymbal 2		Triangle Open	Crash Cymbal 2		
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap		
		Jingle Bells	Ride Cymbal 2		Jingle Bells	Ride Cymbal 2		
C5	C#5	Bell Tree	-		Bell Tree	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Electro Kit 1			Analog Kit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick Gate Heavy		-	Kick Analog	
			Surdo Mute	Side Stick		Surdo Mute	Side Stick Anlg	
D1	D#1		Surdo Open	Snare Noisy 2		Surdo Open	Snare Analog	
			Hi Q	Hand Clap		Hi Q	Hand Clap	
E1			Whip Slap	Snare Noisy 3		Whip Slap	Snare Analog 2	
			Scratch H	Tom Electro 1		Scratch H	Tom Analog 1	
F1	F#1		Scratch L	Hi-Hat Closed		Scratch L	Hat Close Analog	
			Finger Snap	Tom Electro 2		Finger Snap	Tom Analog 2	
G1	G#1		Click Noise	Hi-Hat Pedal		Click Noise	Hat Close Anlg 2	
			Metronome Click	Tom Electro 3		Metronome Click	Tom Analog 3	
A1	A#1		Metronome Bell	Hi-Hat Open		Metronome Bell	Hat Open Analog	
			Seq Click L	Tom Electro 4		Seq Click L	Tom Analog 4	
C2	C#2	-	Seq Click H	Tom Electro 5	-	Seq Click H	Tom Analog 5	
		-	Brush Tap	Crash Cymbal 1	-	Brush Tap	Crash Analog	
D2	D#2	-	Brush Swirl	Tom Electro 6	-	Brush Swirl	Tom Analog 6	
		-	Brush Slap	Ride Cymbal 1	-	Brush Slap	Ride Cymbal 1	
E2		-	Reverse Cymbal	China Cymbal	-	Reverse Cymbal	China Cymbal	
		-	Snare Roll	Ride Cymbal Cup	-	Snare Roll	Ride Cymbal Cup	
F2	F#2	-	Hi Q 2	Tambourine	-	Hi Q 2	Tambourine	
		-	Snare Snap Elec	Splash Cymbal	-	Snare Noisy 4	Splash Cymbal	
G2	G#2	-	Sticks		-	Sticks		
		-	Kick 3		-	Kick 3		
A2	A#2	-	Open Rim Shot		-	Open Rim Shot		
		-	Kick Gate		-	Kick Anlg Short		
C3	C#3	Bongo H	Kick Gate Heavy		Bongo H	Kick Analog		
		Bongo L	Side Stick		Bongo L	Side Stick Anlg		
D3	D#3	Conga H Mute	Snare Noisy 2		Conga Analog H	Snare Analog		
		Conga H Open	Hand Clap		Conga Analog M	Hand Clap		
E3		Conga L	Snare Noisy 3		Conga Analog L	Snare Analog 2		
		Timbale H	Tom Electro 1		Timbale H	Tom Analog 1		
F3	F#3	Timbale L	Hi-Hat Closed		Timbale L	Hat Close Analog		
		Agogo H	Tom Electro 2		Agogo H	Tom Analog 2		
G3	G#3	Agogo L	Hi-Hat Pedal		Agogo L	Hat Close Anlg 2		
		Cabasa	Tom Electro 3		Cabasa	Tom Analog 3		
A3	A#3	Maracas	Hi-Hat Open		Maracas 2	Hat Open Analog		
		Samba Whistle H	Tom Electro 4		Samba Whistle H	Tom Analog 4		
C4	C#4	Samba Whistle L	Tom Electro 5		Samba Whistle L	Tom Analog 5		
		Guiro Short	Crash Cymbal 1		Guiro Short	Crash Analog		
D4	D#4	Guiro Long	Tom Electro 6		Guiro Long	Tom Analog 6		
		Claves	Ride Cymbal 1		Claves 2	Ride Cymbal 1		
E4		Wood Block H	China Cymbal		Wood Block H	China Cymbal		
		Wood Block L	Ride Cymbal Cup		Wood Block L	Ride Cymbal Cup		
F4	F#4	Scratch H 2	Tambourine		Scratch H 2	Tambourine		
		Scratch L 2	Splash Cymbal		Scratch L 2	Splash Cymbal		
G4	G#4	Triangle Mute	Cowbell		Triangle Mute	Cowbell Analog		
		Triangle Open	Crash Cymbal 2		Triangle Open	Crash Cymbal 2		
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap		
		Jingle Bells	Ride Cymbal 2		Jingle Bells	Ride Cymbal 2		
C5	C#5	Bell Tree	-		Bell Tree	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).


		Dance Kit			Jazz Kit		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick Techno		-	Kick Jazz
			Kick Dance 1	Side Stick Anlg		Surdo Mute	Side Stick Light
D1	D#1		Kick Dance 2	Snare Clap		Surdo Open	Snare Jazz L
			Hi Q	Dance Clap		Hi Q	Hand Clap
E1			Whip Slap	Snare Dry		Whip Slap	Snare Jazz M
			Scratch Dance 1	Tom Dance 1		Scratch H	Floor Tom L
F1	F#1		Scratch Dance 2	Hi-Hat Closed 3		Scratch L	Hi-Hat Closed
			Finger Snap	Tom Dance 2		Finger Snap	Floor Tom H
G1	G#1		Click Noise	Hat Close Anlg 3		Click Noise	Hi-Hat Pedal
			Dance Perc 1	Tom Dance 3		Metronome Click	Low Tom
A1	A#1		Reverse Dance 1	Hi-Hat Open 3		Metronome Bell	Hi-Hat Open
			Dance Perc 2	Tom Dance 4		Seq Click L	Mid Tom L
C2	C#2	-	Hi Q Dance 1	Tom Dance 5	-	Seq Click H	Mid Tom H
		-	Snare Analog 3	Crash Analog	-	Brush Tap	Crash Cymbal 1
D2	D#2	-	Vinyl Noise	Tom Dance 6	-	Brush Swirl	High Tom
		-	Snare Analog 4	Ride Cymbal 1	-	Brush Slap	Ride Cymbal 1
E2		-	Reverse Cymbal	China Cymbal	-	Brush Tap Swirl	China Cymbal
		-	Reverse Dance 2	Ride Cymbal Cup	-	Snare Roll	Ride Cymbal Cup
F2	F#2	-	Hi Q 2	Tambourine Anlg	-	Castanet	Tambourine
		-	Snare Techno	Splash Cymbal	-	Snare Jazz H	Splash Cymbal
G2	G#2	-	Snare Dance 1		-	Sticks	
		-	Kick Techno Q		-	Kick Soft	
A2	A#2	-	Rim Gate		-	Open Rim Shot	
		-	Kick Techno L		-	Kick Tight	
C3	C#3	Bongo Analog H	Kick Techno		Bongo H	Kick Jazz	
		Bongo Analog L	Side Stick Anlg		Bongo L	Side Stick Light	
D3	D#3	Conga Analog H	Snare Clap		Conga H Mute	Snare Jazz L	
		Conga Analog M	Dance Clap		Conga H Open	Hand Clap	
E3		Conga Analog L	Snare Dry		Conga L	Snare Jazz M	
		Timbale H	Tom Dance 1		Timbale H	Floor Tom L	
F3	F#3	Timbale L	Hi-Hat Closed 3		Timbale L	Hi-Hat Closed	
		Agogo H	Tom Dance 2		Agogo H	Floor Tom H	
G3	G#3	Agogo L	Hat Close Anlg 3		Agogo L	Hi-Hat Pedal	
		Cabasa	Tom Dance 3		Cabasa	Low Tom	
A3	A#3	Maracas 2	Hi-Hat Open 3		Maracas	Hi-Hat Open	
		Samba Whistle H	Tom Dance 4		Samba Whistle H	Mid Tom L	
C4	C#4	Samba Whistle L	Tom Dance 5		Samba Whistle L	Mid Tom H	
		Guiro Short	Crash Analog		Guiro Short	Crash Cymbal 1	
D4	D#4	Guiro Long	Tom Dance 6		Guiro Long	High Tom	
		Claves 2	Ride Cymbal 1		Claves	Ride Cymbal 1	
E4		Dance Perc 3	China Cymbal		Wood Block H	China Cymbal	
		Dance Perc 4	Ride Cymbal Cup		Wood Block L	Ride Cymbal Cup	
F4	F#4	Dance Breath 1	Tambourine Anlg		Cuica Mute	Tambourine	
		Dance Breath 2	Splash Cymbal		Cuica Open	Splash Cymbal	
G4	G#4	Triangle Mute	Cowbell Dance		Triangle Mute	Cowbell	
		Triangle Open	Crash Cymbal 2		Triangle Open	Crash Cymbal 2	
A4	A#4	Shaker	Vibraslap Analog		Shaker	Vibraslap	
		Jingle Bells	Ride Analog		Jingle Bells	Ride Cymbal 2	
C5	C#5	Wind Chimes	-		Bell Tree	-	
		-	-		-	-	
D5	D#5	-	-		-	-	
		-	-		-	-	
E5		-	-		-	-	
		-	-		-	-	
F5	F#5	-	-		-	-	
		-	-		-	-	
G5	G#5	-	-		-	-	
		-	-		-	-	
A5	A#5	-	-		-	-	
		-	-		-	-	
B5		-	-		-	-	
		-	-		-	-	
C6		-	-		-	-	
		-	-		-	-	

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Brush Kit			Symphony Kit		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick Jazz		-	Gran Cassa Mute
			Surdo Mute	Side Stick Light		Surdo Mute	Side Stick
D1	D#1		Surdo Open	Brush Slap 3		Surdo Open	Band Snare
			Hi Q	Hand Clap		Hi Q	Hand Clap
E1			Whip Slap	Brush Tap 2		Whip Slap	Band Snare 2
			Scratch H	Tom Brush 1		Scratch H	Floor Tom L
F1	F#1		Scratch L	Hi-Hat Closed		Scratch L	Hi-Hat Closed
			Finger Snap	Tom Brush 2		Finger Snap	Floor Tom H
G1	G#1		Click Noise	Hi-Hat Pedal		Click Noise	Hi-Hat Pedal
			Metronome Click	Tom Brush 3		Metronome Click	Low Tom
A1	A#1		Metronome Bell	Hi-Hat Open		Metronome Bell	Hi-Hat Open
			Seq Click L	Tom Brush 4		Seq Click L	Mid Tom L
C2	C#2	-	Seq Click H	Tom Brush 5	-	Seq Click H	Mid Tom H
		-	Brush Tap	Crash Cymbal 1	-	Brush Tap	Hand Cymbal 1
D2	D#2	-	Brush Swirl	Tom Brush 6	-	Brush Swirl	High Tom
		-	Brush Slap	Ride Cymbal 1	-	Brush Slap	Hand Cymbal 1 S
E2		-	Brush Tap Swirl	China Cymbal	-	Brush Tap Swirl	China Cymbal
		-	Snare Roll	Ride Cymbal Cup	-	Snare Roll	Ride Cymbal Cup
F2	F#2	-	Castanet	Tambourine	-	Castanet	Tambourine
		-	Brush Slap 2	Splash Cymbal	-	Snare Soft	Splash Cymbal
G2	G#2	-	Sticks		-	Sticks	
		-	Kick Soft		-	Kick Soft 2	
A2	A#2	-	Open Rim Shot		-	Open Rim Shot	
		-	Kick Tight		-	Gran Cassa	
C3	C#3	Bongo H	Kick Jazz		Bongo H	Gran Cassa Mute	
		Bongo L	Side Stick Light		Bongo L	Side Stick	
D3	D#3	Conga H Mute	Brush Slap 3		Conga H Mute	Band Snare	
		Conga H Open	Hand Clap		Conga H Open	Hand Clap	
E3		Conga L	Brush Tap 2		Conga L	Band Snare 2	
		Timbale H	Tom Brush 1		Timbale H	Floor Tom L	
F3	F#3	Timbale L	Hi-Hat Closed		Timbale L	Hi-Hat Closed	
		Agogo H	Tom Brush 2		Agogo H	Floor Tom H	
G3	G#3	Agogo L	Hi-Hat Pedal		Agogo L	Hi-Hat Pedal	
		Cabasa	Tom Brush 3		Cabasa	Low Tom	
A3	A#3	Maracas	Hi-Hat Open		Maracas	Hi-Hat Open	
		Samba Whistle H	Tom Brush 4		Samba Whistle H	Mid Tom L	
C4	C#4	Samba Whistle L	Tom Brush 5		Samba Whistle L	Mid Tom H	
		Guiro Short	Crash Cymbal 1		Guiro Short	Hand Cymbal 1	
D4	D#4	Guiro Long	Tom Brush 6		Guiro Long	High Tom	
		Claves	Ride Cymbal 1		Claves	Hand Cymbal 1 S	
E4		Wood Block H	China Cymbal		Wood Block H	China Cymbal	
		Wood Block L	Ride Cymbal Cup		Wood Block L	Ride Cymbal Cup	
F4	F#4	Cuica Mute	Tambourine		Cuica Mute	Tambourine	
		Cuica Open	Splash Cymbal		Cuica Open	Splash Cymbal	
G4	G#4	Triangle Mute	Cowbell		Triangle Mute	Cowbell	
		Triangle Open	Crash Cymbal 2		Triangle Open	Hand Cymbal 2	
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap	
		Jingle Bells	Ride Cymbal 2		Jingle Bells	Hand Cymbal 2 S	
B4		Wind Chimes	-		Wind Chimes	-	
		-	-		-	-	
C5	C#5	-	-		-	-	
		-	-		-	-	
D5	D#5	-	-		-	-	
		-	-		-	-	
E5		-	-		-	-	
		-	-		-	-	
F5	F#5	-	-		-	-	
		-	-		-	-	
G5	G#5	-	-		-	-	
		-	-		-	-	
A5	A#5	-	-		-	-	
		-	-		-	-	
B5		-	-		-	-	
		-	-		-	-	
C6		-	-		-	-	
		-	-		-	-	

]: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Live! Studio Kit			Live!AcousticKit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick Studio		-	Kick Open Aco	
			Surdo Mute	Side Stick		Surdo Mute	Stick Acoustic	
D1	D#1		Surdo Open	Snare Studio M		Surdo Open	Snare Acoustic	
			Hi Q	Hand Clap		Hi Q	Hand Clap Power	
E1			Whip Slap	Snare Studio L		Whip Slap	Snare Rough Aco	
			Scratch H	Floor Tom L		Scratch H	Tom Acoustic 1	
F1	F#1		Scratch L	Hi-Hat Closed		Scratch L	Hi-Hat Close Aco	
			Finger Snap	Floor Tom H		Finger Snap	Tom Acoustic 2	
G1	G#1		Click Noise	Hi-Hat Pedal		Click Noise	Hi-Hat Pedal Aco	
			Metronome Click	Low Tom		Metronome Click	Tom Acoustic 3	
A1	A#1		Metronome Bell	Hi-Hat Open		Metronome Bell	Hi-Hat Open Aco	
			Seq Click L	Mid Tom L		Seq Click L	Tom Acoustic 4	
C2	C#2	-	Seq Click H	Mid Tom H	-	Seq Click H	Tom Acoustic 5	
		-	Brush Tap	Crash Cymbal 1	-	Brush Tap	CrashCymbalAco 1	
D2	D#2	-	Brush Swirl	High Tom	-	Brush Swirl	Tom Acoustic 6	
		-	Brush Slap	Ride Cymbal 1	-	Brush Slap	RideCymbal Aco 1	
E2		-	Brush Tap Swirl	China Cymbal	-	Brush Tap Swirl	China Cymbal Aco	
		-	Snare Roll	Ride Cymbal Cup	-	Snare Roll Aco	RideCymbalCupAco	
F2	F#2	-	Castanet	Tambourine	-	Castanet	Tambourine	
		-	Snare Studio 2	Splash Cymbal	-	Snare Soft Aco	SplashCymbal Aco	
G2	G#2	-	Sticks		-	Sticks		
		-	Kick Ambience H		-	Kick Soft Aco		
A2	A#2	-	Open Rim Shot		-	Rim Acoustic		
		-	Kick Ambience L		-	Kick Mute Aco		
C3	C#3	Bongo H	Kick Studio		Bongo H	Kick Open Aco		
		Bongo L	Side Stick		Bongo L	Stick Acoustic		
D3	D#3	Conga H Mute	Snare Studio M		Conga H Mute	Snare Acoustic		
		Conga H Open	Hand Clap		Conga H Open	Hand Clap Power		
E3		Conga L	Snare Studio L		Conga L	Snare Rough Aco		
		Timbale H	Floor Tom L		Timbale H	Tom Acoustic 1		
F3	F#3	Timbale L	Hi-Hat Closed		Timbale L	Hi-Hat Close Aco		
		Agogo H	Floor Tom H		Agogo H	Tom Acoustic 2		
G3	G#3	Agogo L	Hi-Hat Pedal		Agogo L	Hi-Hat Pedal Aco		
		Cabasa	Low Tom		Cabasa	Tom Acoustic 3		
A3	A#3	Maracas	Hi-Hat Open		Maracas	Hi-Hat Open Aco		
		Samba Whistle H	Mid Tom L		Samba Whistle H	Tom Acoustic 4		
C4	C#4	Samba Whistle L	Mid Tom H		Samba Whistle L	Tom Acoustic 5		
		Guiro Short	Crash Cymbal 1		Guiro Short	CrashCymbalAco 1		
D4	D#4	Guiro Long	High Tom		Guiro Long	Tom Acoustic 6		
		Claves	Ride Cymbal 1		Claves	RideCymbal Aco 1		
E4		Wood Block H	China Cymbal		Wood Block H	China Cymbal Aco		
		Wood Block L	Ride Cymbal Cup		Wood Block L	RideCymbalCupAco		
F4	F#4	Cuica Mute	Tambourine		Cuica Mute	Tambourine		
		Cuica Open	Splash Cymbal		Cuica Open	SplashCymbal Aco		
G4	G#4	Triangle Mute	Cowbell		Triangle Mute	Cowbell		
		Triangle Open	Crash Cymbal 2		Triangle Open	CrashCymbalAco 2		
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap		
		Jingle Bells	Ride Cymbal 2		Jingle Bells	RideCymbal Aco 2		
C5	C#5	Wind Chimes	-		Wind Chimes	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Live! PowerKit 1			Live! PowerKit 2		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick Power Mute		-	Kick Power Mute
			Surdo Mute	Side Stick Power		Surdo Mute	Side Stick Power
D1	D#1		Surdo Open	Snare Power 1		Surdo Open	Snare Power 2
			Hi Q	Hand Clap Power		Hi Q	Hand Clap Power
E1			Whip Slap	Snare Rough 1		Whip Slap	Snare Rough 2
			Scratch H	Tom Power 1		Scratch H	Tom Power 1
F1	F#1		Scratch L	Hi-HatClosePower		Scratch L	HH Closed PW Eg
			Finger Snap	Tom Power 2		Finger Snap	Tom Power 2
G1	G#1		Click Noise	Hi-HatPedalPower		Click Noise	Hi-HatPedalPower
			Metronome Click	Tom Power 3		Metronome Click	Tom Power 3
A1	A#1		Metronome Bell	Hi-HatOpen Power		Metronome Bell	Hi-HatOpen Power
			Seq Click L	Tom Power 4		Seq Click L	Tom Power 4
C2	C#2	-	Seq Click H	Tom Power 5	-	Seq Click H	Tom Power 5
		-	Brush Tap	CrashCymbalAco 1	-	Brush Tap	CrashCymbalAco 1
D2	D#2	-	Brush Swirl	Tom Power 6	-	Brush Swirl	Tom Power 6
		-	Brush Slap	RideCymbal Aco 1	-	Brush Slap	RideCymbal Aco 1
E2		-	Brush Tap Swirl	China Cymbal Aco	-	Brush Tap Swirl	China Cymbal Aco
		-	Snare Roll	RideCymbalCupAco	-	Snare Roll	RideCymbalCupAco
F2	F#2	-	Castanet	Tambourine	-	Castanet	Tambourine
		-	SnareSoftPower 1	SplashCymbal Aco	-	SnareSoftPower 2	SplashCymbal Aco
G2	G#2	-	Sticks		-	Sticks	
		-	Kick Ambient+		-	Kick Ambient+	
A2	A#2	-	Open Rim Power 1		-	Open Rim Power 2	
		-	Kick Power Open		-	Kick Power Open	
C3	C#3	Bongo H	Kick Power Mute		Bongo H	Kick Power Mute	
		Bongo L	Side Stick Power		Bongo L	Side Stick Power	
D3	D#3	Conga H Mute	Snare Power 1		Conga H Mute	Snare Power 2	
		Conga H Open	Hand Clap Power		Conga H Open	Hand Clap Power	
E3		Conga L	Snare Rough 1		Conga L	Snare Rough 2	
		Timbale H	Tom Power 1		Timbale H	Tom Power 1	
F3	F#3	Timbale L	Hi-HatClosePower		Timbale L	HH Closed PW Eg	
		Agogo H	Tom Power 2		Agogo H	Tom Power 2	
G3	G#3	Agogo L	Hi-HatPedalPower		Agogo L	Hi-HatPedalPower	
		Cabasa	Tom Power 3		Cabasa	Tom Power 3	
A3	A#3	Maracas	Hi-HatOpen Power		Maracas	Hi-HatOpen Power	
		Samba Whistle H	Tom Power 4		Samba Whistle H	Tom Power 4	
C4	C#4	Samba Whistle L	Tom Power 5		Samba Whistle L	Tom Power 5	
		Guiro Short	CrashCymbalAco 1		Guiro Short	CrashCymbalAco 1	
D4	D#4	Guiro Long	Tom Power 6		Guiro Long	Tom Power 6	
		Claves	RideCymbal Aco 1		Claves	RideCymbal Aco 1	
E4		Wood Block H	China Cymbal Aco		Wood Block H	China Cymbal Aco	
		Wood Block L	RideCymbalCupAco		Wood Block L	RideCymbalCupAco	
F4	F#4	Cuica Mute	Tambourine		Cuica Mute	Tambourine	
		Cuica Open	SplashCymbal Aco		Cuica Open	SplashCymbal Aco	
G4	G#4	Triangle Mute	Cowbell		Triangle Mute	Cowbell	
		Triangle Open	CrashCymbalAco 2		Triangle Open	CrashCymbalAco 2	
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap	
		Jingle Bells	RideCymbal Aco 2		Jingle Bells	RideCymbal Aco 2	
C5	C#5	Wind Chimes	-		Wind Chimes	-	
		-	-		-	-	
D5	D#5	-	-		-	-	
		-	-		-	-	
E5		-	-		-	-	
		-	-		-	-	
F5	F#5	-	-		-	-	
		-	-		-	-	
G5	G#5	-	-		-	-	
		-	-		-	-	
A5	A#5	-	-		-	-	
		-	-		-	-	
B5		-	-		-	-	
		-	-		-	-	
C6		-	-		-	-	
		-	-		-	-	

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Live! Rock Kit			Live! Real Drums		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick Rock		-	Kick Real 2	
			Surdo Mute	Stick Rock		Surdo Mute	Stick Real	
D1	D#1		Surdo Open	Snare Rock		Surdo Open	Snare Real 1	
			Hi Q	Hand Clap Power		Hi Q	Clap Power	
E1			Whip Slap	Snare Dry Rock		Whip Slap	Snare Real 2	
			Scratch H	Tom Rock 1		Scratch H	Tom Real 1	
F1	F#1		Scratch L	Hi-HatClosedRock		Scratch L	Hi-HatClosedReal	
			Finger Snap	Tom Rock 2		Finger Snap	Tom Real 2	
G1	G#1		Click Noise	Hi-HatPedal Rock		Click Noise	Hi-Hat PedalReal	
			Metronome Click	Tom Rock 3		Metronome Click	Tom Real 3	
A1	A#1		Metronome Bell	Hi-Hat Open Rock		Metronome Bell	Hi-Hat Open Real	
			Seq Click L	Tom Rock 4		Seq Click L	Tom Real 4	
C2	C#2	-	Seq Click H	Tom Rock 5	-	Seq Click H	Tom Real 5	
		-	Brush Tap	CrashCymbalAco 1	-	Brush Tap	CrashCymbalReal1	
D2	D#2	-	Brush Swirl	Tom Rock 6	-	Brush Tap Swirl	Tom Real 6	
		-	Brush Slap	RideCymbal Aco 1	-	Brush Slap	RideCymbalReal 1	
E2		-	Brush Tap Swirl	China Cymbal Aco	-	Brush Tap Swirl	ChinaCymbal Real	
		-	Snare Roll Rock	RideCymbalCupAco	-	Snare Roll Rock	RideCym Cup Real	
F2	F#2	-	Castanet	Tambourine	-	Castanet	Tambourine	
		-	Snare Soft Rock	SplashCymbal Aco	-	Snare Tight	SplashCymbalReal	
G2	G#2	-	Sticks		-	Sticks		
		-	Kick Soft Rock		-	Kick Genuine		
A2	A#2	-	Rim Rock		-	Rim Real		
		-	Kick Rock Heavy		-	Kick Real 1		
C3	C#3	Bongo H	Kick Rock		Bongo H	Kick Real 2		
		Bongo L	Stick Rock		Bongo L	Stick Real		
D3	D#3	Conga H Mute	Snare Rock		Conga H Mute	Snare Real 1		
		Conga H Open	Hand Clap Power		Conga H Open	Clap Power		
E3		Conga L	Snare Dry Rock		Conga L	Snare Real 2		
		Timbale H	Tom Rock 1		Timbale H	Tom Real 1		
F3	F#3	Timbale L	Hi-HatClosedRock		Timbale L	Hi-HatClosedReal		
		Agogo H	Tom Rock 2		Agogo H	Tom Real 2		
G3	G#3	Agogo L	Hi-HatPedal Rock		Agogo L	Hi-Hat PedalReal		
		Cabasa	Tom Rock 3		Cabasa	Tom Real 3		
A3	A#3	Maracas	Hi-Hat Open Rock		Maracas	Hi-Hat Open Real		
		Samba Whistle H	Tom Rock 4		Samba Whistle H	Tom Real 4		
C4	C#4	Samba Whistle L	Tom Rock 5		Samba Whistle L	Tom Real 5		
		Guiro Short	CrashCymbalAco 1		Guiro Short	CrashCymbalReal1		
D4	D#4	Guiro Long	Tom Rock 6		Guiro Long	Tom Real 6		
		Claves	RideCymbal Aco 1		Claves	RideCymbalReal 1		
E4		Wood Block H	China Cymbal Aco		Wood Block H	ChinaCymbal Real		
		Wood Block L	RideCymbalCupAco		Wood Block L	RideCym Cup Real		
F4	F#4	Cuica Mute	Tambourine		Cuica Mute	Tambourine		
		Cuica Open	SplashCymbal Aco		Cuica Open	SplashCymbalReal		
G4	G#4	Triangle Mute	Cowbell		Triangle Mute	Cowbell		
		Triangle Open	CrashCymbalAco 2		Triangle Open	CrashCymbalReal2		
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap		
		Jingle Bells	RideCymbal Aco 2		Jingle Bells	RideCymbalReal 2		
C5	C#5	Wind Chimes	-		Wind Chimes	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Live!RealBrushes			Analog T8 Kit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	KickJazzAmbience		-	Kick T8 1	
			Surdo Mute	Stick Brush		Surdo Mute	Snare T8 Rim	
D1	D#1		Surdo Open	Vintage Slap 4		Surdo Open	Snare T8 2	
			Hi Q	Clap Power		Hi Q	Clap T9	
E1			Whip Slap	Vintage Slap 5		Whip Slap	Snare T8 1	
			Scratch H	TomRealBrushes 1		Scratch H	Tom T8 1	
F1	F#1		Scratch L	Hi-Hat Closed RB		Scratch L	Hi-Hat Closed T8	
			Finger Snap	TomRealBrushes 2		Snare Hammer	Tom T8 2	
G1	G#1		Click Noise	Hi-Hat Pedal RB		Kick Zap Hard	Hi-Hat Pedal T8	
			Metronome Click	TomRealBrushes 3		Snare Garg L	Tom T8 3	
A1	A#1		Metronome Bell	Hi-Hat Open RB		Kick Tek Power	Hi-Hat Open T8	
			Vintage Tip	TomRealBrushes 4		Kick Slimy	Tom T8 4	
C2	C#2	-	Vintage Swirl 1	TomRealBrushes 5	-	Kick T8 4	Tom T8 6	
		-	Vintage Slap 1	CrashCymbal RB 1	-	Snare Analog CR	Crash Cymbal T8	
D2	D#2	-	Vintage Swirl 2	TomRealBrushes 6	-	Snare T8 7	Tom T8 7	
		-	Vintage Slap 2	Ride Cymbal RB	-	SnareClap Analog	Ride Cymbal T9	
E2		-	Vintage TapSwirl	China Cymbal RB	-	Snare T8 6	China Cymbal 2	
		-	VintageSlapSwirl	Ride Cup RB 1	-	Tom T8 5	RideCymbal Cup 2	
F2	F#2	-	Vintage Swirl 3	Tambourine	-	Snare T8 5	Tambourine RX5	
		-	Vintage Slap 3	Splash Cymbal RB	-	Kick T8 3	Splash Cymbal	
G2	G#2	-	Sticks		-	Snare T8 4		
		-	Kick Soft L		-	Kick T8 2		
A2	A#2	-	Open Rim Shot RB		-	Snare T8 3		
		-	Kick Soft H		-	T8 Kick Bass		
C3	C#3	Bongo H	KickJazzAmbience		Conga T8 5	Kick T8 1		
		Bongo L	Stick Brush		Conga T8 4	Snare T8 Rim		
D3	D#3	Conga H Mute	Vintage Slap 4		Conga T8 3	Snare T8 2		
		Conga H Open	Clap Power		Conga T8 2	Clap T9		
E3		Conga L	Vintage Slap 5		Conga T8 1	Snare T8 1		
		Timbale H	TomRealBrushes 1		Timbale H	Tom T8 1		
F3	F#3	Timbale L	Hi-Hat Closed RB		Timbale L	Hi-Hat Closed T8		
		Agogo H	TomRealBrushes 2		Glass H	Tom T8 2		
G3	G#3	Agogo L	Hi-Hat Pedal RB		Glass L	Hi-Hat Pedal T8		
		Cabasa	TomRealBrushes 3		Cabasa	Tom T8 3		
A3	A#3	Maracas	Hi-Hat Open RB		Maracas T8	Hi-Hat Open T8		
		Samba Whistle H	TomRealBrushes 4		Fx Gun 2	Tom T8 4		
C4	C#4	Samba Whistle L	TomRealBrushes 5		Fx Gun 1	Tom T8 6		
		Guiro Short	CrashCymbal RB 1		Analog Shaker H	Crash Cymbal T8		
D4	D#4	Guiro Long	TomRealBrushes 6		Analog Shaker L	Tom T8 7		
		Claves	Ride Cymbal RB		Claves T8	Ride Cymbal T9		
E4		Wood Block H	China Cymbal RB		Hi Q 1	China Cymbal 2		
		Wood Block L	Ride Cup RB 1		Hi Q 2	RideCymbal Cup 2		
F4	F#4	Cuica Mute	Tambourine		Scratch H 2	Tambourine RX5		
		Cuica Open	Splash Cymbal RB		Scratch L 2	Splash Cymbal		
G4	G#4	Triangle Mute	Cowbell		Triangle Mute	Cowbell T8		
		Triangle Open	CrashCymbal RB 2		Triangle Open	Crash Cymbal 4		
A4	A#4	Shaker	Vibraslap		Analog Shaker	Vibraslap		
		Jingle Bells	Ride Cup RB 2		Jingle Bells	Ride Cymbal 3		
C5	C#5	Wind Chimes	-		Wind Chimes	-		
		-	-		Snare Hip 1	-		
D5	D#5	-	-		Snare Hip 2	-		
		-	-		Snare Hip Gate	-		
E5		-	-		Snare Break 1	-		
		-	-		Kick Blip	-		
F5	F#5	-	-		Snare Fx 1	-		
		-	-		Kick Fx Hammer	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Analog T9 Kit			House Kit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick T9 3		-	Kick T9 5	
			Surdo Mute	Snare T9 Rim		W Kick	Snare T9 Rim	
D1	D#1		Surdo Open	Snare T9 1		Disco Fx	Snare T9 1	
			Hi Q	Clap T9		WhiteNoiseDown 1	Clap T9	
E1			Whip Slap	Snare T9 2		PinkNoise Down 1	Snare T9 2	
			Scratch H	Tom T9 1		WhiteNoiseDown 2	Tom T9 1	
F1	F#1		Scratch L	Hi-Hat Closed T9		PinkNoise Down 2	Hi-Hat Closed T8	
			Snare Drum&Bass1	Tom T9 2		White Noise Up 2	Tom T9 2	
G1	G#1		Kick Break 2	Hi-Hat Pedal T9		White Noise Up 1	Hi-Hat Pedal T9	
			Snare Distortion	Tom T9 3		Pink Noise Up	Tom T9 3	
A1	A#1		Kick Tek Power	Hi-Hat Open T9		WhiteNoiseUp Rel	Hi-Hat Open T9	
			KickDistortionRM	Tom T9 4		PinkNoise Up Rel	Tom T9 4	
C2	C#2	-	Kick T9 2	Tom T9 5	-	Kick T9 4	Tom T9 5	
		-	Snare Analog CR	Crash Cymbal T9	-	Snare T8 Rim	Crash Cymbal T9	
D2	D#2	-	Snare T9 5	Tom T9 6	-	Snare T8 5	Tom T9 6	
		-	Clap Analog Sm	Ride Cymbal T9	-	Hand Clap	Ride Cymbal T9	
E2		-	Snare T9 Gate 1	China Cymbal 2	-	Snare Garg L	Crash Cymbal 4	
		-	Snare Rock Roll	RideCymbal Cup 2	-	Snare Roll	RideCymbal Cup 2	
F2	F#2	-	Snare T9 3	Tambourine RX5	-	Snare T9 3	Tambourine Hit	
		-	Snare T9 4	Splash Cymbal 2	-	Snare T8 1	Splash Cymbal 2	
G2	G#2	-	Snare T9 Gate 2		-	Snare T9 5		
		-	Kick T9 4		-	Kick T9 1		
A2	A#2	-	Snare T9 6		-	Snare T9 Gate		
		-	Kick T9 1		-	Kick T9 2		
C3	C#3	Conga T8 5	Kick T9 3		Bongo H Open 1 F	Kick T9 5		
		Conga T8 4	Snare T9 Rim		Bongo L Open 3 F	Snare T9 Rim		
D3	D#3	Conga Tip	Snare T9 1		Conga H Tip	Snare T9 1		
		Conga Open Slap	Clap T9		Conga H SlapOpen	Clap T9		
E3		Conga Open	Snare T9 2		Conga H Open 2	Snare T9 2		
		Timbale H	Tom T9 1		Timbale H	Tom T9 1		
F3	F#3	Timbale L	Hi-Hat Closed T9		Timbale L	Hi-Hat Closed T8		
		Analog Click	Tom T9 2		Agogo H	Tom T9 2		
G3	G#3	Conga T8 1	Hi-Hat Pedal T9		Agogo L	Hi-Hat Pedal T9		
		Cabasa	Tom T9 3		Cabasa	Tom T9 3		
A3	A#3	Maracas Slur 2	Hi-Hat Open T9		Maracas Slur 2	Hi-Hat Open T9		
		Fx Gun 2	Tom T9 4		Vox Drum L	Tom T9 4		
C4	C#4	Fx Gun 1	Tom T9 5		Vox Drum H	Tom T9 5		
		Scratch H 3	Crash Cymbal T9		Guio Short	Crash Cymbal T9		
D4	D#4	Scratch Down	Tom T9 6		Guio Long	Tom T9 6		
		Hi Q 3	Ride Cymbal T9		Claves	Ride Cymbal T9		
E4		Hi Q 1	China Cymbal 2		Wood Block H	Crash Cymbal 4		
		Hi Q 2	RideCymbal Cup 2		Wood Block L	RideCymbal Cup 2		
F4	F#4	Scratch H 2	Tambourine RX5		Cuica H	Tambourine Hit		
		Scratch L 2	Splash Cymbal 2		Cuica L	Splash Cymbal 2		
G4	G#4	Triangle Mute	Cowbell 1		Triangle Mute	Cowbell 1		
		Triangle Open	Crash Cymbal 4		Triangle Open	Crash Cymbal 1		
A4	A#4	Analog Shaker	Cowbell T8		Analog Shaker	Cowbell T8		
		Jingle Bells	Ride Cymbal 3		Jingle Bells	Ride Cymbal 3		
C5	C#5	Wind Chimes	-		Wind Chimes	-		
		Snare Piccolo	-		Snare Break Roll	-		
D5	D#5	Snare T8 7	-		Noise Burst	-		
		SnareRckRollDist	-		Vox Bell	-		
E5		Snare Brush Mute	-		Snare R&B 1	-		
		Kick Blip Hard	-		Vox Alk	-		
F5	F#5	Snare Jungle 1	-		Udu High	-		
		Kick Sustain	-		Filter Kick	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			HipHop Kit			Drum Machine		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick Analog CR		-	Kick T9 4	
			Surdo Mute	SnareAnalogSmRim		Surdo Mute	Snare T9 Rim	
D1	D#1		Surdo Open	Snare HipHop 1		Surdo Open	Snare T9 1	
			Hi Q	Snare Clappy		Hi Q	Clap T9	
E1			Whip Slap	Snare HipHop 2		Whip Slap	Snare T9 4	
			Scratch H	Floor Tom L		Scratch H	Tom T9 1	
F1	F#1		Scratch L	Hi-HatClosed Hip		Scratch L	Hi-Hat Closed T9	
			Hi-HatClosedT8 2	Low Tom		Snare Drum&Bass1	Tom T9 2	
G1	G#1		Tom T8 3	Hi-Hat Pedal Hip		Kick Break 2	Hi-Hat Pedal T9	
			Hi-Hat Open T8 2	Mid Tom L		Snare Distortion	Tom T9 3	
A1	A#1		Tom T8 6	Hi-Hat Open Hip		Kick Tek Power	Hi-Hat Open T9	
			Crash T8	High Tom		KickDistortionRM	Tom T9 4	
C2	C#2	-	Triangle Mute	Ride Cymbal 3	-	BassDrumHardLong	Tom T9 5	
		-	Triangle Open	Crash Cymbal 3	-	BassDrumTekPower	Crash Cymbal T9	
D2	D#2	-	Wind Chimes	Shaker 2	-	Bass Drum Dist 5	Conga T8 1	
		-	TambourineLight2	ScratchBDForward	-	Bass Drum Dist 3	Ride Cymbal T9	
E2		-	TambourineLight1	ScratchBDRreverse	-	Bass Drum Dist 1	Conga T8 2	
		-	Kick HipHop 9	Kick HipHop 2	-	BD Drum&Bass	Analog Click	
F2	F#2	-	Hi-HatClosed Tek	SnareHipHopRim 2	-	Bass Drum Blip	Claves T8 1	
		-	Kick Gate	HipHop Clap 2	-	BassDrumAnalogSm	Maracas T8	
G2	G#2	-	Hi-HatOpen Lo-Fi		-	Kick T8 2		
		-	KickGranCasaOpen		-	Kick T8 3		
A2	A#2	-	Hi-HatReverseD&B		-	Kick T9 HD 3		
		-	Kick HipHop 1		-	Kick T9 2		
C3	C#3	Kick HipHop 3	Kick Analog CR		Snare T8 1	Kick T9 4		
		SnareHipHopRim 3	SnareAnalogSmRim		Snare T8 2	Snare T9 Rim		
D3	D#3	Snare HipHop 5	Snare HipHop 1		Snare T8 3	Snare T9 1		
		Electric Clap 1	Snare Clappy		Snare Analog CR	Clap T9		
E3		Handbell H	Snare HipHop 2		Snare Jungle 1	Snare T9 4		
		Kick HipHop 4	Floor Tom L		Snare Drum&Bass2	Tom T9 1		
F3	F#3	HipHop Clap 3	Hi-HatClosed Hip		Snare Hip 1	Hi-Hat Closed T9		
		HipHop Snap 2	Low Tom		Snare R&B 1	Tom T9 2		
G3	G#3	SnareHipHopRim 5	Hi-Hat Pedal Hip		Snare R&B 2	Hi-Hat Pedal T9		
		HipHop Flex 1	Mid Tom L		Snare Hip 1	Tom T9 3		
A3	A#3	HipHop Flex 2	Hi-Hat Open Hip		Snare Wood	Hi-Hat Open T9		
		Shaker 2	High Tom		Snare Timbre	Tom T9 4		
C4	C#4	Kick HipHop 5	Ride Cymbal 3		Hi-HatClosedT8 1	Tom T9 5		
		SnareHipHopRim 4	Crash Cymbal 3		Hi-Hat Open T8 1	Crash Cymbal T9		
D4	D#4	Snare HipHop 6	Shaker 2		Hi-HatClosedT8 2	Conga T8 1		
		Snare HipHop 11	ScratchBDForward		Hi-Hat Open T8 2	Ride Cymbal T9		
E4		Kick HipHop 10	ScratchBDRreverse		Hi-Hat Pedal Aco	Conga T8 2		
		Snare HipHop 7	Kick HipHop 2		Hi-HatClosed Aco	Analog Click		
F4	F#4	HipHop Clap 5	SnareHipHopRim 2		Hi-Hat Open Aco	Claves T8 1		
		Conga H Tip	HipHop Clap 2		Hi-HatClosedLoFi	Maracas T8		
G4	G#4	Conga H Heel	HipHop Snap 1		Hi-HatOpen Lo-Fi	TambourineAna CR		
		Conga H Open	Snare HipHop 3		Hi-HatClosed Syn	Analog Shaker		
A4	A#4	Conga L Open 1	Electric Clap 2		Hi-Hat Open Syn	Cowbell T8		
		Conga L Open 2	Kick Hip Deep		Analog Shaker 1	CowbellAnalog CR		
C5	C#5	Kick HipHop 8	-		Tambourine RX5 2	-		
		HipHop Clap 6	-		Tambourine 1 Hit	-		
D5	D#5	Snare T8 1	-		Electric Cowbell	-		
		Snare T8 1 H	-		Conga T8 3	-		
E5		HipHop Clap 7	-		ElectricTriangle	-		
		Tom T8 1	-		Claves T8 2	-		
F5	F#5	Hi-HatClosedT8 2	-		Analog Shaker 2	-		
		Tom T8 2	-		Electric Clap 1	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Break Kit			SFX Kit 1		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick Break 1		-	Cutting Noise 1
			Surdo Mute	Snare Hip Rim 1		-	Cutting Noise 2
D1	D#1		Surdo Open	Snare Break 3		-	-
			Hi Q	Snare Break 1		-	String Slap
E1			Whip Slap	Snare Break 2		-	-
			Scratch H	Tom Break 1		-	-
F1	F#1		Scratch L	HHClosedRockSoft		-	-
			Finger Snap	Tom Break 2		-	-
G1	G#1		Snare Break 8	Hi-Hat PedalRock		-	-
			Snare Break 9	Tom Break 3		-	-
A1	A#1		Hi-HatClosedBrk1	HH HalfOpen Rock		-	-
			Hi-HatClosedBrk2	Tom Break 4		-	-
C2	C#2	-	Kick Break Deep	Tom Break 5	-	-	-
		-	Snare Hip	Crash Cymbal 1	-	-	-
D2	D#2	-	Snare Lo-Fi	Tom Break 6	-	-	-
		-	Snare Clappy	Ride Cymbal 3	-	-	-
E2		-	Snare LdwH Mono	China Cymbal 2	-	-	Flute Key Click
		-	Snare Rock Roll	RideCymbal Cup 2	-	-	-
F2	F#2	-	Snare Gate 1	Tambourine 1 Hit	-	-	-
		-	Snare Mid	Splash Cymbal 2	-	-	-
G2	G#2	-	Snare Break Rim		-	-	
		-	Kick Break Heavy		-	-	
A2	A#2	-	Snare Hip Rim 4		-	-	
		-	Kick Break 2		-	-	
C3	C#3	Bongo H	Kick Break 1		-	-	Cutting Noise 1
		Bongo L	Snare Hip Rim 1		-	-	Cutting Noise 2
D3	D#3	Conga H Tip	Snare Break 3		-	-	
		Conga H OpenSlap	Snare Break 1		-	-	String Slap
E3		Conga H Open	Snare Break 2		-	-	
		Bongo 2 H	Tom Break 1		-	-	
F3	F#3	Bongo 2 L	HHClosedRockSoft		-	-	
		Conga Open	Tom Break 2		-	-	
G3	G#3	Agogo L	Hi-Hat PedalRock		-	-	
		Cabasa	Tom Break 3		Shower	-	
A3	A#3	Maracas Slur	HH HalfOpen Rock		Thunder	-	
		Timbale H	Tom Break 4		Wind	-	
C4	C#4	Timbale L	Tom Break 5		Stream	-	
		Scratch H 3	Crash Cymbal 1		Bubble	-	
D4	D#4	Scratch Down	Tom Break 6		Feed	-	
		Claves		Tom Break 6	-	-	
E4		Wood Block H	Ride Cymbal 3		-	-	
		Wood Block L	China Cymbal 2		-	-	Flute Key Click
F4	F#4	Scratch H 2	RideCymbal Cup 2		-	-	
		Scratch L 2	Tambourine 1 Hit		-	-	
G4	G#4	Scratch L 2	Splash Cymbal 2		-	-	
		Triangle Mute	Cowbell 1		-	-	
A4	A#4	Triangle Open			-	-	
		Kick Break 3	Crash Cymbal 2		-	-	
B4		Kick Break 4	Cowbell RX11		-	-	
		Kick Break 5	Ride Cymbal 2		-	-	
C5	C#5	Kick Break 6			Dog	-	
		Kick Break 7	-		Horse	-	
D5	D#5	Kick Break 7	-		Bird Tweet	-	
		Hi-HatClosedBrk3	-		-	-	
E5		Snare Break 4	-		-	-	
		Snare Break 5	-		-	-	
F5	F#5	Snare Break 6	-		-	-	
		Snare Break 7	-		Ghost	-	
G5	G#5	-	-		Maou	-	
		-	-		-	-	
A5	A#5	-	-		-	-	
		-	-		-	-	
B5		-	-		-	-	
		-	-		-	-	
C6		-	-		-	-	
		-	-		-	-	

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

SFX Kit 2			Live! SFX Kit 1				
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)
C1	C#1		-	Phone Call		-	Cutting Noise 1
			-	Door Squeak		-	Cutting Noise 2
D1	D#1		-	Door Slam		-	-
			-	Scratch Cut		-	String Slap
E1			-	Scratch Split		-	-
			-	Wind Chimes		-	-
F1	F#1		-	Telephone Ring		-	-
			-	-		-	-
G1	G#1		-	-		-	-
			-	-		-	-
A1	A#1		-	-		-	-
			-	-		-	-
B1			-	-		-	-
			-	-		-	-
C2	C#2	-	-	-	-	-	-
		-	-	-	-	-	-
D2	D#2	-	-	-	-	-	-
		-	-	-	-	-	-
E2		-	-	CarEngn Ignition	-	-	Flute Key Click
		-	-	Car Tires Squeal	-	-	-
F2	F#2	-	-	Car Passing	-	-	-
		-	-	Car Crash	-	-	-
G2	G#2	-	-		-	-	
		-	-		-	-	
A2	A#2	-	-		-	-	
		-	-		-	-	
B2		-	-		-	-	
C3	C#3	Burst	Phone Call		-	Cutting Noise 1	
		Roller Coaster	Door Squeak		-	Cutting Noise 2	
D3	D#3	Submarine	Door Slam		-		
		-	Scratch Cut		-	String Slap	
E3		-	Scratch Split		-		
		-	Wind Chimes		-		
F3	F#3	-	Telephone Ring		-		
		-			-		
G3	G#3	Laugh			Shower 2	-	
		Scream	-		Thunder 2	-	
A3	A#3	Punch	-		Wind 2	-	
		Heart Beat	-		Stream 2	-	
C4	C#4	Foot Steps	-		Bubble 2	-	
		-	-		Feed	-	
D4	D#4	-	-		-	-	
		-	-		-	-	
E4		-	CarEngn Ignition		-	Flute Key Click	
		-	Car Tires Squeal		-		
F4	F#4	-	Car Passing		-		
		-	Car Crash		-		
G4	G#4	-	Siren		-	-	
		-	Train		-	-	
A4	A#4	-	Jet Plane		-	-	
		-	Starship		-	-	
C5	C#5	Machine Gun	-		Dog	-	
		Laser Gun	-		Horse	-	
D5	D#5	Explosion	-		Bird Tweet	-	
		Firework	-		-	-	
E5		-	-		-	-	
		-	-		-	-	
F5	F#5	-	-		Ghost	-	
		-	-		Maou	-	
G5	G#5	-	-		-	-	
		-	-		-	-	
A5	A#5	-	-		-	-	
		-	-		-	-	
B5		-	-		-	-	
		-	-		-	-	
C6		-	-		-	-	

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

Live! SFX Kit 2			Noise Kit				
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)
C1	C#1		-	Phone Call 2		-	White Noise
			-	Door Squeak 2		-	Pink Noise
D1	D#1		-	Door Slam 2		-	WhiteNoiseDown 1
			-	Scratch Cut		-	PinkNoise Down 1
E1			-	Scratch Split		-	WhiteNoiseDown 2
			-	Wind Chimes		-	PinkNoise Down 2
F1	F#1		-	Telephone Ring 2		-	White Noise Up 2
			-	-		-	White Noise Up 1
G1	G#1		-	-		-	Pink Noise Up
			-	-		-	WhiteNoiseUp Rel
A1	A#1		-	-		-	PinkNoise Up Rel
			-	-		-	WhiteNoiseUp LFO
B1			-	-		-	PinkNoise Up LFO
			-	-		-	-
C2	C#2		-	-		-	-
			-	-		-	-
D2	D#2		-	-		-	-
			-	-		-	-
E2			-	CarEngn Ignition		-	-
			-	Car Tires Squeal		-	-
F2	F#2		-	Car Passing		-	-
			-	Car Crash		-	-
G2	G#2		-			-	
			-			-	
A2	A#2		-			-	
			-			-	
B2			-			-	
			-			-	
C3	C#3	Burst	Phone Call 2		-	White Noise	
		Roller Coaster	Door Squeak 2		-	Pink Noise	
D3	D#3	Submarine	Door Slam 2		-	WhiteNoiseDown 1	
			Scratch Cut		-	PinkNoise Down 1	
E3			Scratch Split		-	WhiteNoiseDown 2	
			Wind Chimes		-	PinkNoise Down 2	
F3	F#3		Telephone Ring 2		-	White Noise Up 2	
			-		-	White Noise Up 1	
G3	G#3	Laugh	-		-	Pink Noise Up	
		Scream 2	-		-	WhiteNoiseUp Rel	
A3	A#3	Punch 2	-		-	PinkNoise Up Rel	
		Heart Beat	-		-	WhiteNoiseUp LFO	
C4	C#4	Foot Steps 2	-		-	PinkNoise Up LFO	
			-		-	-	
D4	D#4		-		-	-	
			-		-	-	
E4			-		-	-	
			CarEngn Ignition		-	-	
F4	F#4		Car Tires Squeal		-	-	
			Car Passing		-	-	
G4	G#4		Car Crash		-	-	
			Siren 2		-	-	
A4	A#4		Train 2		-	-	
			Jet Plane 2		-	-	
B4			Starship		-	-	
			-		-	-	
C5	C#5	Machine Gun 2	-		-	-	
		Laser Gun	-		-	-	
D5	D#5	Explosion 2	-		-	-	
		Firework	-		-	-	
E5			-		-	-	
			-		-	-	
F5	F#5		-		-	-	
			-		-	-	
G5	G#5		-		-	-	
			-		-	-	
A5	A#5		-		-	-	
			-		-	-	
B5			-		-	-	
			-		-	-	
C6			-		-	-	
			-		-	-	

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			VocalEffects Kit			GospelAdLibs		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Male Ha 1		-	-	
			-	Female Ha 1		-	-	
D1	D#1		-	Male Ha 2		-	-	
			-	Male Ha 3		-	-	
E1			-	Male Bh 1		-	-	
			-	Female Bh 1		-	-	
F1	F#1		-	Male Kh 1		-	-	
			-	Female Kh 1		-	-	
G1	G#1		-	Male Ph 1		-	-	
			-	Female Ph 1		-	-	
A1	A#1		-	Male Th 1		-	-	
			-	Female Th 1		-	-	
C2	C#2	-	-	Male Bh 2	-	-	C'mon	
		-	-	Female Bh 2	-	-	Hoo!	
D2	D#2	-	-	Male Kh 2	-	-	Aha!	
		-	-	Female Kh 2	-	-	Oh Yeah	
E2		-	-	Male Ph 2	-	-	Yayayayah	
		-	-	Female Ph 2	-	-	Put Your Hands...	
F2	F#2	-	-	Male Th 2	-	-	C'mon Now	
		-	-	Female Th 2	-	-	Heeey	
G2	G#2	-	-		-	-		
		-	-		-	-		
A2	A#2	-	-		-	-		
		-	-		-	-		
B2		-	-		-	-		
C3	C#3	Male Bh 3	Male Ha 1		Uhh Yeah	-		
		Female Bh 3	Female Ha 1		Aaoh	-		
D3	D#3	Male Kh 3	Male Ha 2		Come On!	-		
		Female Kh 3	Male Ha 3		Yeah!	-		
E3		Male Ph 3	Male Bh 1		Alright Now!	-		
		Female Ph 3	Female Bh 1		One	-		
F3	F#3	Male Th 3	Male Kh 1		Two	-		
		Female Th 3	Female Kh 1		Three	-		
G3	G#3	Male Bh 4	Male Ph 1		Four	-		
		Female Bh 4	Female Ph 1		One!	-		
A3	A#3	Male Kh 4	Male Th 1		Two!	-		
		Female Kh 4	Female Th 1		Three!	-		
C4	C#4	Male Ph 4	Male Bh 2		Four!	C'mon		
		Female Ph 4	Female Bh 2		Five!	Hoo!		
D4	D#4	Male Th 4	Male Kh 2		Six!	Aha!		
		Female Th 4	Female Kh 2		Seven!	Oh Yeah		
E4		-	Male Ph 2		Eight!	Yayayayah		
		-	Female Ph 2		Clap!	Put Your Hands...		
F4	F#4	-	Male Th 2		Gospel Clap 1	C'mon Now		
		-	Female Th 2		Gospel Clap 2	Heeey		
G4	G#4	-	Male Ha 4		-	Everybody Now		
		-	Female Ha 2		-	ClapYourHands...		
A4	A#4	-	Male Ha 5		-	WithAllYourSoul		
		-	Male Ha 6		-	Stand Up On...		
C5	C#5	-	-		-	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Wonderland Kit			Pop Latin Kit 1		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		Laser Beam	Thunder		-	Bongo H Open 1 f
			Laser Shot	Hoofbeats		Cajon Low	Bongo H Open 3 f
D1	D#1		Water Phone	Bass Drum		Cajon Slap	Bongo H Rim
			Bubble	Footsteps		Cajon Tip	Bongo H Tip
E1			Puddle	Snare		Claves High	Bongo H Heel
			Thunder	Snare Roll		Claves Low	Bongo H Slap
F1	F#1		Shower	Footsteps		Hand Clap	Bongo L Open 1 f
			Beach	Lion		-	Bongo L Open 3 f
G1	G#1		Stream	Footsteps		Finger Snap	Bongo L Rim
			Footsteps	Cow		Castanet	Bongo L Tip
A1	A#1		Door Squeak	Footsteps		Conga H Tip	Bongo L Heel
			Door Slam	Door Slam		Conga H Heel	Bongo L Slap
C2	C#2	Bass Drum	Bass Drum	Big Clock	-	Conga H Open	Timbale L
		Gran Cassa	Gran Cassa	Footsteps	-	Conga H Mute	-
D2	D#2	Tom 2	Tom 2	Starship	-	Conga H SlapOpen	-
		Tom 1	Tom 1	Footsteps	-	Conga H Slap	-
E2		Snare	Snare	Train	-	Conga H SlapMute	-
		Snare Roll	Snare Roll	Car Crash	-	Conga L Tip	Paila L
F2	F#2	Hi-Hat Closed	Hi-Hat Closed	Footsteps	-	Conga L Heel	Timbale H
		Cymbal	Cymbal	Puddle	-	Conga L Open	-
G2	G#2	Hi-Hat Open	Hi-Hat Open		-	Conga L Mute	
		Tambourine	Tambourine		-	Conga L SlapOpen	
A2	A#2	Finger Snap	Finger Snap		-	Conga L Slap	
		Castanet	Castanet		-	Conga L Slide	
C3	C#3	Triangle Mute	Triangle Mute		Cowbell Top	Bongo H Open 1 f	
		Wood Block L	Wood Block L		Cowbell 1	Bongo H Open 3 f	
D3	D#3	Triangle Open	Triangle Open		Cowbell 2	Bongo H Rim	
		Wood Block H	Wood Block H		Cowbell 3	Bongo H Tip	
E3		Hand Clap	Hand Clap		Guiro Short	Bongo H Heel	
		Jingle Bells	Jingle Bells		Guiro Long	Bongo H Slap	
F3	F#3	Bell Tree	Bell Tree		MetalGuiro Short	Bongo L Open 1 f	
		Alarm Bell	Alarm Bell		MetalGuiro Long	Bongo L Open 3 f	
G3	G#3	Train	Train		Tambourine	Bongo L Rim	
		Horn 1	Horn 1		Tamborim Open	Bongo L Tip	
A3	A#3	Horn 2	Horn 2		Tamborim Mute	Bongo L Heel	
		Siren	Siren		Tamborim Tip	Bongo L Slap	
C4	C#4	CarEngn Ignition	CarEngn Ignition		Maracas	Timbale L	
		Car Crash	Car Crash		Shaker	-	
D4	D#4	Helicopter	Helicopter		Cabasa	-	
		Starship	Starship		Cuica Mute	-	
E4		Sheep	Sheep		Cuica Open	-	
		Goat	Goat		Cowbell High 1	Paila L	
F4	F#4	Cow	Cow		Cowbell High 2	Timbale H	
		Whinny	Whinny		Shekere	-	
G4	G#4	Hoofbeats	Hoofbeats		Shekere Tone	-	
		Lion	Lion		Triangle Mute	-	
A4	A#4	Dog	Dog		Triangle Open	-	
		Cat	Cat		-	Paila H	
C5	C#5	Hen	Hen		Wind Chimes	-	
		Owl	-		-	-	
D5	D#5	Insects	-		-	-	
		Frog	-		-	-	
E5		Tweet 1	-		-	-	
		Tweet 2	-		-	-	
F5	F#5	Cuckoo Clock	-		-	-	
		Big Clock	-		-	-	
G5	G#5	Bell	-		-	-	
		Telephone	-		-	-	
A5	A#5	Camera	-		-	-	
		Gnaw	-		-	-	
B5		Applause	-		-	-	

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Arabic Kit			Turkish Kit		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1			-	Kick Soft		-	Tef Dum Mute
	C#1		-	Side Stick		Asma Davul L	Tef Cymbal
D1			-	Snare Soft		Asma Davul R	Tef Cymbal Mute
	D#1		-	Arabic Hand Clap		Asma Davul Side	Tef Tremolo
E1			-	Snare Drum		Asma Davul Both	Tef Shake 1
			-	Floor Tom L		KoltukDavul Flam	Tef Shake 2
F1			-	Hi-Hat Closed		KoltukDavul Teke	Tef Tek Flam
	F#1		-	Floor Tom H		Koltuk Davul Tek	Tef Full Open
G1			-	Hi-Hat Pedal		Koltuk Davul Dum	Tef Teke OpShort
	G#1		-	Low Tom		Bendir Teke Flam	Tef Tek Op Short
A1			-	Hi-Hat Open		Bendir Teke Dead	Tef Tek Open
	A#1		-	Mid Tom L		Bendir Tek Dead	Tef Dum Open
B1			-	Mid Tom H	-	Bendir Teke	Hollo FingerDead
	C#2		-	Crash Cymbal 1	-	Bendir Tek	Hollo Slap
D2			-	High Tom	-	Bendir Slap	Hollo Dum
	D#2		-	Ride Cymbal 1	-	Bendir Dum	Kasik
E2			-	Crash Cymbal 2	-	Zil Right Close	Kasik Flam
			-	Bongo H	-	Zil Right Open	BDarbuka TekDead
F2			-	Tambourine	-	Zil Left Close	BDarbuka TekFlam
	F#2		-	Duhulla Tak	-	Zil Left Open	BassDarbuka Teke
G2			-		-	Tef Teke Flam	
	G#2		-	Conga L	-	Tef Tek Mute	
A2			-	Zagrouda H	-	Tef Teke Damped	
	A#2		-	Zagrouda L	-	TefTekMuteMedium	
B2			-		-		
			-		-		
C3			-		-		
	C#3		-		-		
D3			-		-		
	D#3		-		-		
E3			-		-		
			-		-		
F3			-		-		
	F#3		-		-		
G3			-		-		
	G#3		-		-		
A3			-		-		
	A#3		-		-		
B3			-		-		
			-		-		
C4			-		-		
	C#4		-		-		
D4			-		-		
	D#4		-		-		
E4			-		-		
			-		-		
F4			-		-		
	F#4		-		-		
G4			-		-		
	G#4		-		-		
A4			-		-		
	A#4		-		-		
B4			-		-		
			-		-		
C5			-		-		
	C#5		-		-		
D5			-		-		
	D#5		-		-		
E5			-		-		
			-		-		
F5			-		-		
	F#5		-		-		
G5			-		-		
	G#5		-		-		
A5			-		-		
	A#5		-		-		
B5			-		-		
			-		-		
C6			-		-		
			-		-		

]: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Chinese Kit			Orchestra Perc		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1			-	Luo High 1		-	Snare Ensemble
	C#1		-	Gong Batter		Symphonic Gong 1	Sus Cym 1 Roll S
D1			-	Jin Luo		Symphonic Gong L	Sus Cymbal 1
	D#1		-	Luo High 2		Symphonic Gong 2	Sus Cym 2 Roll L
E1			-	Luo Mid-Low		Timpani E	Sus Cymbal 2
			-	Luo		Timpani F	Concert Tom 5
F1			-	Jin Luo Low		Timpani F#	OrchCymbal 1 ckd
	F#1		-	Da Cha 1		Timpani G	Concert Tom 4
G1			-	Da Cha Effect		Timpani G#	Orch Cymbal 1
	G#1		-	Zhong Cha		Timpani A	Concert Tom 3
A1			-	Xiao Cha Effect		Timpani A#	Orch Cymbal 2
	A#1		Da Cha 2	Xiao Cha		Timpani B	Concert Tom 2
C2		-	Da Gu mp	Mang Luo Low	-	Timpani C	Concert Tom 1
	C#2	-	Da Gu Rim	Mang Luo Mid	-	Timpani C#	Finger Cymbal
D2		-	Da Gu f	Qing	-	Timpani D	Gong
	D#2	-	Da Gu Hand	Finger Bell	-	Timpani D#	Ride Cymbal Tip
E2		-	Da Gu Roll	Luo Big	-	Timpani High E	China Cymbal
		-	Pai Gu 4	Mu Yu Low	-	Gran Cassa Hard	Ride Cymbal Cup
F2		-	Pai Gu 4 High	Mu Yu Mid-Low	-	Gran Cassa Soft	Tambourine
	F#2	-	Pai Gu 3	Mu Yu Mid	-	Gran Cassa Hit	Splash Cymbal
G2		-	Pai Gu 3 High		-	Gran Cassa Cresc	
	G#2	-	Pai Gu 2		-	ConcertSnareDrum	
A2		-	Pai Gu 2 High		-	Snare Roll	
	A#2	-	Pai Gu 1		-	Snare Drum Light	
C3		Ban	Luo High 1		Bongo H Stick	Snare Ensemble	
	C#3	Ban Gu Roll	Gong Batter		Bongo L Stick	Sus Cym 1 Roll S	
D3		ChineseOperaVo 1	Jin Luo		Conga H Stick	Sus Cymbal 1	
	D#3	ChineseOperaVo 2	Luo High 2		Conga L Stick	Sus Cym 2 Roll L	
E3		ChineseOperaVo 3	Luo Mid-Low		Whip	Sus Cymbal 2	
		Yun Luo F	Luo		Rotating Tom 5	Concert Tom 5	
F3		Yun Luo F#	Jin Luo Low		Tubular Bell L	OrchCymbal 1 ckd	
	F#3	Yun Luo G	Da Cha 1		Rotating Tom 4	Concert Tom 4	
G3		Yun Luo G#	Da Cha Effect		Tubular Bell M	Orch Cymbal 1	
	G#3	Yun Luo A	Zhong Cha		Rotating Tom 3	Concert Tom 3	
A3		Yun Luo A#	Xiao Cha Effect		Tubular Bell H	Orch Cymbal 2	
	A#3	Yun Luo B	Xiao Cha		Rotating Tom 2	Concert Tom 2	
B3		Yun Luo C	Mang Luo Low		Rotating Tom 1	Concert Tom 1	
	C#4	Yun Luo C#	Mang Luo Mid		Temple Block H	Finger Cymbal	
D4		Yun Luo D	Qing		Temple Block L	Gong	
	D#4	Yun Luo D#	Finger Bell		Claves	Ride Cymbal Tip	
E4		Yun Luo E	Luo Big		Wood Block H	China Cymbal	
		Yun Luo High F	Mu Yu Low		Wood Block L	Ride Cymbal Cup	
F4		Yun Luo High F#	Mu Yu Mid-Low		Anvil	Tambourine	
	F#4	Yun Luo High G	Mu Yu Mid		Triangle Roll	Splash Cymbal	
G4		Yun Luo High G#	Mu Yu High		Triangle Mute	Cowbell	
	G#4	Yun Luo High A	Nan Bang Zi Roll		Triangle Open	Jingle Ring	
A4		Yun Luo High A#	Nan Bang Zi		Bell Tree	Castanet Roll	
	A#4	Yun Luo High B	Ban Gu		Sleigh Bells	Table Castanet	
B4		Yun Luo High C	-		Wind Chimes	-	
	C#5	-	-		-	-	
D5		-	-		-	-	
	D#5	-	-		-	-	
E5		-	-		-	-	
		-	-		-	-	
F5		-	-		-	-	
	F#5	-	-		-	-	
G5		-	-		-	-	
	G#5	-	-		-	-	
A5		-	-		-	-	
	A#5	-	-		-	-	
B5		-	-		-	-	
		-	-		-	-	
C6		-	-		-	-	
		-	-		-	-	

]: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Ambi Pop Drums			Ambi Rock Drums		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 1 PD		-	Kick 1 RD	
			Hat Tip 00 PD	Snare 1 Stick PD		Hat Tip 00 RD	Snare 1 Stick RD	
D1	D#1		Hat Edge 00 PD	Snare 1 PD		Hat Edge 00 RD	Snare 1 RD	
			Hat Tip 10 PD	Clap Power		Hat Tip 10 RD	Clap Power	
E1			Hat Edge 10 PD	Snare 2 PD		Hat Edge 10 RD	Snare 3 RD	
			Hat Edge 25 PD	Tom 1 PD		Hat Edge 25 RD	Tom 1 RD	
F1	F#1		Hat Edge 50 PD	Hat Edge 00 PD		Hat Edge 50 RD	Hat Edge 00 RD	
			Hat Edge 75 PD	Tom 2 PD		Hat Edge 75 RD	Tom 2 RD	
G1	G#1		Hat Edge 99 PD	Hat Pdl Close PD		Hat Edge 99 RD	Hat Pdl Close RD	
			Hat Pdl Close PD	Tom 3 PD		Hat Pdl Close RD	Tom 3 RD	
A1	A#1		Hat Pdl Splash	Hat Edge 75 PD		Hat Pdl Splash	Hat Edge 75 RD	
			Seq Click L	Tom 4 PD		Seq Click L	Tom 4 RD	
C2	C#2	-	Seq Click H	Tom 5 PD	-	Seq Click H	Tom 5 RD	
		-	SB Mt Off Ed Prs	Crash 1 PD	-	SB Mt Off Ed Prs	Crash 1 RD	
D2	D#2	-	Snare 4 noRim PD	Tom 6 PD	-	Snare 2 noRim RD	Tom 6 RD	
		-	Snare 3 noRim PD	Ride Tip 1 PD	-	Snare 4 noRim RD	Ride Tip 1 RD	
E2		-	Snare 2 noRim PD	China Cymbal PD	-	Snare 3 noRim RD	China Cymbal RD	
		-	Snare Roll PD	Ride Cup PD	-	Snare Roll RD	Ride Cup RD	
F2	F#2	-	Snare 4 PD	Tambourine	-	Snare 2 RD	Tambourine	
		-	Snare 3 PD	Splash Cymbal PD	-	Snare 4 RD	Splash Cymbal RD	
G2	G#2	-	Stick Count VO		-	Stick Count VO		
		-	Kick 3 PD		-	Kick 3 RD		
A2	A#2	-	Snare 1 OpRim PD		-	Snare 1 OpRim RD		
		-	Kick 2 PD		-	Kick 2 RD		
C3	C#3	Bongo H	Kick 1 PD		Bongo H	Kick 1 RD		
		Bongo L	Snare 1 Stick PD		Bongo L	Snare 1 Stick RD		
D3	D#3	Conga H Mute	Snare 1 PD		Conga H Mute	Snare 1 RD		
		Conga H Open	Clap Power		Conga H Open	Clap Power		
E3		Conga L	Snare 2 PD		Conga L	Snare 3 RD		
		Timbale H	Tom 1 PD		Timbale H	Tom 1 RD		
F3	F#3	Timbale L	Hat Edge 00 PD		Timbale L	Hat Edge 00 RD		
		Agogo H	Tom 2 PD		Agogo H	Tom 2 RD		
G3	G#3	Agogo L	Hat Pdl Close PD		Agogo L	Hat Pdl Close RD		
		Cabasa	Tom 3 PD		Cabasa	Tom 3 RD		
A3	A#3	Maracas	Hat Edge 75 PD		Maracas	Hat Edge 75 RD		
		Samba Whistle H	Tom 4 PD		Samba Whistle H	Tom 4 RD		
C4	C#4	Samba Whistle L	Tom 5 PD		Samba Whistle L	Tom 5 RD		
		Guiro Short	Crash 1 PD		Guiro Short	Crash 1 RD		
D4	D#4	Guiro Long	Tom 6 PD		Guiro Long	Tom 6 RD		
		Claves	Ride Tip 1 PD		Claves	Ride Tip 1 RD		
E4		Wood Block H	China Cymbal PD		Wood Block H	China Cymbal RD		
		Wood Block L	Ride Cup PD		Wood Block L	Ride Cup RD		
F4	F#4	Cuica Mute	Tambourine		Cuica Mute	Tambourine		
		Cuica Open	Splash Cymbal PD		Cuica Open	Splash Cymbal RD		
G4	G#4	Triangle Mute	Cowbell 1 JB		Triangle Mute	Cowbell RD		
		Triangle Open	Crash 2 PD		Triangle Open	Crash 2 RD		
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap		
		Jingle Bells	Ride Tip 2 PD		Jingle Bells	Ride Tip 2 PD		
C5	C#5	Wind Chimes	-		Wind Chimes	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Ambi VintageOpen			Ambi VintageMute		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 1 VO		-	Kick 3 VM	
			Hat Tip 00 VO	Snare 1 Stick VO		Hat Tip 00 VM	Snare 1 Stick VM	
D1	D#1		Hat Edge 00 VO	Snare 1 VO		Hat Edge 00 VM	Snare 1 VM	
			Hat Tip 10 VO	Clap Power		Hat Tip 10 VM	Clap Power	
E1			Hat Edge 10 VO	Snare 2 VO		Hat Edge 10 VM	Snare 2 VM	
			Hat Edge 25 VO	Tom 1 VO		Hat Edge 25 VM	Tom 1 VM	
F1	F#1		Hat Edge 50 VO	Hat Tip 00 VO		Hat Edge 50 VM	Hat Edge 00 VM	
			Hat Edge 75 VO	Tom 2 VO		Hat Edge 75 VM	Tom 2 VM	
G1	G#1		Hat Edge 99 VO	Hat Pdl Close VO		Hat Edge 99 VM	Hat Pdl Close VM	
			Hat Pdl Close VO	Tom 3 VO		Hat Pdl Close VM	Tom 3 VM	
A1	A#1		Hat Pdl Splash	Hat Edge 75 VO		Hat Pdl Splash	Hat Edge 75 VM	
			Seq Click L	Tom 4 VO		Seq Click L	Tom 4 VM	
C2	C#2	-	Seq Click H	Tom 5 VO	-	Seq Click H	Tom 5 VM	
		-	Tambourine Stick	Crash 1 VO	-	Tambourine Stick	Crash 1 VM	
D2	D#2	-	Snare 4 noRim VO	Tom 6 VO	-	Snare 4 noRim VM	Tom 6 VM	
		-	Snare 3 noRim VO	Ride Tip 1 VO	-	Snare 3 noRim VM	Ride Tip VM	
E2		-	Snare 2 noRim VO	China Cymbal PD	-	Snare 2 noRim VM	China Cymbal PD	
		-	Snare Roll PD	Ride Cup VO	-	Snare Roll PD	Ride Cup VM	
F2	F#2	-	Snare 3 VO	Tambourine	-	Snare 3 VM	Tambourine	
		-	Snare 4 VO	Splash Cymbal PD	-	Snare 4 VM	Splash Cymbal PD	
G2	G#2	-	Stick Count VO		-	Stick Count VM		
		-	Kick 3 VO		-	Kick 2 VM		
A2	A#2	-	Snare 1 OpRim VO		-	Snare 1 OpRim VM		
		-	Kick 2 VO		-	Kick 1 VM		
C3	C#3	Bongo H	Kick 1 VO		Bongo H	Kick 3 VM		
		Bongo L	Snare 1 Stick VO		Bongo L	Snare 1 Stick VM		
D3	D#3	Conga H Mute	Snare 1 VO		Conga H Mute	Snare 1 VM		
		Conga H Open	Clap Power		Conga H Open	Clap Power		
E3		Conga L	Snare 2 VO		Conga L	Snare 2 VM		
		Timbale H	Tom 1 VO		Timbale H	Tom 1 VM		
F3	F#3	Timbale L	Hat Tip 00 VO		Timbale L	Hat Edge 00 VM		
		Agogo H	Tom 2 VO		Agogo H	Tom 2 VM		
G3	G#3	Agogo L	Hat Pdl Close VO		Agogo L	Hat Pdl Close VM		
		Cabasa	Tom 3 VO		Cabasa	Tom 3 VM		
A3	A#3	Maracas	Hat Edge 75 VO		Maracas	Hat Edge 75 VM		
		Samba Whistle H	Tom 4 VO		Samba Whistle H	Tom 4 VM		
C4	C#4	Samba Whistle L	Tom 5 VO		Samba Whistle L	Tom 5 VM		
		Guiro Short	Crash 1 VO		Guiro Short	Crash 1 VM		
D4	D#4	Guiro Long	Tom 6 VO		Guiro Long	Tom 6 VM		
		Claves	Ride Tip 1 VO		Claves	Ride Tip VM		
E4		Wood Block H	China Cymbal PD		Wood Block H	China Cymbal PD		
		Wood Block L	Ride Cup VO		Wood Block L	Ride Cup VM		
F4	F#4	Cuica Mute	Tambourine		Cuica Mute	Tambourine		
		Cuica Open	Splash Cymbal PD		Cuica Open	Splash Cymbal PD		
G4	G#4	Triangle Mute	Cowbell 1 JB		Triangle Mute	Cowbell 1 JB		
		Triangle Open	Crash 2 VO		Triangle Open	Crash 2 VM		
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap		
		Jingle Bells	Ride Tip 2 PD		Jingle Bells	Ride Real		
C5	C#5	Wind Chimes	-		Wind Chimes	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Ambi Jazz Stick			Ambi Jazz Brush		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 2 JS		-	Kick 2 JB	
			Hat Tip 00 JS	Snare 2 Stick JS		Surdo Mute	Snare 2 Stick JS	
D1	D#1		Hat Edge 00 JS	Snare 2 noRim JS		Surdo Open	SB Mute Shaft	
			Hat Tip 10 JS	Clap Power		Hi Q	Clap Power	
E1			Hat Edge 10 JS	Snare 2 Off JS		Whip Slap	SB with Shaft	
			Hat Edge 25 JS	Tom 1 JS		Scratch H	Tom 1 JB	
F1	F#1		Hat Edge 50 JS	Hat Edge 00 JS		Scratch L	Hat Center 00 JB	
			Hat Edge 75 JS	Tom 2 JS		Finger Snap	Tom 2 JB	
G1	G#1		Hat Edge 99 JS	Hat Pdl Close JS		Click Noise	Hat Pdl Close JB	
			Hat Pdl Close JS	Tom 3 JS		Metronome Click	Tom 3 JB	
A1	A#1		Hat Pdl Splash	Hat Edge 99 JS		Metronome Bell	Hat Edge 75 JB	
			Seq Click L	Tom 4 JS		SB Lin Sweep Sh	Tom 4 JB	
C2	C#2	-	Seq Click H	Tom 5 JS	-	SB Lin Sweep Ln	Tom 5 JB	
		-	Snare Off Stk JS	Crash 1 JS	-	SB Off Ed Prs	Crash 1 JB	
D2	D#2	-	SD2 noRim Off JS	Tom 6 JS	-	SB Swirl Loop 1	Tom 6 JB	
		-	Snare 1 noRim JS	Ride Tip 1 JS	-	SB Pressed	Ride Tip JB	
E2		-	Snare 3 noRim JS	China Cymbal PD	-	SB Swirl 2 Atk	China Cymbal RB	
		-	Snare Roll JS	Ride Cup JS	-	SB Swirl 1 Atk	Ride Cup JB	
F2	F#2	-	Snare 1 JS	Tambourine	-	SB Dyn Sweep	Tambourine	
		-	Snare 3 JS	Splash Cymbal JS	-	SB Prs Low Range	Splash Cymbal JB	
G2	G#2	-	Stick Count VO		-	Stick Count VO		
		-	Kick 3 VM		-	Kick 3 VM		
A2	A#2	-	Snare 2 OpRim JS		-	SB Mt only Shaft		
		-	Kick 1 JS		SB Op Cntr Sh JB	Kick 1 JB		
C3	C#3	Bongo H	Kick 2 JS		Bongo H	Kick 2 JB		
		Bongo L	Snare 2 Stick JS		Bongo L	Snare 2 Stick JS		
D3	D#3	Conga H Mute	Snare 2 noRim JS		Conga H Mute	SB Mute Shaft		
		Conga H Open	Clap Power		Conga H Open	Clap Power		
E3		Conga L	Snare 2 Off JS		Conga L	SB with Shaft		
		Timbale H	Tom 1 JS		Timbale H	Tom 1 JB		
F3	F#3	Timbale L	Hat Edge 00 JS		Timbale L	Hat Center 00 JB		
		Cowbell 1 JB	Tom 2 JS		Agogo H	Tom 2 JB		
G3	G#3	Cowbell 1 Tip JB	Hat Pdl Close JS		Agogo L	Hat Pdl Close JB		
		Cabasa	Tom 3 JS		Cabasa	Tom 3 JB		
A3	A#3	Maracas	Hat Edge 99 JS		Maracas	Hat Edge 75 JB		
		Samba Whistle H	Tom 4 JS		Samba Whistle H	Tom 4 JB		
C4	C#4	Samba Whistle L	Tom 5 JS		Samba Whistle L	Tom 5 JB		
		Guiro Short	Crash 1 JS		Guiro Short	Crash 1 JB		
D4	D#4	Guiro Long	Tom 6 JS		Guiro Long	Tom 6 JB		
		Claves	Ride Tip 1 JS		Claves	Ride Tip JB		
E4		Wood Block H	China Cymbal PD		Wood Block H	China Cymbal RB		
		Wood Block L	Ride Cup JS		Wood Block L	Ride Cup JB		
F4	F#4	Cuica Mute	Tambourine		Cuica Mute	Tambourine		
		Cuica Open	Splash Cymbal JS		Cuica Open	Splash Cymbal JB		
G4	G#4	Triangle Mute	Cowbell 2 JB		Triangle Mute	Cowbell 1 JB		
		Triangle Open	Crash 2 JS		Triangle Open	Crash 2 JB		
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap		
		Jingle Bells	Ride Tip 2 PD		Jingle Bells	Ride Backend JB		
C5	C#5	Wind Chimes	-		Wind Chimes	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Ambi JazzBrushEx			Ambi Production		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 2 JB		-	Kick 12 PF	
			Hat Center 00 JB	Snare 2 Stick JS		Hat Tip 00 PF	Side-Stick PF	
D1	D#1		Hat Edge 00 JB	SB Mute Shaft		Hat Edge 00 PF	Snare 5 noRim PF	
			Hat Center 10 JB	Clap Power		Hat Tip 10 PF	Clap Power	
E1			Hat Edge 10 JB	SB with Shaft		Hat Edge 10 PF	Snare 3 PF	
			Hat Edge 25 JB	Tom 1 JB		Hat Edge 25 PF	Tom 1 PF	
F1	F#1		Hat Edge 50 JB	Hat Center 00 JB		Hat Edge 50 PF	Hat Edge 00 PF	
			Hat Edge 75 JB	Tom 2 JB		Hat Edge 75 PF	Tom 2 PF	
G1	G#1		Hat Edge 99 JB	Hat Pdl Close JB		Hat Edge 99 PF	Hat Pdl Close PF	
			Hat Pdl Close JB	Tom 3 JB		Hat Pdl Close PF	Tom 3 PF	
A1	A#1		Hat Pdl Splash	Hat Edge 75 JB		Hat Pedal Splash	Hat Edge 99 PF	
			SB Swirl Loop 1	Tom 4 JB		Seq Click L	Tom 4 PF	
C2	C#2	-	SB Swirl Loop 2	Tom 5 JB	-	Seq Click H	Tom 5 PF	
		-	SB Dyn Sweep Ln	Crash 1 JB	-	SB Op Cntr Sh JB	Crash 1 PF	
D2	D#2	-	SB Dyn Sweep Md	Tom 6 JB	-	Snare 1 PF	Tom 6 PF	
		-	SB Dyn Sweep Sh	Ride Tip JB	Kick 1 PF	Snare 4 noRim PD	Ride Tip PF	
E2		-	SB Lin Swp Ln L	China Cymbal RB	Kick 2 PF	Snare 2 PF	China Cymbal PD	
		-	SB Lin Swp Ln R	Ride Cup JB	Kick 3 PF	Snare Roll PF	Ride Cup PF	
F2	F#2	-	SB Lin Swp Sh L	Tambourine	Kick 4 PF	Snare 3 noRim PF	Tambourine	
		-	SB Lin Swp Sh R	Splash Cymbal JB	Kick 5 PF	Snare 4 PF	Splash Cymbal PF	
G2	G#2	-	Stick Count VO		Kick 6 PF	Stick Count VO		
		-	Kick 3 VM		Kick 7 PF	Kick 10 PF		
A2	A#2	-	SB Pressed		Kick 8 PF	Snare 5 OpRim PF		
		SB Op Cntr Sh JB	Kick 1 JB		Kick 9 PF	Kick 11 PF		
C3	C#3	SB Roll	Kick 2 JB		Bongo H	Kick 12 PF		
		SB Off Prs	Snare 2 Stick JS		Bongo L	Side-Stick PF		
D3	D#3	SB Off Ed Prs	SB Mute Shaft		Conga H Mute	Snare 5 noRim PF		
		SB Snappy Off	Clap Power		Conga H Open	Clap Power		
E3		SB Off Edge	SB with Shaft		Conga L	Snare 3 PF		
		SB Mt Off Prs	Tom 1 JB		Timbale H	Tom 1 PF		
F3	F#3	SB Mt Off Ed Prs	Hat Center 00 JB		Timbale L	Hat Edge 00 PF		
		SB Mt Snappy Off	Tom 2 JB		Cowbell 1 JB	Tom 2 PF		
G3	G#3	SB Mt Off Edge	Hat Pdl Close JB		Cowbell 1 Tip JB	Hat Pdl Close PF		
		SB Swish L	Tom 3 JB		Cabasa	Tom 3 PF		
A3	A#3	SB Swish R	Hat Edge 75 JB		Maracas	Hat Edge 99 PF		
		Kick 3 JB	Tom 4 JB		Samba Whistle H	Tom 4 PF		
C4	C#4	Kick 2 JS	Tom 5 JB		Samba Whistle L	Tom 5 PF		
		Snare Off Stk JS	Crash 1 JB		Guiro Short	Crash 1 PF		
D4	D#4	Snare 2 noRim JS	Tom 6 JB		Guiro Long	Tom 6 PF		
		Clap AF	Ride Tip JB		Claves	Ride Tip PF		
E4		Snare 2 Off JS	China Cymbal RB		Wood Block H	China Cymbal PD		
		Tom 1 JS	Ride Cup JB		Wood Block L	Ride Cup PF		
F4	F#4	Hat Edge 00 JS	Tambourine		Cuica Mute	Tambourine		
		Tom 2 JS	Splash Cymbal JB		Cuica Open	Splash Cymbal PF		
G4	G#4	Hat Edge 50 JS	Cowbell 1 JB		Triangle Mute	Cowbell 2 JB		
		Tom 3 JS	Crash 2 JB		Triangle Open	Crash 2 PF		
A4	A#4	Hat Edge 99 JS	Cowbell 1 Tip JB		Shaker	Vibraslap		
		Tom 4 JS	Ride Backend JB		Jingle Bells	Ride Tip 2 PD		
C5	C#5	Tom 5 JS	-		Wind Chimes	-		
		Crash 1 JS	-		-	-		
D5	D#5	Tom 6 JS	-		-	-		
		Ride Tip JS	-		-	-		
E5		China Cymbal PD	-		-	-		
		Ride Cup JS	-		-	-		
F5	F#5	Shaker	-		-	-		
		Splash Cymbal JS	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Ambi Dirty Kit			Ambi Symphonic		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 12 DK		-	Gran Cassa Mute	
			Hat Tip 00 DK	Side-Stick DK		Surdo Mute	Side Stick	
D1	D#1		Hat Edge 00 DK	Snare 5 DK		Surdo Open	Band Snare 1	
			Hat Tip 10 DK	Clap Power		Hi Q	Hand Clap	
E1			Hat Edge 10 DK	Snare 1 DK		Whip Slap	Band Snare 2	
			Hat Edge 25 DK	Tom 1 DK		Scratch H	Floor Tom L	
F1	F#1		Hat Edge 50 DK	Hat Edge 00 DK		Scratch L	Hi-Hat Closed	
			Hat Edge 75 DK	Tom 2 DK		Finger Snap	Floor Tom H	
G1	G#1		Hat Edge 99 DK	Hat Pdl Close DK		Click Noise	Hi-Hat Pedal	
			Hat Pdl Close DK	Tom 3 DK		Metronome Click	Low Tom	
A1	A#1		Hat Pedal Splash	Hat Edge 99 DK		Metronome Bell	Hi-Hat Open	
			Seq Click L	Tom 4 DK		Seq Click L	Mid Tom L	
C2	C#2	-	Seq Click H	Tom 5 DK	-	Seq Click H	Mid Tom H	
		-	SB Op Cntr Sh JB	Crash 1 DK	-	Brush Tap	Hand Cymbal 1	
D2	D#2	-	Snare 1 noRim DK	Tom 6 DK	-	Brush Swirl	High Tom	
			Kick 1 DK	Snare 2 DK	-	Brush Slap	Hand Cymbal 1 S	
E2			Kick 2 DK	Snare 3 DK	-	Brush Tap Swirl	China Cymbal	
			Kick 3 DK	Snare Roll DK	-	Snare Roll	Ride Cymbal Cup	
F2	F#2		Kick 4 DK	Snare 1	-	Castanet	Tambourine	
			Kick 5 DK	Snare 4 DK	-	Snare Soft	Splash Cymbal	
G2	G#2		Kick 6 DK	Stick Count DK	-	Sticks		
			Kick 7 DK	Kick 10 DK	-	Kick Soft		
A2	A#2		Kick 8 DK	Snare 3 OpRim DK	-	Open Rim Shot		
			Kick 9 DK	Kick 11 DK	-	Gran Cassa		
C3	C#3	Bongo H	Kick 12 DK		Bongo H	Gran Cassa Mute		
		Bongo L	Side-Stick DK		Bongo L	Side Stick		
D3	D#3	Conga H Mute	Snare 5 DK		Conga H Mute	Band Snare 1		
		Conga H Open	Clap Power		Conga H Open	Hand Clap		
E3		Conga L	Snare 1 DK		Conga L	Band Snare 2		
		Timbale H	Tom 1 DK		Timbale H	Floor Tom L		
F3	F#3	Timbale L	Hat Edge 00 DK		Timbale L	Hi-Hat Closed		
		Cowbell 1 JB	Tom 2 DK		Agogo H	Floor Tom H		
G3	G#3	Cowbell 1 Tip JB	Hat Pdl Close DK		Agogo L	Hi-Hat Pedal		
		Cabasa	Tom 3 DK		Cabasa	Low Tom		
A3	A#3	Maracas	Hat Edge 99 DK		Maracas	Hi-Hat Open		
		Samba Whistle H	Tom 4 DK		Samba Whistle H	Mid Tom L		
C4	C#4	Samba Whistle L	Tom 5 DK		Samba Whistle L	Mid Tom H		
		Guiro Short	Crash 1 DK		Guiro Short	Hand Cymbal 1		
D4	D#4	Guiro Long	Tom 6 DK		Guiro Long	High Tom		
		Claves	Ride Tip DK		Claves	Hand Cymbal 1 S		
E4		Wood Block H	China Cymbal DK		Wood Block H	China Cymbal		
		Wood Block L	Ride Cup DK		Wood Block L	Ride Cymbal Cup		
F4	F#4	Cuica Mute	Tambourine DK		Cuica Mute	Tambourine		
		Cuica Open	Splash Cymbal DK		Cuica Open	Splash Cymbal		
G4	G#4	Triangle Mute	Cowbell DK		Triangle Mute	Cowbell		
		Triangle Open	Crash 2 DK		Triangle Open	Hand Cymbal 2		
A4	A#4	Shaker	Vibraslap		Shaker	Vibraslap		
		Jingle Bells	Ride Tip 2 PD		Sleigh Bells	Hand Cymbal 2 S		
C5	C#5	Wind Chimes	-		Wind Chimes	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Revo Tight EDM			EDM Kit		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		Clap 6 TEDM	Kick 3 TEDM		-	Kick 10 EDM
D1			Snare 5 TEDM	Shaker TEDM		Kick 1 EDM	Thump EDM
	D#1		Clap 7 TEDM	Snare 3 TEDM		Kick 2 EDM	Snare 8 EDM
E1			Snare 6 TEDM	Clap 3 TEDM		Glitch 2 EDM	Clap 1 EDM
	F1		Snare 7 TEDM	Clap 4 TEDM		Snare 10 EDM	Snare 9 EDM
F1			Hat Close 7 TEDM	Tom 4 TEDM		Snare 3 EDM	Tom B6 80P
	F#1		Tom 9 TEDM	Hat Close 2 TEDM		Snare 4 EDM	Hat Close 1 EDM
G1			Hat Close 8 TEDM	Tom 5 TEDM		White Noise Up	Tom B5 80P
	G#1		Tom 10 TEDM	Hat Pedal TEDM		Glitch 1 EDM	Hat Shank EDM
A1			Hat Open 5 TEDM	Tom 6 TEDM		Bump EDM	Tom B4 80P
	A#1		Tom 11 TEDM	Hat Open 2 TEDM		Rev Shot EDM	Hat Open 1 EDM
B1			Crash 6 TEDM	Tom 7 TEDM		Glitch 3 EDM	Tom B3 80P
C2	C#2	-	Kick 1 TEDM	Tom 8 TEDM	-	Kick 9 EDM	Tom B2 80P
D2		-	Snare 1 TEDM	Crash 2 TEDM	-	Snare 6 EDM	Crash Cymbal T9
	D#2	-	Clap 1 TEDM	Clock TEDM	-	Snare 12 EDM	Tom B1 80P
E2		-	Clap 2 TEDM	Ride TEDM	-	Snare 5 EDM	Ride Shank EDM
	F2	-	Snare 2 TEDM	Click TEDM	-	Snare 13 EDM	Crash Cymbal 4
F2		-	Tom 1 TEDM	Cowbell TEDM	-	Rev Hit EDM	Ride Cup 2
	F#2	-	Hat Close 1 TEDM	Crash 3 TEDM	-	Snare 15 EDM	Tambourine Hit
G2		-	Tom 2 TEDM	Sub SE 1 TEDM	-	Snare 2 EDM	Splash Cymbal 2
	G#2	-	Hat Open 1 TEDM		-	Snare 1 EDM	
A2		-	Tom 3 TEDM		-	Kick 5 EDM	
	A#2	-	Crash 1 TEDM		-	Snare 14 EDM	
B2		-	Kick 2 TEDM		-	Kick 3 EDM	
C3	C#3	SE 2 TEDM	Kick 3 TEDM		Bongo H Open 1F	Kick 10 EDM	
D3		Voice 1 TEDM	Shaker TEDM		Bongo L Open 3F	Thump EDM	
	D#3	SideChain 1 TEDM	Snare 3 TEDM		Conga H Tip	Snare 8 EDM	
E3		Voice 2 TEDM	Clap 3 TEDM		Conga H SlapOpen	Clap 1 EDM	
	F3	SideChain 2 TEDM	Clap 4 TEDM		Conga H Open 2	Snare 9 EDM	
F3		Voice 3 TEDM	Tom 4 TEDM		Timbale H	Tom B6 80P	
	F#3	Impact TEDM	Hat Close 2 TEDM		Timbale L	Hat Close 1 EDM	
G3		Voice 4 TEDM	Tom 5 TEDM		Agogo H	Tom B5 80P	
	G#3	Reverse 1 TEDM	Hat Pedal TEDM		Agogo L	Hat Shank EDM	
A3		Voice 5 TEDM	Tom 6 TEDM		Cabasa	Tom B4 80P	
	A#3	Reverse 2 TEDM	Hat Open 2 TEDM		Maracas Slur	Hat Open 1 EDM	
B3		Voice 6 TEDM	Tom 7 TEDM		Vox Drum L	Tom B3 80P	
C4	C#4	Voice 7 TEDM	Tom 8 TEDM		Vox Drum H	Tom B2 80P	
D4		Voice 8 TEDM	Crash 2 TEDM		Guiro Short	Crash Cymbal T9	
	D#4	SE 3 TEDM	Clock TEDM		Guiro Long	Tom B1 80P	
E4		SE 4 TEDM	Ride TEDM		Claves	Ride Shank EDM	
	F4	SE 5 TEDM	Click TEDM		Clap 2 EDM	Crash Cymbal 4	
F4		Voice 9 TEDM	Cowbell TEDM		Clap 3 EDM	Ride Cup 2	
	F#4	SE 6 TEDM	Crash 3 TEDM		Hat Close 4 EDM	Tambourine Hit	
G4		Snare 4 TEDM	Sub SE 1 TEDM		Hat Open 2 EDM	Splash Cymbal 2	
	G#4	Clap 5 TEDM	Hat Close 3 TEDM		Hat Close 2 EDM	Cowbell 1	
A4		Hat Close 4 TEDM	Sub SE 2 TEDM		Hat Close 3 EDM	Crash Cymbal 2	
	A#4	Tom 9 TEDM	Hat Open 3 TEDM		Kick 4 EDM	Cowbell T8	
B4		Hat Close 5 TEDM	SE 1 TEDM		Kick 6 EDM	Ride Cymbal 3	
C5	C#5	Tom 10 TEDM	-		Kick 7 EDM	-	
D5		Voice 10 TEDM	-		Kick 8 EDM	-	
	D#5	Voice 11 TEDM	-		Fill Tom EDM	-	
E5		Crash 4 TEDM	-		Fill Snare EDM	-	
	F5	Voice 12 TEDM	-		Snare 7 EDM	-	
F5		SE 7 TEDM	-		Snare 11 EDM	-	
	F#5	Hat Close 6 TEDM	-		Impact Lo EDM	-	
G5		SE 8 TEDM	-		Impact Hi EDM	-	
	G#5	Hat Open 4 TEDM	-		-	-	
A5		SE 9 TEDM	-		-	-	
	A#5	Crash 5 TEDM	-		-	-	
B5		Kick 4 TEDM	-		-	-	
C6		Kick 5 TEDM	-		-	-	

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Punchy EDM Kit			Electro Kit 2		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 5 PE		-	Kick 8 EK	
D1			Slice 14 PE	Snap 1 PE		Kick 5 EK	Rim Shot EK	
E1	D#1		Loop Kick PE	Snare 8 PE		Kick 6 EK	Snare 9 EK	
F1			Loop Hi-Hat PE	Clap 1 PE		SFX 6 EK	Clap 1 EK	
G1	F#1		Loop Snare PE	Snare 9 PE		SFX 7 EK	Snare T9 1	
A1			Kick 1 PE	Tom 7 PE		Kick 3 EK	Tom 1 EK	
B1	G#1		Hat Close 1 PE	Hat Close 2 PE		Kick 4 EK	Hat Close 1 EK	
C2			Snare 1 PE	Tom 8 PE		SFX 12 EK	Tom 2 EK	
D2	A#1		Clap+Snare PE	Hat Close 3 PE		SFX 11 EK	Hat Close 2 EK	
E2			Snare 2 PE	Tom 9 PE		SFX 10 EK	Tom 3 EK	
F2	B#1		Tom 1 PE	Hat Open PE		SFX 9 EK	Hat Open 3 EK	
G2			Tom 2 PE	Tom 10 PE		SFX 8 EK	Tom 4 EK	
A2	C#2		Side-Stick 3 PE	Kick 2 PE	-	Kick 2 EK	Tom 5 EK	
B2			Snare 28 PE	Snare 3 PE	-	Snare 2 EK	Crash Cymbal T9	
C3	D#2		Snare 29 PE	Snare 4 PE	-	Snare 3 EK	Tom 6 EK	
D3			Snare 30 PE	Tom 3 PE	-	Clap 6 EK	Ride Cymbal T9	
E3	F#2		Snare 31 PE	Tom 4 PE	-	Snare 1 EK	Crash Cymbal 4	
F3			Snare 32 PE	Tom 5 PE	-	Snare 4 EK	Ride Cup 2	
G3	G#2		Kick 6 PE	Tom 6 PE	-	Snare 10 EK	Tambourine 82P	
A3			Kick 7 PE	Snare 5 PE	-	Snare 5 EK	Splash Cymbal 2	
B3	A#2		Kick 8 PE	Snare 6 PE	-	Clap 5 EK		
C4			Kick 9 PE	Kick 3 PE	-	Kick 11 EK		
D4	B#2		Kick 10 PE	Snare 7 PE	-	Clap 2 EK		
E4			Kick 11 PE	Kick 4 PE	-	Kick 1 EK		
F4	C#3		Snare 13 PE	Kick 5 PE	Bongo H 80R	Kick 8 EK		
G4			Snare 14 PE	Snap 1 PE	Bongo L 80R	Rim Shot EK		
A4	D#3		Snare 15 PE	Snare 8 PE	Conga Mute 80R	Snare 9 EK		
B4			Clap 2 PE	Clap 1 PE	Conga H 80R	Clap 1 EK		
C5	E#3		Snap 2 PE	Snare 9 PE	Conga L 80R	Snare T9 1		
D5			Snap 3 PE	Tom 7 PE	Timbale H	Tom 1 EK		
E5	F#3		Snare 16 PE	Hat Close 2 PE	Timbale L	Hat Close 1 EK		
F5			Snare 17 PE	Tom 8 PE	Agogo H 80R	Tom 2 EK		
G5	G#3		Snare 18 PE	Hat Close 3 PE	Agogo L 80R	Hat Close 2 EK		
A5			Shaker 1 PE	Tom 9 PE	Cabasa 80R	Tom 3 EK		
B5	A#3		Shaker 2 PE	Hat Open PE	Cabasa 81R	Hat Open 3 EK		
C6			Snare 19 PE	Tom 10 PE	Vox Drum L	Tom 4 EK		
D6	C#4		Snare 20 PE	Tom 11 PE	Vox Drum H	Tom 5 EK		
E6			Snare 21 PE	Crash 1 PE	SFX 5 EK	Crash Cymbal T9		
F6	D#4		Snare 22 PE	Snare 10 PE	SFX 4 EK	Tom 6 EK		
G6			Snare 23 PE	Ride 1 PE	SFX 1 EK	Ride Cymbal T9		
A6	F#4		Hat Close 4 PE	Impact 1 PE	SFX 2 EK	Crash Cymbal 4		
B6			Hat Close 5 PE	Ride 2 PE	SFX 3 EK	Ride Cup 2		
C7	G#4		Hat Close 6 PE	Tambourine PE	Clap 8 EK	Tambourine 82P		
D7			Hat Close 7 PE	Crash 2 PE	Clap 4 EK	Splash Cymbal 2		
E7	A#4		Hat Close 8 PE	Wood Block PE	Hat Open 1 EK	Cowbell 80R		
F7			Hat Close 9 PE	Crash 3 PE	Hat Open 2 EK	Crash Cymbal 2		
G7	B#4		Hat Close 10 PE	Snare 11 PE	Hat Open 4 EK	Cowbell T8		
A7			Shaker 3 PE	Snare 12 PE	Kick 7 EK	Ride Cymbal 3		
B7	C#5		Click 1 PE	Slice 1 PE	Kick 10 EK	-		
C8			Side-Stick 1 PE	Slice 2 PE	Kick 12 EK	-		
D8	D#5		Side-Stick 2 PE	Slice 3 PE	Kick 9 EK	-		
E8			Click 2 PE	Slice 4 PE	Snare 6 EK	-		
F8	F#5		Click 3 PE	Slice 5 PE	Snare 8 EK	-		
G8			Click 4 PE	Slice 6 PE	Snare 11 EK	-		
A8	G#5		Snare 24 PE	Slice 7 PE	Snare 7 EK	-		
B8			Brush Snare PE	Slice 8 PE	Filter Kick	-		
C9	A#5		Snare 25 PE	Slice 9 PE	-	-		
D9			Snare 26 PE	Slice 10 PE	-	-		
E9	B#5		Clap 3 PE	Slice 11 PE	-	-		
F9			Clap 4 PE	Slice 12 PE	-	-		
G9	C#6		Snare 27 PE	Slice 13 PE	-	-		
A9								

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Dubstep Kit			Trap Kit 1		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 1 DS		-	Kick 8 NT	
			Kick 4 DS	Rim Shot DS		-	Side-Stick NT	
D1	D#1		Kick 5 DS	Snare 1 DS		-	Snare 1 NT	
			Digital DS	Clap 1 DS		-	Clap 1 NT	
E1			PinkNoise Down 1	Snare 2 DS		-	Snare 2 NT	
			WhiteNoiseDown 2	Tom T9 1		-	Tom 1 NT	
F1	F#1		PinkNoise Down 2	Hat Close 1 DS		-	Hat Close 2 NT	
			Boomer DS	Tom T9 2		-	Tom 2 NT	
G1	G#1		Synth Scratch DS	Hat Pedal DS		-	Hat Close 3 NT	
			Bouncer DS	Tom T9 3		-	Kick 9 NT	
A1	A#1		Tin Cowbell DS	Hat Open 1 DS		-	Hat Open NT	
			RevFlngrSnare DS	Tom T9 4		-	Tom 3 NT	
C2	C#2	-	Kick 10 DS	Tom T9 5	-	Dab Vox 1 NT	Tom 4 NT	
		-	Snare 3 DS	Crash Cymbal T9	-	Perc Pipe NT	Crash 1 NT	
D2	D#2	-	Clap 4 DS	Tom T9 6	-	Crash FX NT	Tom 5 NT	
		-	Snare 4 DS	Ride Cym T9	-	Ride 1 NT	Ride 2 NT	
E2		-	Snare 11 DS	Crash Cymbal 4	-	Hat Close 1 NT	Dab Vox 1 NT	
		-	Snare 5 DS	Ride Cup 2	-	Kick 1 NT	Knock NT	
F2	F#2	-	Snare T9 3	Tambourine 82P	-	Kick 2 NT	Perc Low NT	
		-	Snare 6 DS	Splash Cymbal 2	-	Kick 3 NT	Strike NT	
G2	G#2	-	Clap 3 DS		-	Kick 4 NT		
		-	Kick 2 DS		-	Kick 5 NT		
A2	A#2	-	Clap 2 DS		-	Kick 6 NT		
		-	Kick 3 DS		-	Kick 7 NT		
C3	C#3	Bongo H 82P	Kick 1 DS		Snap 1 NT	Kick 8 NT		
		Bongo L 82P	Rim Shot DS		Snap 2 NT	Side-Stick NT		
D3	D#3	Conga Mute 82P	Snare 1 DS		Snap 3 NT	Snare 1 NT		
		Conga H 82P	Clap 1 DS		Snap 4 NT	Clap 1 NT		
E3		Conga L 82P	Snare 2 DS		Snap 5 NT	Snare 2 NT		
		Timbale H	Tom T9 1		Snare 1 NT	Tom 1 NT		
F3	F#3	Timbale L	Hat Close 1 DS		Snare 3 NT	Hat Close 2 NT		
G3	G#3	Cowbell H 82P	Tom T9 2		Clap 2 NT	Tom 2 NT		
		Cowbell M 82P	Hat Pedal DS		Clap 3 NT	Hat Close 3 NT		
A3	A#3	Cabasa 81P	Tom T9 3		Snare 4 NT	Kick 9 NT		
		Maracas Slur	Hat Open 1 DS		Clap 4 NT	Hat Open NT		
B3		Vox Drum L	Tom T9 4		Clap 5 NT	Tom 3 NT		
C4	C#4	Vox Drum H	Tom T9 5		Clap 6 NT	Tom 4 NT		
		Guiro Short	Crash Cymbal T9		Clap 1 NT	Crash 1 NT		
D4	D#4	Guiro Long	Tom T9 6		Clap 7 NT	Tom 5 NT		
		Claves 83P	Ride Cym T9		Clap 8 NT	Ride 2 NT		
E4		Wood Block H	Crash Cymbal 4		Snap 6 NT	Dab Vox 1 NT		
F4	F#4	Wood Block L	Ride Cup 2		Kick 6 NT	Knock NT		
G4	G#4	Hat Close 2 DS	Tambourine 82P		Kick 5 NT	Perc Low NT		
		Hat Close 3 DS	Splash Cymbal 2		Kick 4 NT	Strike NT		
A4	A#4	Triangle Mute	Cowbell L 82P		Kick 3 NT	Perc Echo NT		
		Triangle Open	Crash Cymbal 2		Dab Vox 2 NT	Crash 2 NT		
B4		Hat Open 2 DS	Cowbell T8		Voice 1 NT	Crash 3 NT		
		Kick 6 DS	Ride Cymbal 3		Voice 2 NT	Crash 4 NT		
C5	C#5	Kick 7 DS	-		Voice 3 NT	-		
		Kick 8 DS	-		Voice 4 NT	-		
D5	D#5	Kick 9 DS	-		Voice 5 NT	-		
		Snare 7 DS	-		Voice 6 NT	-		
E5		Snare 8 DS	-		Voice 7 NT	-		
F5	F#5	Snare 9 DS	-		Voice 8 NT	-		
		Snare 10 DS	-		Voice 9 NT	-		
G5	G#5	Filter Kick	-		Voice 10 NT	-		
A5	A#5	-	-		SE 1 NT	-		
		-	-		SE 2 NT	-		
B5		-	-		SE 3 NT	-		
		-	-		SE 2 NT	-		
C6		-	-		SE 4 NT	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Trap Kit 2			Schlager Kit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 4 TP		-	Kick 1 SC	
			Kick 5 TP	Rim Shot TP		LpElement 1a SC	Side Stick Power	
D1	D#1		Kick 6 TP	Snare 1 TP		LpElement 1b SC	Snare 2 SC	
			WhiteNoiseDown 1	Clap 5 TP		LpElement 1c SC	Snare 3 SC	
E1			PinkNoise Down 1	Snare 2 TP		LpElement 1d SC	Snare 6 SC	
			WhiteNoiseDown 2	Tom 1 TP		LpElement 1e SC	Tom 1 SC	
F1	F#1		PinkNoise Down 2	Hat Close 3 TP		LpElement 1f SC	Hat Close 1 SC	
			FNS 1 TP	Tom 2 TP		LpElement 1g SC	Tom 2 SC	
G1	G#1		FNS 2 TP	Hat Close 4 TP		LpElement 1h SC	Hat Close 2 SC	
			SFX 1 TP	Tom 3 TP		LpElement 1i SC	Tom 3 SC	
A1	A#1		SFX 2 TP	Hat Open 1 TP		LpElement 1f SC	Hat Open 1 SC	
			SFX 3 TP	Tom 4 TP		NoiseUp SC	Tom 4 SC	
C2	C#2	-	Kick 11 TP	Tom 5 TP	-	Kick TB SC	Tom 5 SC	
		-	Snare 4 TP	Crash Cymbal T9	-	LpElement 2a SC	Crash 1 SC	
D2	D#2	-	Clap 1 TP	Tom 6 TP	-	LpElement 2b SC	Tom 6 SC	
		-	Clap 1 83P	Ride Cymbal T9	-	LpElement 2c SC	Ride Acoustic 1	
E2		-	Snare 5 TP	Crash Cymbal 4	-	LpElement 2d SC	Impact SC	
		-	Snare 6 TP	Ride Cup 2	-	LpElement 2h SC	Crash Impact SC	
F2	F#2	-	Snare T9 3	Tambourine Hit	-	LpElement 2i SC	Tambourine	
		-	Snare 3 TP	Splash Cymbal 2	-	Snare 1 SC	Crash 2 SC	
G2	G#2	-	Clap 2 TP		-	Snare 1 83P		
		-	Kick 2 TP		-	Kick 2 81P		
A2	A#2	-	Clap 3 TP		-	Snare 4 SC		
		-	Kick 1 TP		-	Kick 2 SC		
C3	C#3	Bongo H Open 1F	Kick 4 TP		Snare 8 SC	Kick 1 SC		
		Bongo L Open 3F	Rim Shot TP		Snare 9 SC	Side Stick Power		
D3	D#3	Conga H Tip	Snare 1 TP		Snare 10 SC	Snare 2 SC		
		Conga H SlapOpen	Clap 5 TP		Clap 4 SC	Snare 3 SC		
E3		Conga H Open 2	Snare 2 TP		Clap 1 SC	Snare 6 SC		
		Timbale H	Tom 1 TP		Clap 2 SC	Tom 1 SC		
F3	F#3	Timbale L	Hat Close 3 TP		Clap 6 SC	Hat Close 1 SC		
		Agogo H	Tom 2 TP		Clap 3 SC	Tom 2 SC		
G3	G#3	Agogo L	Hat Close 4 TP		Clap 7 SC	Hat Close 2 SC		
		Cabasa	Tom 3 TP		Shaker 4 SC	Tom 3 SC		
A3	A#3	Maracas Slur	Hat Open 1 TP		Shaker 3 SC	Hat Open 1 SC		
		Vox Drum L	Tom 4 TP		Clap 5 SC	Tom 4 SC		
C4	C#4	Vox Drum H	Tom 5 TP		Echo Shot 1 SC	Tom 5 SC		
		Guiro Short	Crash Cymbal T9		Echo Shot 2 SC	Crash 1 SC		
D4	D#4	Guiro Long	Tom 6 TP		Echo Shot 3 SC	Tom 6 SC		
		Cowbell 2 TP	Ride Cymbal T9		Echo Shot 4 SC	Ride Acoustic 1		
E4		Wood Block H	Crash Cymbal 4		Hat Close 3 SC	Impact SC		
		Wood Block L	Ride Cup 2		Hat Close 4 SC	Crash Impact SC		
F4	F#4	Hat Close 1 TP	Tambourine Hit		Hat Close 5 SC	Tambourine		
		Hat Close 2 TP	Splash Cymbal 2		Hat Open 2 SC	Crash 2 SC		
G4	G#4	Triangle Mute	Cowbell 1 TP		Shaker 1 SC	Cowbell 1		
		Triangle Open	Crash Cymbal 2		Shaker 2 SC	Crash 3 SC		
A4	A#4	Hat Open 2 TP	Cowbell T8		Shaker 6 SC	Snare 5 SC		
		Kick 7 TP	Ride Cymbal 3		Shaker 5 SC	Snare 7 SC		
C5	C#5	Kick 8 TP	-		Reverse 1 SC	-		
		Kick 9 TP	-		Reverse 2 SC	-		
D5	D#5	Kick 10 TP	-		Rev Snare SC	-		
		Snare 7 TP	-		Long Snare SC	-		
E5		Snare 8 TP	-		LpDrums Kick SC	-		
		Snare 9 TP	-		LpDrums Hat 1 SC	-		
F5	F#5	Snare 10 TP	-		LpDrums Snare SC	-		
		Clap 4 TP	-		LpDrums Hat 2 SC	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

 : Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Club Kit			Chill Kit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 3 CL		-	Kick 3 CH	
D1			-	Snare 6 CL		-	Side-Stick CH	
E1	D#1		-	Snare 7 CL		-	Snare 3 CH	
F1			-	Clap 5 CL		-	Clap 3 CL	
G1	F#1		-	Snare 8 CL		-	Snare 4 CH	
A1			-	Tom 1 CL		-	Tom 1 CH	
B1	G#1		-	Hat Close CL		-	Hat Close 1 CH	
C2			-	Tom 2 CL		-	Tom 2 CH	
D2	A#1		-	Hat Pedal CL		-	Hat Close 2 CH	
E2			-	Tom 3 CL		-	Tom 3 CH	
F2	B#1		-	Hat Open CL		-	Hat Open CH	
G2			-	Tom 4 CL		-	Tom 4 CH	
A2	C#2	-	Claves CL	Tom 5 CL	-	Claves CL	Tom 5 CH	
B2			Clap 1 CL	Crash 1 CL	-	Swarm CH	Crash 1 CH	
C3	D#2	-	Clap 2 CL	Tom 6 CL	-	Turn Table CH	Tom 6 CH	
D3			Clap 3 CL	Ride 1 CL	-	SE 1 CH	Ride 1 CL	
E3	F#2	-	Clap 4 CL	China Cymbal CL	-	SE 2 CH	Crash 2 CH	
F3			Snare 1 CL	Ride 2 CL	-	SE 3 CH	Ride 2 CL	
G3	G#2	-	Snare 2 CL	Tambourine 1 CL	-	SE 4 CH	Tambourine 1 CL	
A3			Snare 3 CL	Crash 2 CL	-	Snap 1 CH	Splash CH	
B3	A#2	-	Snare 4 CL		-	Snare 1 CH		
C4			Kick 1 CL		-	Kick 1 CH		
D4	C#3	-	Snare 5 CL		-	Snare 2 CH		
E4			Kick 2 CL		-	Kick 2 CH		
F4	D#3	Percussion 1 CL	Kick 3 CL		Knock CH	Kick 3 CH		
G4			Percussion 2 CL	Snare 6 CL		Cowbell CH	Side-Stick CH	
A4	E#3	Percussion 3 CL	Snare 7 CL		Percussion 1 CH	Snare 3 CH		
B4			Percussion 4 CL	Clap 5 CL		Conga CH	Clap 3 CL	
C5	F#3	Percussion 5 CL	Snare 8 CL		Percussion 2 CH	Snare 4 CH		
D5			Percussion 6 CL	Tom 1 CL		Timbales 1 CH	Tom 1 CH	
E5	G#3	Percussion 7 CL	Hat Close CL		Timbales 2 CH	Hat Close 1 CH		
F5			Percussion 8 CL	Tom 2 CL		Percussion 3 CH	Tom 2 CH	
G5	A#3	Percussion 9 CL	Hat Pedal CL		Percussion 4 CH	Hat Close 2 CH		
A5			Tambourine 2 CL	Tom 3 CL		Cabasa CH	Tom 3 CH	
B5	B#3	Tambourine 3 CL	Hat Open CL		Shaker CH	Hat Open CH		
C6			Percussion 10 CL	Tom 4 CL		Wood Block 2 CH	Tom 4 CH	
D6	C#4	SE 1 CL	Tom 5 CL		Percussion 5 CH	Tom 5 CH		
E6			SE 2 CL	Crash 1 CL		Voice 1 CH	Crash 1 CH	
F6	D#4	SE 3 CL	Tom 6 CL		Voice 2 CH	Tom 6 CH		
G6			SE 4 CL	Ride 1 CL		Voice 3 CH	Ride 1 CL	
A6	E#4	SE 5 CL	China Cymbal CL		Percussion 1 CL	Crash 2 CH		
B6			SE 6 CL	Ride 2 CL		Percussion 2 CL	Ride 2 CL	
C7	F#4	SE 7 CL	Tambourine 1 CL		Percussion 8 CL	Tambourine 1 CL		
D7			SE 8 CL	Crash 2 CL		Percussion 9 CL	Splash CH	
E7	G#4	SE 9 CL	Wood Block CL		Wood Block CL	Wood Block 1 CH		
F7			SE 10 CL	Crash 3 CL		Percussion 6 CH	Crash 3 CL	
G7	A#4	SE 11 CL	SE 14 CL		Granular CH	Percussion 4 CL		
A7			SE 12 CL	Ride 3 CL		Noise Rise CH	Ride 3 CL	
B7	C#5	SE 13 CL	-		Sweep CH	-		
C8			Kick 4 CL	-		Kick 4 CH	-	
D8	D#5	Kick 5 CL	-		Kick 5 CH	-		
E8			Kick 6 CL	-		Kick 6 CH	-	
F8	F#5	Kick 7 CL	-		Kick 7 CH	-		
G8			Kick 8 CL	-		Kick 8 CH	-	
A8	G#5	Kick 9 CL	-		Kick 9 CH	-		
B8			Kick 10 CL	-		Kick 10 CH	-	
C9	A#5	Kick 11 CL	-		Kick 11 CH	-		
D9			Kick 12 CL	-		Kick 12 CH	-	
E9	B#5	Kick 13 CL	-		Kick 13 CH	-		
F9			Kick 14 CL	-		Kick 14 CH	-	
G9	C#6	Kick 15 CL	-		Kick 15 CH	-		
A9								

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			80s Pop Kit			80s R&B Kit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick 1 82P		-	Kick 1 80R	
			Hat 2 Close 81P	Side Stick 1 82P		Hat 3 Close 80R	Side Stick 1 80R	
D1	D#1		Hat 2 Open 81P	Snare 2 82P		Hat 3 Open 80R	Snare 2 80R	
			Hat 3 Close 81P	Clap 1 P-Up 82P		Hat 1 Close 80R	Clap 1 80R	
E1			Hat 3 Open 81P	Snare 1 82P		Hat 1 Open 80R	Snare 1 80R	
			Hat 1 Close 83P	Tom A6 82P		Hat 3 Close 81R	Tom A6 81R	
F1	F#1		Hat 1 Open 83P	Hat 1 Close 82P		Hat 3 Open 81R	Hat 2 Close 81R	
			Clap 1 83P	Tom A5 82P		Hat 1 Close 81R	Tom A5 81R	
G1	G#1		Clap 3 81P	Hat 1 Pedal 82P		Hat 1 Open 81R	Hat 2 Pedal 81R	
			Metronome 2 83P	Tom A4 82P		Metronome 2 81R	Tom A4 81R	
A1	A#1		Metronome 1 83P	Hat 1 Open 82P		Metronome 1 81R	Hat 2 Open 81R	
			Side Stick 1 83P	Tom A3 82P		Side Stick 4 81R	Tom A3 81R	
C2	C#2	-	Kick 2 83P	Tom A2 82P	-	Kick 3 81R	Tom A2 81R	
		-	Side Stick 3 82P	Crash 1 PD	-	Side Stick 2 81R	Crash 1 81R	
D2	D#2	-	Clap 1 82P	Tom A1 82P	-	Clap 3 81R	Tom A1 81R	
		-	Clap 2 81P	Ride 1 82P	-	Clap 1 81R	Ride Cymbal 81R	
E2		-	Side Stick 4 81P	China Cymbal 82P	-	Clap 2 80R	China Cymbal 81R	
		-	Side Stick 2 81P	Ride Bell 82P	-	Side Stick 4 80R	Ride Bell 80R	
F2	F#2	-	Snare 4 81P	Tambourine 82P	-	Clap 3 80R	Tambourine 80R	
		-	Snare 3 81P	Splash 82P	-	Snare 4 81R	Splash 80R	
G2	G#2	-	Snare 1 83P		-	Side Stick 3 80R		
		-	Kick 2 81P		-	Kick 2 81R		
A2	A#2	-	Snare 2 83P		-	Snare 3 81R		
		-	Kick 1 83P		-	Kick 2 80R		
C3	C#3	Bongo H 82P	Kick 1 82P		Bongo H 80R	Kick 1 80R		
		Bongo L 82P	Side Stick 1 82P		Bongo L 80R	Side Stick 1 80R		
D3	D#3	Conga Mute 82P	Snare 2 82P		Conga Mute 80R	Snare 2 80R		
		Conga H 82P	Clap 1 P-Up 82P		Conga H 80R	Clap 1 80R		
E3		Conga L 82P	Snare 1 82P		Conga L 80R	Snare 1 80R		
		Timbale H	Tom A6 82P		Timbale H	Tom A6 81R		
F3	F#3	Timbale L	Hat 1 Close 82P		Timbale L	Hat 2 Close 81R		
		Agogo H 82P	Tom A5 82P		Agogo H 80R	Tom A5 81R		
G3	G#3	Agogo L 82P	Hat 1 Pedal 82P		Agogo L 80R	Hat 2 Pedal 81R		
		Cabasa 82P	Tom A4 82P		Cabasa 80R	Tom A4 81R		
A3	A#3	Tom B5 83P	Hat 1 Open 82P		Tom T8 1	Hat 2 Open 81R		
		Tom B4 83P	Tom A3 82P		Tom T8 2	Tom A3 81R		
C4	C#4	Tom B3 83P	Tom A2 82P		Tom T8 3	Tom A2 81R		
		Tom B2 83P	Crash 1 PD		Tom T8 4	Crash 1 81R		
D4	D#4	Tom B1 83P	Tom A1 82P		Tom T8 5	Tom A1 81R		
		Claves 83P	Ride 1 82P		Claves T8	Ride Cymbal 81R		
E4		Tom A6 81P	China Cymbal 82P		Tom A6 80R	China Cymbal 81R		
		Tom A5 81P	Ride Bell 82P		Tom A5 80R	Ride Bell 80R		
F4	F#4	Tom A4 81P	Tambourine 82P		Tom A4 80R	Tambourine 80R		
		Tom A3 81P	Splash 82P		Tom A3 80R	Splash 80R		
G4	G#4	Tom A2 81P	Cowbell 82P		Tom A2 80R	Cowbell 80R		
		Tom A1 81P	Crash 2 PD		Tom A1 80R	Crash 2 81R		
A4	A#4	Cabasa 81P	Cowbell T8		Cabasa 81R	Vibraslap		
		Jingle Bells	Ride 2 82P		-	Crash 1 RD		
C5	C#5	Wind Chimes	-		-	-		
		Tom B6 80P	-		-	-		
D5	D#5	Tom B5 80P	-		-	-		
		Tom B4 80P	-		-	-		
E5		Tom B3 80P	-		-	-		
		Tom B2 80P	-		-	-		
F5	F#5	Tom B1 80P	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Massive Dance			Chinese Pop Drum		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		Super Low MD	Kick Elec 4 MD		-	Kick 1 PD
			Kick RX11 MD	Snare ElecRim MD		Hat Tip 00 PD	Snare 1 Stick PD
D1	D#1		Kick T9 MD	Snare Elec 1 MD		Hat Edge 00 PD	Snare 1 PD
			KickThickSkin MD	Clap House 1 MD		Hat Tip 10 PD	Clap Power
E1			Kick Dist MD	Snare Elec 2 MD		Hat Edge 10 PD	Snare 2 PD
			Kick Zap Hard MD	Tom Analog 1 MD		Hat Edge 25 PD	Tom 1 PD
F1	F#1		Kick 9 CL	Hat Closed T9 MD		Hat Edge 50 PD	Hat Edge 00 PD
			Kick Blip MD	Tom Analog 2 MD		Hat Edge 75 PD	Tom 2 PD
G1	G#1		Kick Elec 1 MD	Hat Close 4 PE		Hat Edge 99 PD	Hat Pdl Close PD
			Kick Dub Step MD	Tom Analog 3 MD		Hat Pdl Close PD	Tom 3 PD
A1	A#1		Kick 6 PE	Hat Open T9 MD		Hat Pedal Splash	Hat Edge 75 PD
			Kick Elec 2 MD	Tom Analog 4 MD		Seq Click L	Tom 4 PD
C2	C#2	Scratch L 2	Kick 8 NT	Crash Noise MD	-	Seq Click H	Tom 5 PD
		ScratchBDForward	Vocal 4 MD	Crash 1 NT	-	SB Mt Off Ed Prs	Crash 1 PD
D2	D#2	ScratchBDRReverse	Snare 14 PE	Crash 1 PE	-	Snare 4 noRim PD	Tom 6 PD
		Tape Stop MD	Clap 1 NT	Crash Trap MD	-	Snare 3 noRim PD	Ride Tip PD
E2		Turn Table CH	Snare 23 PE	Crash T9 MD	-	Snare 2 noRim PD	China Cymbal PD
		Impact MD	Tom T8 1 MD	Ride Cup RX5 MD	-	Snare Roll PD	Ride Cup PD
F2	F#2	Impact Hi MD	Hat Closed T8 MD	Tambourine S PE	-	Snare 4 PD	Tambourine
		Crash Impact MD	Tom T8 2 MD	CrashDancePop MD	-	Snare 3 PD	Splash Cymbal PD
G2	G#2	Noise Build 1 PE	Electric Perc MD		-	Stick Count VO	
		Noise Build 3 PE	Tom T8 3 MD		-	Kick 3 PD	
A2	A#2	Impact Zap MD	Hat Open T8 MD		-	Snare 1 OpRim PD	
		Sine Drop MD	Kick Elec 3 MD		-	Kick 2 PD	
C3	C#3	Snare DS Rim MD	Kick Elec 4 MD		Da Gu 2 Soft	Kick 1 PD	
		Snare T8 Rim MD	Snare ElecRim MD		Da Gu 2 Hard	Snare 1 Stick PD	
D3	D#3	Snare T9 Rim MD	Snare Elec 1 MD		Da Gu Ens Center	Snare 1 PD	
		Snare Hip Rim MD	Clap House 1 MD		Da Gu Ens Rim	Clap Power	
E3		Snare Jungle MD	Snare Elec 2 MD		Da Luo	Snare 2 PD	
		Snare T9 1 MD	Tom Analog 1 MD		Pai Gu 1	Tom 1 PD	
F3	F#3	Snare Elec MD	Hat Closed T9 MD		Da Luo Crash	Hat Edge 00 PD	
		Snare RX5 MD	Tom Analog 2 MD		Pai Gu 2	Tom 2 PD	
G3	G#3	Snare 3 TEDM	Hat Close 4 PE		Nao Bo Muted	Hat Pdl Close PD	
		Snare Gate 1 MD	Tom Analog 3 MD		Pai Gu 3	Tom 3 PD	
A3	A#3	Snare Elec 3 MD	Hat Open T9 MD		Nao Bo	Hat Edge 75 PD	
		Snare Gate 2 MD	Tom Analog 4 MD		Pai Gu 4	Tom 4 PD	
C4	C#4	Snare Elec 4 MD	Crash Noise MD		Pai Gu 5	Tom 5 PD	
		Snare Bounce MD	Crash 1 NT		Xiao Bo 1 Muted	Crash 1 PD	
D4	D#4	Snare T9 2 MD	Crash 1 PE		Ban Gu Left	Tom 6 PD	
		Snare 33 PE	Crash Trap MD		Xiao Bo 1	Ride Tip PD	
E4		Clap 4 CL	Crash T9 MD		Kuai Ban Big	China Cymbal PD	
		Clap House 2 MD	Ride Cup RX5 MD		Mu Yu 1	Ride Cup PD	
F4	F#4	Clap 6 EK	Tambourine S PE		Xiao Bo 2 Muted	Tambourine	
		Clap 1 EDM	CrashDancePop MD		Mu Yu 2	Splash Cymbal PD	
G4	G#4	Clap 3 NT	Cowbell T8 MD		Xiao Bo 2	Cowbell 1 JB	
		Clap Hip Hop MD	Crash T8 MD		Mu Yu 3	Crash 2 PD	
A4	A#4	Snap 1 CH	HatClose Anlg MD		Xiao Luo 2	Vibraslap	
		Snap 1 PE	Ride T9 MD		Mu Yu 4	Ride Acoustic 2	
C5	C#5	Snap 3 NT	Tom Gate 2 MD		Mu Yu 5	-	
		Snap Hip Hop MD	Tom Gate 3 MD		Jing Luo 1	-	
D5	D#5	Tambourine Op MD	Tom PopRock 1 MD		Shou Gu 2 Center	-	
		Tambourine Hit	Tom PopRock 2 MD		Jing Luo 2	-	
E5		Tambourine H PE	Tom PopRock 3 MD		Shou Gu 1 Center	-	
		Tambourine 82P	Cabasa 81P		Jingle Bells	-	
F5	F#5	HatCls HipHop MD	Shaker 1 SC		Jing Luo 3	-	
		HatOp HipHop MD	Shaker 3 SC		Wind Chimes	-	
G5	G#5	Hat Close R&B MD	Claves 83P		-	-	
		Hat Open R&B MD	Triangle Mute MD		-	-	
A5	A#5	HatCls Elect MD	Triangle Open MD		-	-	
		HatOp Elect MD	Cowbell MD		-	-	
B5		Tom Gate 1 MD	-		-	-	

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

Ambi Cinematic			Revo Pop Percus		
Preset 1 (Upper Keyboard)			Preset 1 (Lower Keyboard)		
Preset 2 (Pedal Keyboard)			Preset 2 (Pedal Keyboard)		
C1	C#1	Cymbal Roll Low	GranCassa M Soft	-	Bongo H Tip AF
D1	D#1	Cymbal Top Low	GranCassa M Wood	Djembe Bass AF	Bongo H OpRm1 AF
E1		Cymbal Roll Med	GranCassa H Soft	Djembe Close AF	Bongo H OpRm3 AF
F1	F#1	Cymbal Top Med	GranCassa H Lthr	Djembe Open AF	Bongo H Mute1 AF
G1	G#1	Cymbal Roll High	GranCassa H Wood	Djembe Slap AF	Bongo H Slap AF
A1	A#1	Cymbal Top High	Floor Tom Low	Cajon Bass PP	Cowbell2 Mth AF
B1		Hand Cym Low	Floor Tom High	Cajon Mid PP	Cowbell1 Mth AF
C2	C#2	Hand Cym Low S	Mid Tom Low	Cajon Hi PP	Chabell Open AF
D2	D#2	Hand Cym Med	Mid Tom High	Conga L Open BR	Cowbell RD
E2		Hand Cym Med S	High Tom	Conga L Close BR	Fibre Clave PP
F2	F#2	Hand Cym High	Roto Tom Low L	Conga L SlpOp BR	Wood Block AF
G2	G#2	Hand Cym High S	Roto Tom Low	Conga L SlpMt BR	African Clave AF
A2	A#2	Bow Low	Roto Tom Med L	Conga H Bass BR	Wood Clave AF
B2		Tam-tam	Roto Tom Med H	Conga H Heel BR	Crash Cymbal AF
C3	C#3	Tam-tam High	Roto Tom High	Conga H Tip BR	Temp Block L PP
D3	D#3	Tam-tam Low	Orch Snare RH	Conga H Open BR	Temp Block M PP
E3		Handmade Tam-tam	Orch Snare LH	Conga H SlpCl BR	Temp Block H PP
F3	F#3	Asian Tam-tam	Orch Snare Roll	Conga H SlpOp BR	Tamb1 Shake PP
G3	G#3	Gong	Orch Snare Flam	Conga H SlpMt BR	Tamb1 Hit PP
A3	A#3	Crash Low	Orch Snare Stick	Bongo L OpRm1 AF	Tamb2 Shake PP
B3		Splash Cymbal		Bongo L Open3 AF	
C4	C#4	Splash Short	GranCassa L Soft	Bongo L Cls3 AF	
D4	D#4	Ride Top	GranCassa L Lthr	Bongo L Slap AF	
E4		Ride Cup	GranCassa L Wood	Bongo H Heel AF	
F4	F#4	March Snare Stck	GranCassa M Soft	Palmas L Open AF	Bongo H Tip AF
G4	G#4	Snare LH	GranCassa M Wood	Palmas R Open AF	Bongo H OpRm1 AF
A4	A#4	Snare RH	GranCassa H Soft	Claps Lo PP	Bongo H OpRm3 AF
B4		Snare Roll	GranCassa H Lthr	Claps Hi PP	Bongo H Mute1 AF
C5	C#5	Snare Flam	GranCassa H Wood	Cabasa L BR	Bongo H Slap AF
D5	D#5	Sidestick	Floor Tom Low	Cabasa R BR	Cowbell2 Mth AF
E5		Piccl Snare LH	Floor Tom High	Shaker1 Up BR	Cowbell1 Mth AF
F5	F#5	Piccl Snare RH	Mid Tom Low	Shaker1 Down BR	Chabell Open AF
G5	G#5	Piccl Snare Roll	Mid Tom High	Shaker1 Long BR	Cowbell RD
A5	A#5	Piccl Snare Flam	High Tom	Shaker2 Up BR	Fibre Clave PP
B5		Piccl Snare Stck	Roto Tom Low L	Shaker2 Down BR	Wood Block AF
C6		Snare Ensemble	Roto Tom Low	Shaker2 Long BR	African Clave AF
		Snare Ens Flam	Roto Tom Med L	Shaker3 Up BR	Wood Clave AF
		Snare Ens Roll	Roto Tom Med H	Shaker3 Down BR	Crash Cymbal AF
		Snare Ens Cresc	Roto Tom High	Shaker3 Long BR	Temp Block L PP
		Whip L	Orch Snare RH	Shaker4 Up BR	Temp Block M PP
		Whip H	Orch Snare LH	Shaker4 Down BR	Temp Block H PP
		Wood Block L	Orch Snare Roll	Shaker4 Long BR	Tamb1 Shake PP
		Wood Block H	Orch Snare Flam	Shaker5 Up PP	Tamb1 Hit PP
		Block	Orch Snare Stick	Shaker5 Down PP	Tamb2 Shake PP
		Boobam Tuned 1	March Snare LH	Udu Bass Open PP	Tamb2 Hit PP
		Boobam Tuned 2	March Snare RH	Udu Bass PP	Tamb3 Hit PP
		Boobam Tuned 3	March Snare Roll	Udu Heel PP	Palmas L Mute AF
		Boobam Tuned 4	March Snare Flam	Udu Tip PP	Palmas R Mute AF
		Boobam Tuned 5	Wind Chimes 1	Udu Body PP	-
		Boobam Tuned 6	Wind Chimes 2	Udu Top PP	-
		Boobam Tuned 7	Bell Tree Down	Triangle OpUp BR	-
		Boobam Tuned 8	Bell Tree Up	Triangle OpDn BR	-
		Boobam Tuned 9	Sleigh Bells	Triangle ClUp BR	-
		Bongo H	Finger Cymbal	Triangle ClDn BR	-
		Bongo L	Fngr Cym Rub Tip	Chimes Down AF	-
		Conga H	Fngr Cym Hammer	Chimes Up AF	-
		Conga L	Fngr Cym Roll	-	-
		Triangle	Tambourine 1	-	-
		Triangle Mute	Tambourine1 Roll	-	-
		Triangle Roll 1	Tambourine 2	-	-
		Triangle Roll 2		-	-

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Revo Afro Cuban			Revo Brazilian		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1			-	Bongo H Tip AF		-	Bongo H Tip AF
	C#1		Djembe Bass AF	Bongo H OpRm1 AF		Djembe Bass AF	Bongo H OpRm1 AF
D1			Djembe Close AF	Bongo H OpRm3 AF		Djembe Close AF	Bongo H OpRm3 AF
	D#1		Djembe Open AF	Bongo H Mute1 AF		Djembe Open AF	Bongo H Mute1 AF
E1			Djembe Slap AF	Bongo H Slap AF		Djembe Slap AF	Bongo H Slap AF
	F1		Cajon Bass AF	Cowbell1 Mth AF		Surdo Open BR	Agogo2 Close BR
G1			Cajon Mid AF	Cowbell1 Top1 AF		Surdo Mute BR	Agogo2 Bell 2 BR
	G#1		Cajon Hi AF	Cowbell1 Top2 AF		Surdo Stop BR	Agogo2 Bell 1 BR
A1			Conga L Open AF	Cowbell1 Edge AF		Conga L Open BR	Agogo1 Close BR
	A#1		Conga L Cls AF	Cowbell2 Mth AF		Conga L Close BR	Agogo1 Bell 2 BR
B1			Conga L SlpOp AF	Cowbell2 Top1 AF		Conga L SlpOp BR	Agogo1 Bell 1 BR
			Conga L SlpMt AF	Cowbell2 Top2 AF		Conga L SlpMt BR	Cabasa L BR
C2		-	Conga H Bass AF	Cowbell2 Edge AF	-	Conga H Bass BR	Cabasa R BR
	C#2	-	Conga H Heel AF	Crash Cymbal AF	-	Conga H Heel BR	Crash Cymbal AF
D2		-	Conga H Tip AF	Chabell Mute AF	-	Conga H Tip BR	Tamborim1 Bck BR
	D#2	-	Conga H Open AF	Chabell Open AF	-	Conga H Open BR	Tamborim1 Cls BR
E2		-	Conga H SlpCl AF	Chabell Top AF	-	Conga H SlpCl BR	Tamborim1 Op BR
	F2		Conga H SlpOp AF	Mambobell Ctr AF	-	Conga H SlpOp BR	Tamborim1 Rim BR
G2		-	Conga H SlpMt AF	Mambobell Edg AF	-	Conga H SlpMt BR	Tamborim2 Up BR
	G#2	-	Bongo L OpRm1 AF	Timb Fg L Mt AF	-	Bongo L OpRm1 AF	Tamborim2 Dn BR
A2		-	Bongo L Open3 AF		-	Bongo L Open3 AF	
	A#2	-	Bongo L Cls3 AF		-	Bongo L Cls3 AF	
B2		-	Bongo L Slap AF		-	Bongo L Slap AF	
		-	Bongo H Heel AF		-	Bongo H Heel AF	
C3		Timb L Open AF	Bongo H Tip AF		Pandeir2 ToCl BR	Bongo H Tip AF	
	C#3	Timb L Rim AF	Bongo H OpRm1 AF		Pandeir2 Slap BR	Bongo H OpRm1 AF	
D3		Timb H Open AF	Bongo H OpRm3 AF		Pandeir1 Heel BR	Bongo H OpRm3 AF	
	D#3	Timb H Rim AF	Bongo H Mute1 AF		Pandeir1 TmOp BR	Bongo H Mute1 AF	
E3		Wood Block AF	Bongo H Slap AF		Pandeir1 ToOp BR	Bongo H Slap AF	
	F3	African Clave AF	Cowbell1 Mth AF		Pandeir1 ThCl BR	Agogo2 Close BR	
G3		Wood Clave AF	Cowbell1 Top1 AF		Pandeir1 ToCl BR	Agogo2 Bell 2 BR	
	G#3	Maracas1 L AF	Cowbell1 Top2 AF		Pandeir1 Slap BR	Agogo2 Bell 1 BR	
A3		Maracas1 H AF	Cowbell1 Edge AF		Shaker1 Up BR	Agogo1 Close BR	
	A#3	Maracas2 L AF	Cowbell2 Mth AF		Shaker1 Down BR	Agogo1 Bell 2 BR	
B3		Maracas2 H AF	Cowbell2 Top1 AF		Shaker1 Long BR	Agogo1 Bell 1 BR	
		Shekere2 Tone AF	Cowbell2 Top2 AF		Shaker2 Up BR	Cabasa L BR	
C4		Shekere2 Up AF	Cowbell2 Edge AF		Shaker2 Down BR	Cabasa R BR	
	C#4	Shekere2 Down AF	Crash Cymbal AF		Shaker2 Long BR	Crash Cymbal AF	
D4		Shekere1 Tone AF	Chabell Mute AF		Shaker3 Up BR	Tamborim1 Bck BR	
	D#4	Shekere1 Up AF	Chabell Open AF		Shaker3 Down BR	Tamborim1 Cls BR	
E4		Shekere1 Down AF	Chabell Top AF		Shaker3 Long BR	Tamborim1 Op BR	
	F4	Guiro Up Shrt AF	Mambobell Ctr AF		Shaker4 Up BR	Tamborim1 Rim BR	
G4		Guiro Dn Shrt AF	Mambobell Edg AF		Shaker4 Down BR	Tamborim2 Up BR	
	G#4	Guiro Up Slow AF	Timb Fg L Mt AF		Shaker4 Long BR	Tamborim2 Dn BR	
A4		Guiro Up Fast AF	Timb Fg L Op AF		Shekere1 Tone AF	Pandeir2 Heel BR	
	A#4	M Guiro Up Sh AF	Timb L Cask AF		Shekere1 Up AF	Pandeir2 TmOp BR	
B4		M Guiro Dn Sh AF	Timb H Cask AF		Shekere1 Down AF	Pandeir2 ToOp BR	
		M Guiro Long AF	Timb L Stick AF		Reco Scrape BR	Pandeir2 TmCl BR	
C5		Palmas L Mute AF	-		Reco Short BR	-	
	C#5	Palmas C Mute AF	-		Reco Long BR	-	
D5		Palmas R Mute AF	-		Triangle OpUp BR	-	
	D#5	Palmas L Open AF	-		Triangle OpDn BR	-	
E5		Palmas C Open AF	-		Triangle ClUp BR	-	
	F5	Palmas R Open AF	-		Triangle ClDn BR	-	
G5		Chimes Down AF	-		Chimes Down AF	-	
	F#5	Chimes Up AF	-		Chimes Up AF	-	
A5		-	-		-	-	
	G#5	-	-		-	-	
B5		-	-		-	-	
	A#5	-	-		-	-	
C6		-	-		-	-	
		-	-		-	-	

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Bass Drum Kit			Reverse BD Kit		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	BD Analog Rubb 1		-	Rev BD AnaRubb 1
			BD Electro	BD Analog Loose		Rev BD Electro	Rev BD AnaLoose
D1	D#1		BD FX Gate	BD Synth 1		Rev BD Fx Gate	Rev BD Synth 1
			BD Hammer	BD Synth 2		Rev BD Hammer	Rev BD Synth 2
E1			BD Analog Power	BD Analog Dist 1		Rev BD AnaPower	Rev BD AnaDist 1
			BD Analog Dist 5	Ripper		-	Reverse Ripper
F1	F#1		BD Analog Dist 6	BD Analog 70 L		Rev BD AnaDist 4	-
			BD Analog Dist 4	BD Analog 70		-	Rev BD Analog 70
G1	G#1		BD Analog Dist 3	BD Analog 80		Rev BD AnaDist 3	Rev BD Analog 81
			BD Analog Dist 2	BD Analog 80Long		Rev BD AnaDist 2	-
A1	A#1		BD Analog Tight	BD Dry		Rev BD AnaTight	Reverse BD Dry
			BD Analog 94	BD Dry Hard		Rev BD Analog 94	-
C2	C#2	-	BD Analog Blip 2	BD Room 1	-	Rev BD AnaBlip 2	-
		-	BD Analog Rubb 2	BD Soft	-	Rev BD AnaRubb 2	Reverse BD Soft
D2	D#2	-	BD Analog 93	BD Room 2	-	Rev BD Analog 93	Rev BD Room 1
		-	BD Analog 90	BD Break Lo-fi 2	-	Rev BD Analog 90	Rev BD BrkLofi 2
E2		-	BD Analog 83	BD Break Lo-fi 1	-	Rev BD Analog 83	Rev BD BrkLofi 1
		-	BD Analog 82	BD&Hi-Hat Open	-	Rev BD Analog 82	Rev BD&HH Open
F2	F#2	-	BD Analog 92	BD Jungle 2	-	-	-
		-	BD Analog 91	BD Jungle 1	-	Rev BD Analog 91	-
G2	G#2	-	BD Analog Deep		-	Rev BD AnaDeep	
		-	BD Analog Hard 2		-	-	
A2	A#2	-	BD Analog Hard 1		-	Rev BD AnaHard	
		-	BD Analog Blip 1		-	Rev BD AnaBlip 1	
C3	C#3	BD RX5 2	BD Analog Rubb 1		Reverse BD RX5 2	Rev BD AnaRubb 1	
		BD Room 3	BD Analog Loose		Rev BD Room 2	Rev BD AnaLoose	
D3	D#3	BD Power Gate	BD Synth 1		Rev BD Pwr Gate	Rev BD Synth 1	
		BD R&B 1	BD Synth 2		Reverse BD R&B 1	Rev BD Synth 2	
E3		BD R&B 2	BD Analog Dist 1		Reverse BD R&B 2	Rev BD AnaDist 1	
		BD Lo-fi	Ripper		Reverse BD Lo-fi	Reverse Ripper	
F3	F#3	BD Hip Deep	BD Analog 70 L		-	-	
		BD Break Deep	BD Analog 70		Rev BD Brk Deep	Rev BD Analog 70	
G3	G#3	BD Break Heavy	BD Analog 80		Rev BD Brk Heavy	Rev BD Analog 81	
		BD Break Hard	BD Analog 80Long		Rev BD Brk Hard	-	
A3	A#3	Big Drum	BD Dry		Reverse Big Drum	Reverse BD Dry	
		Taiko Drum	BD Dry Hard		Rev Taiko Drum	-	
C4	C#4	Surdo Open	BD Room 1		Rev Surdo Open	-	
		Feet 2	BD Soft		Reverse Feet 2	Reverse BD Soft	
D4	D#4	BD Industrial	BD Room 2		Rev Tom Indust	Rev BD Room 1	
		Door Slam	BD Break Lo-fi 2		Rev Door Slam	Rev BD BrkLofi 2	
E4		Punch	BD Break Lo-fi 1		Reverse Punch	Rev BD BrkLofi 1	
		Heart	BD&Hi-Hat Open		-	Rev BD&HH Open	
F4	F#4	Feet 1	BD Jungle 2		Reverse Feet 1	-	
		BD Human	BD Jungle 1		Reverse BD Human	-	
G4	G#4	BD Human Deep	BD Jungle 3		Rev BD Human Dp	Rev BD Jungle	
		Vox Buh!	BD D&B 1		Reverse Vox Buh!	Reverse BD D&B 1	
A4	A#4	Vox Muh!	BD D&B 2		Reverse Vox Muh!	Reverse BD D&B 2	
		-	BD RX5 1		-	Reverse BD RX5 1	
C5	C#5	-	-		-	-	
		-	-		-	-	
D5	D#5	-	-		-	-	
		-	-		-	-	
E5		-	-		-	-	
		-	-		-	-	
F5	F#5	-	-		-	-	
		-	-		-	-	
G5	G#5	-	-		-	-	
		-	-		-	-	
A5	A#5	-	-		-	-	
		-	-		-	-	
B5		-	-		-	-	
		-	-		-	-	
C6		-	-		-	-	
		-	-		-	-	

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Cymbal Kit			Industrial Kit		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Kick A		Plastic Box Kick	Woodbox Kick 1	
			-	Timbale A		Ladder Hit	Click	
D1	D#1		-	China Cymbal A		Metal Spring	Woodbox Kick 2	
			-	Crash Cymbal A		Alpha Impact	Clock	
E1			-	Ride Cymbal A		Bravo Impact	Boxplosion	
			-	Splash Cymbal A		Charlie Impact	Woodbox Kick 3	
F1	F#1		-	-		Duct Tape Rip	Metal HiHat 1	
			-	-		Noise Sweep	Metal HiHat 2	
G1	G#1		-	Crash Cymbal B1		Metal Tom	Metal HiHat 3	
			-	Crash Cymbal B2		Cinematic Sweep	Metal HiHat 4	
A1	A#1		-	Ride Cymbal B		Knuckle Hit	Metal HiHat 5	
			-	-		Scifi Sweep	Metal HiHat 6	
C2	C#2	-	-	-	-	Giant Bass Drum	Oil Barrell 1	
		-	-	Crash Cymbal C	-	Impact FX 1	Oil Barrell 2	
D2	D#2	-	-	Ride Cymbal C	-	Impact FX 2	Oil Barrell 3	
		-	-	Brush Ride Cym C	-	Impact FX 3	Oil Barrell 4	
E2		-	-	Brush SizzlCym C	-	Impact FX 4	Oil Barrell 5	
		-	-	-	-	Impact FX 5	Oil Barrell 6	
F2	F#2	-	-	-	-	Glass Break	Oil Barrell 7	
		-	-	Crash Cymbal D1	-	Canned Kick	Oil Barrell 8	
G2	G#2	-	-		-	Metal Door 1		
		-	-		-	Dist Bass Drum 3		
A2	A#2	-	-		-	Dist Bass Drum 2		
		-	-		-	Dist Bass Drum 1		
C3	C#3	-	Kick A		Stone Bag	Woodbox Kick 1		
		-	Timbale A		Dancing Can	Click		
D3	D#3	Crash Cymbal E1	China Cymbal A		Duct Tape Rip	Woodbox Kick 2		
		Crash Cymbal E2	Crash Cymbal A		Wheelsweep	Clock		
E3		Ride Cymbal E	Ride Cymbal A		Iron Bar Hi	Boxplosion		
		HiHat HalfOpen E	Splash Cymbal A		Iron Bar Lo	Woodbox Kick 3		
F3	F#3	-	-		Iron Sledge	Metal HiHat 1		
		-	-		T.Bell Soft	Metal HiHat 2		
G3	G#3	-	Crash Cymbal B1		T.Bell Rim	Metal HiHat 3		
		-	Crash Cymbal B2		T.Bell Muffle	Metal HiHat 4		
A3	A#3	-	Ride Cymbal B		T.Bell Hard	Metal HiHat 5		
		-	-		Car Door Slam	Metal HiHat 6		
C4	C#4	Crash Cymbal F1	-		Small Metal Box	Oil Barrell 1		
		Brush CrashCymF1	Crash Cymbal C		Mixed Hit 1	Oil Barrell 2		
D4	D#4	Crash Cymbal F2	Ride Cymbal C		Mixed Hit 2	Oil Barrell 3		
		Jazz Ride Cym F1	Brush Ride Cym C		Mixed Hit 3	Oil Barrell 4		
E4		Crash Cymbal F3	Brush SizzlCym C		Mixed Hit 4	Oil Barrell 5		
		Hi-Hat Splash F	-		Mixed Hit 5	Oil Barrell 6		
F4	F#4	Ride Cymbal F1	-		Mixed Hit 6	Oil Barrell 7		
		Crash Cymbal F4	Crash Cymbal D1		Mixed Hit 7	Oil Barrell 8		
G4	G#4	Ride Cymbal F2	Crash Cymbal D2		Metal Clap	Iron Filings		
		Brush CrashCymF2	Crash Cymbal D3		Pump	Iron Spring		
A4	A#4	Jazz Ride Cym F2	Ride Cymbal D		Metal Shot FX	Ladder Clap		
		Crash Cymbal F5	Splash Cymbal D		Metal Sneeze FX	Barn Door		
C5	C#5	-	-		Industrial Snare	-		
		-	-		Woodlog 1	-		
D5	D#5	-	-		Woodlog 2	-		
		-	-		Woodlog 3	-		
E5		-	-		Water Drop	-		
		-	-		Gas Lighter	-		
F5	F#5	-	-		Gas Lighter On	-		
		-	-		Metal Door 2	-		
G5	G#5	-	-		Key Chain	-		
		-	-		Measure Tape	-		
A5	A#5	-	-		MeasureTape Snap	-		
		-	-		Stone Shelf	-		
B5		-	-		Metal Rainpipe	-		
		-	-					

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Vocal Beatbox			ElectroVocal&SFX		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1			-	Kick 1 Class BB		Analog G 2 VX	M One VX
	C#1		Kick 3 Ftbm 2 BB	Snare 3 Stick BB		Trap 1 VX	M Two VX
D1			Kick 5 Throat BB	Snare 1 Class BB		Pop Rock 1 VX	M Three VX
	D#1		Kick 4 Throat BB	Snare 5 KCH BB		Pitch 5 VX	M Feel it VX
E1			Scratch 10 BB	Snare 8 KUCH BB		Analog J 3 VX	M DJ VX
			Scratch 11 BB	Tom 6 Classic BB		Analog J 4 VX	M Some noise VX
F1			Scratch 3 BB	Hat 1 Z-Style BB		Analog J 5 VX	M Feels good VX
	F#1		Scratch 12 BB	Tom 5 Classic BB		Analog J 6 VX	M Turn it up VX
G1			Kick 3 Ftbm 1 BB	Hat 5 Tch-Sty BB		Analog M 1 VX	M Popping VX
	G#1		Kick 6 Elec 2 BB	Tom 4 Classic BB		Vocoder 1 VX	M Louder VX
A1			ZtkPauu 1 BB	Hat 7 Open BB		Vocoder 2 VX	M Beat it VX
	A#1		ZtkPauu 2 BB	Tom 3 Classic BB		Vocoder 3 VX	M Fire VX
B1			-	Kick 7 Throat BB	Pitch 6 VX	Trap One VX	M Stop VX
	C#2		Breath3 BB	Crash Hi 1 BB	Pitch 7 VX	Trap Two VX	M One more VX
D2			Breath2 BB	Tom 1 Classic BB	Clap HipHop 1 VX	Trap Three VX	M Oh my Gosh VX
	D#2		Breath1 BB	Crash Hi 2 BB	Clap House VX	Trap Come on VX	M Fly away VX
E2			Breath4 BB	China Cym 1 BB	Clap DancePop VX	Trap 2 VX	M Bring it VX
			Vibrato BB	China Cym 2 BB	Clap HipHop 2 VX	Trap 3 VX	M Congrats VX
F2			Snare 4 T-Sty BB	Hat 8 Pedal BB	Impact 1 VX	M Dub Step VX	M Birthday VX
	F#2		Snare 6 ISCH BB	FX Cymbal Hi BB	Pop Rock 2 VX	M Electro VX	M Heat it up VX
G2			Snare 2 Clap BB		House 1 VX	M Future Bass VX	
	G#2		Kick 6 Elec 1 BB		Big Room 1 VX	M Hip Hop VX	
A2			Snare 7 TSCH BB		Dub Step 2 VX	M House VX	
	A#2		Kick 2 Class BB		Analog G 3 VX	M Lo-fi VX	
C3		Tom 5 Rim BB	Kick 1 Class BB		F One VX	M One VX	
	C#3		Tom 4 Rim BB	Snare 3 Stick BB	F Two VX	M Two VX	
D3		Tom 3 Rim BB	Snare 1 Class BB		F Three VX	M Three VX	
	D#3		Tom 2 Rim BB	Snare 5 KCH BB	F Let's go VX	M Feel it VX	
E3		Tom 1 Rim BB	Snare 8 KUCH BB		F Come on VX	M DJ VX	
		Now BB	Tom 6 Classic BB		F All right VX	M Some noise VX	
F3		GetReady BB	Hat 1 Z-Style BB		F Hands up VX	M Feels good VX	
	F#3		Fanfare BB	Tom 5 Classic BB	F Uh huh VX	M Turn it up VX	
G3		Trumpet BB	Hat 5 Tch-Sty BB		F Yeah VX	M Popping VX	
	G#3		Shaker BB	Tom 4 Classic BB	F Ready go VX	M Louder VX	
A3		Hat 2 S-Style BB	Hat 7 Open BB		F Ready? VX	M Beat it VX	
	A#3		Scratch 1 BB	Tom 3 Classic BB	F Clap your VX	M Fire VX	
B3		Scratch 2 BB	Tom 2 Classic BB		F Jump VX	M Stop VX	
	C#4		Hat 3 NZ-Sty BB	Crash Hi 1 BB	F Power VX	M One more VX	
D4		Scratch 4 BB	Tom 1 Classic BB		F Ok VX	M Oh my Gosh VX	
	D#4		Hat 4 F-Style BB	Crash Hi 2 BB	F Ahaha VX	M Fly away VX	
E4		Can 2 BB	China Cym 1 BB		F Good time VX	M Bring it VX	
		Can 1 BB	China Cym 2 BB		F Chill VX	M Congrats VX	
F4		Tom 5 Electro BB	Hat 8 Pedal BB		F Click VX	M Birthday VX	
	F#4		Tom 4 Electro BB	FX Cymbal Hi BB	F Close eyes VX	M Heat it up VX	
G4		Tom 3 Electro BB	Hat 6 Wd-Sty BB		F Day VX	M Scratch VX	
	G#4		Tom 2 Electro BB	Crash Lo 1 BB	F Fight VX	M Skrrr skrrr VX	
A4		Tom 1 Electro BB	Scratch 5 BB		F Future VX	M What's up VX	
	A#4		Scratch 6 BB	Crash Lo 2 BB	F Good VX	M Yo VX	
B4		Scratch 7 BB	-		F Hey VX	Analog M 2 VX	
	C#5		Scratch 8 BB	-	F What VX	Dance 3 VX	
D5		Scratch 9 BB	-		F Sing it VX	Synth VX	
	D#5		Peepthkp 1 BB	-	F Look at me VX	Big Room 2 VX	
E5		Peepthkp 2 BB	-	F Ikuyo VX	House 2 VX		
		Laughter BB	-	F Hai VX	Impact 2 VX		
F5		-	-	F Yoisho VX	Raspberry VX		
	F#5		-	-	F Huh VX	Pop Rock 3 VX	
G5		-	-		Hey! VX	Analog J 7 VX	
	G#5		-	-	Accent VX	Analog J 8 VX	
A5		-	-		Dance Pop VX	Pop Rock 4 VX	
	A#5		-	-	Horn DJ VX	Analog J 9 VX	
B5		-	-		Dub Step 1 VX	-	
C6		-	-				

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

			Pop Latin Kit 2			Pop Latin 2 Comp		
			Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Bongo H Open 1F		-	Bongo H Op 1F LC	
			Cajon Low	Bongo H Open 3F		Cajon Low LC	Bongo H Op 3F LC	
D1	D#1		Cajon Slap	Bongo H Rim		Cajon Slap LC	Bongo H Rim LC	
			Cajon Tip	Bongo H Tip		Cajon Tip LC	Bongo H Tip LC	
E1			Claves High	Bongo H Heel		Claves High LC	Bongo H Heel LC	
			Claves Low	Bongo H Slap		Claves Low LC	Bongo H Slap LC	
F1	F#1		Hand Clap	Bongo L Open 1F		Hand Clap LC	Bongo L Op 1F LC	
			-	Bongo L Open 3F		-	Bongo L Op 3F LC	
G1	G#1		Finger Snap	Bongo L Rim		Finger Snap LC	Bongo L Rim LC	
			Castanet	Bongo L Tip		Castanet LC	Bongo L Tip LC	
A1	A#1		Conga H Tip	Bongo L Heel		Conga H Tip LC	Bongo L Heel LC	
			Conga H Heel	Bongo L Slap		Conga H Heel LC	Bongo L Slap LC	
C2	C#2	-	Conga H Open	Timbale L	-	Conga H Open LC	Timbale L LC	
		-	Conga H Mute	-	-	Conga H Mute LC	-	
D2	D#2	-	Conga H SlapOpen	-	-	Conga H SlpOp LC	-	
		-	Conga H Slap	-	-	Conga H Slap LC	-	
E2		-	Conga H SlapMute	-	-	Conga H SlpMt LC	-	
		-	Conga L Tip	Paila L	-	Conga L Tip LC	Paila L LC	
F2	F#2	-	Conga L Heel	Timbale H	-	Conga L Heel LC	Timbale H LC	
		-	Conga L Open	Hand Clap Mute 1	-	Conga L Open LC	Clap Mute 1 LC	
G2	G#2	-	Conga L Mute		-	Conga L Mute LC		
		-	Conga L SlapOpen		-	Conga L SlpOp LC		
A2	A#2	-	Conga L Slap		-	Conga L Slap LC		
		-	Conga L Slide		-	Conga L Slide LC		
C3	C#3	Cowbell Top	Bongo H Open 1F		Cowbell Top LC	Bongo H Op 1F LC		
		Cowbell 1	Bongo H Open 3F		Cowbell 1 LC	Bongo H Op 3F LC		
D3	D#3	Cowbell 2	Bongo H Rim		Cowbell 2 LC	Bongo H Rim LC		
		Cowbell 3	Bongo H Tip		Cowbell 3 LC	Bongo H Tip LC		
E3		Guiro Short	Bongo H Heel		Guiro Short LC	Bongo H Heel LC		
		Guiro Long	Bongo H Slap		Guiro Long LC	Bongo H Slap LC		
F3	F#3	MetalGuiroShort	Bongo L Open 1F		Metal Guiro S LC	Bongo L Op 1F LC		
		MetalGuiro Long	Bongo L Open 3F		Metal Guiro L LC	Bongo L Op 3F LC		
G3	G#3	Tambourine	Bongo L Rim		Tambourine LC	Bongo L Rim LC		
		Tamborim Open	Bongo L Tip		Tamborim Op LC	Bongo L Tip LC		
A3	A#3	Tamborim Mute	Bongo L Heel		Tamborim Mt LC	Bongo L Heel LC		
		Tamborim Tip	Bongo L Slap		Tamborim Tip LC	Bongo L Slap LC		
C4	C#4	Maracas	Timbale L		Maracas LC	Timbale L LC		
		Shaker	-		Shaker LC	-		
D4	D#4	Cabasa	-		Cabasa LC	-		
		Cuica Mute	-		Cuica Mute LC	-		
E4		Cuica Open	-		Cuica Open LC	-		
		Cowbell High 1	Paila L		Cowbell Hi 1 LC	Paila L LC		
F4	F#4	Cowbell High 2	Timbale H		Cowbell Hi 2 LC	Timbale H LC		
		Shekere	Hand Clap Mute 1		Shekere LC	Clap Mute 1 LC		
G4	G#4	Shekere Tone	Hand Clap Mute 2		Shekere Tone LC	Clap Mute 2 LC		
		Triangle Mute	Hand Clap Open 1		Triangle Mute LC	Clap Open 1 LC		
A4	A#4	Triangle Open	Hand Clap Open 2		Triangle Open LC	Clap Open 2 LC		
		-	Paila H		-	Paila H LC		
C5	C#5	Wind Chimes	-		Wind Chimes LC	-		
		-	-		-	-		
D5	D#5	-	-		-	-		
		-	-		-	-		
E5		-	-		-	-		
		-	-		-	-		
F5	F#5	-	-		-	-		
		-	-		-	-		
G5	G#5	-	-		-	-		
		-	-		-	-		
A5	A#5	-	-		-	-		
		-	-		-	-		
B5		-	-		-	-		
		-	-		-	-		
C6		-	-		-	-		
		-	-		-	-		

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

		Indian Kit			Chinese Percus		
		Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)	Preset 1 (Upper Keyboard)	Preset 1 (Lower Keyboard)	Preset 2 (Pedal Keyboard)
C1	C#1		-	Dandia Short		-	Da Gu 2 Hard
D1			-	Dandia Long		Xiao Luo 1	Shou Gu 2 Center
E1	D#1		-	Chutki		XiaoLuo 1 Muffle	Shou Gu 2 Edge 1
F1			Indian Hand Clap	Chipri		Xiao Luo 2	Shou Gu 2 Edge 2
G1	F#1		Dafli Open	Khanjira Open		XiaoLuo 2 Muffle	Shou Gu 2 Edge 3
A1			Dafli Slap	Khanjira Slap		Zhong Luo 1	Pai Gu 1
B1	G#1		Dafli Rim	Khanjira Mute		Zhong Luo 2	Da Bo Muted
C2			Duff Open	Khanjira Bend Up		Da Luo	Pai Gu 2
D2	A#1		Duff Slap	Khanjira Bend Dn		Da Luo Stick	Da Bo Effect
E2			Duff Rim	Dholak 1 Open		Mang Luo 1	Pai Gu 3
F2	B#1		Hatheli Long	Dholak 1 Mute		Mang Luo 2	Da Bo
G2			Hatheli Short	Dholak 1 Slap		Mang Luo 3	Pai Gu 4
A2	C#2	-	Baya ge	Dhol 2 Open	-	Mang Luo 4	Pai Gu 5
B2		-	Baya ke	Dhol 2 Slap	-	Xiao Gu	Da Luo Crash
C3	D#2	-	Baya ghe	Dhol 2 Rim	-	Da Gu Ens Center	Da Luo Effect 1
D3		-	Baya ka	Mridangam na	-	Da Gu Ens Rim	Da Luo Effect 2
E3	F#2	-	Tabla na	Mridangam din	-	Da Gu Ens Shout	Da Luo Effect 3
F3		-	Tabla tin	Mridangam ki	-	Shou Gu 1 Side	Zhong Bo 1 Soft
G3	G#2	-	Tablabaya dha	Mridangam ta	-	Shou Gu 1 Center	Zhong Bo 1 Hard
A3		-	Dhol 1 Open	Mridangam Chapu	-	Shou Gu 1 Edge	Zhong Bo 2 Soft
B3	A#2	-	Dhol 1 Slap		-	Da Gu 1 Rim	
C4		-	Dhol 1 Mute		-	Da Gu 1	
D4	B#2	-	Dhol 1 Open Slap		-	Da Gu 2 Rim	
E4		-	Dhol 1 Roll		-	Da Gu 2 Soft	
F4	C#3	Dholki Hi Open	Dandia Short		Xiao Bo 1	Da Gu 2 Hard	
G4		Dholki Hi Mute	Dandia Long		Xiao Bo 1 Muted	Shou Gu 2 Center	
A4	D#3	Dholki Lo Open	Chutki		Xiao Bo 2	Shou Gu 2 Edge 1	
B4		Dholki Hi Slap	Chipri		Xiao Bo 2 Muted	Shou Gu 2 Edge 2	
C5	E#3	Dholki Lo Slide	Khanjira Open		Jing Luo 1	Shou Gu 2 Edge 3	
D5		Khol Open	Khanjira Slap		Jing Luo 1 Muted	Pai Gu 1	
E5	F#3	Khol Slide	Khanjira Mute		Jing Luo 2	Da Bo Muted	
F5		Khol Mute	Khanjira Bend Up		Jing Luo 2 Muted	Pai Gu 2	
G5	G#3	Manjira Open	Khanjira Bend Dn		Jing Luo 3	Da Bo Effect	
A5		Manjira Close	Dholak 1 Open		Jing Luo 3 Muted	Pai Gu 3	
B5	A#3	Jhanji Open	Dholak 1 Mute		Pai Ban 1	Da Bo	
C6		Jhanji Close	Dholak 1 Slap		Pai Ban 2	Pai Gu 4	
D6	C#4	Mondira Open	Dhol 2 Open		Ban Gu Left	Pai Gu 5	
E6		Mondira Close	Dhol 2 Slap		Ban Gu Roll	Da Luo Crash	
F6	D#4	Bhangra Scat 1	Dhol 2 Rim		Ban Gu Right	Da Luo Effect 1	
G6		Bhangra Scat 2	Mridangam na		Kuai Ban Big	Da Luo Effect 2	
A6	E#4	Bhangra Scat 3	Mridangam din		Kuai Ban Small	Da Luo Effect 3	
B6		Bhangra Scat 4	Mridangam ki		Mu Yu 1	Zhong Bo 1 Soft	
C7	F#4	Khomokh Normal	Mridangam ta		Mu Yu 2	Zhong Bo 1 Hard	
D7		Khomokh Mute	Mridangam Chapu		Mu Yu 3	Zhong Bo 2 Soft	
E7	G#4	Khomokh Flam	Mridangam Lo CIs		Mu Yu 4	Zhong Bo 2 Hard	
F7		Thavil Open	Mridangam Lo Op		Mu Yu 5	Peng Ling	
G7	A#4	Thavil Slap	Chimta Normal		Shi Mian Luo 1	Nao Bo	
A7		Thavil Mute	Chimta Ring		Shi Mian Luo 2	Nao Bo Muted	
B7	C#5	Khartaal	-		Shi Mian Luo 3	-	
C8		Dholak 2 Open	-		Shi Mian Luo 4	-	
D8	D#5	Dholak 2 Slide	-		Shi Mian Luo 5	-	
E8		Dholak 2 Rim 1	-		Shi Mian Luo 6	-	
F8	E#5	Dholak 2 Rim 2	-		Shi Mian Luo 7	-	
G8		Dholak 2 Ring	-		Shi Mian Luo 8	-	
A8	F#5	Dholak 2 Slap	-		Shi Mian Luo 9	-	
B8		-	-		Shi Mian Luo 10	-	
C9	G#5	-	-		-	-	
D9		-	-		-	-	
E9	A#5	-	-		-	-	
F9		-	-		-	-	
G9	B#5	-	-		-	-	
A9		-	-		-	-	
B9	C#6	-	-		-	-	
C10		-	-		-	-	

: Indicates the positions of the Upper Keyboard, Lower Keyboard, and Pedalboard (ELS-03G, ELS-03X, ELS-03XR).

User Keyboard Percussion Kit List

Kit Name	Category	Percussion name (Voice name)			
EL Kit	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Crash Cym Mute	
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Orchestra Cymbal	Orch Cymbal Roll	Orch Cymbal Mute	
		Cymbal March	Cym Brush Shot	Tam-tam	
	HI-HAT	Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal 1	Hi-Hat Pedal 2
		Analog HH Open	Analog HH Closed		
	SNARE DRUM	Snare Drum Light	Snare Drum Heavy	Snare Drum Rim 1	Snare Drum Rim 2
		SD Accent 1	SD Accent 2	SD Reverb 1	SD Reverb 2
		Synth Snare Drum	Orch Snare Drum	Snare Drum Roll	Analog SD
	SNARE BRUSH	SD Brush Shot 1	SD Brush Shot 2	SD Brush Roll	
	TOM	Tom 1	Tom 2	Tom 3	Tom 4
		Tom Brush Shot 1	Tom Brush Shot 2	Tom Brush Shot 3	Tom Brush Shot 4
		Synth Tom 1	Synth Tom 2	Synth Tom 3	
	BASS DRUM	Bass Drum Light	Bass Drum Heavy	Bass Drum Attack	Synth Bass Drum
		Bass Drum March	Concert BD		
		Analog BD Short	Analog BD Long		
	CONGA/BONGO	Conga High	Conga Low	Conga Slap	
		Conga Muff	Conga Slide		
		Bongo High	Bongo Low	Bongo Slap	Bongo Mute
	CUICA/SURDO	Cuica High	Cuica Middle	Cuica Low	
		Tamborim Open	Tamborim Mute		
		Surdo Open	Surdo Mute	Surdo Rim	Surdo Muff
	TIMBALES/ COWBELL	Timbale 1 High	Timbale 1 Low	Timbale 2 High	Timbale 2 Low
		Timbale 3 High	Timbale 3 Low	Timbale 4 High	Timbale 4 Low
		Cowbell 1	Cowbell 2	Cowbell 3	Cowbell 4
	PERCUSSION 1	Cabasa	Shaker	Maracas High	Maracas Low
		Guiro Short	Guiro Long		
		Wood Block High	Wood Block Mid	Wood Block Low	
	PERCUSSION 2	Claves	Castanet	Vibraslap	
		Agogo High	Agogo Low		
		Triangle Open	Triangle Mute	Wind Chime Down	Wind Chime Up
	PERCUSSION 3	Tambourine	Pandeiro	Bells	
		Hand Claps	Finger Snap	Scratch	Noise Percussion
		Kotsuzumi 1	Kotsuzumi 2	Kotsuzumi 3	Kotsuzumi 4
		Ohtsuzumi 1	Ohtsuzumi 2		
		Taiko 1	Taiko 2	Ohdaiko 1	Ohdaiko 2
Standard Kit 1	CYMBAL	Kakegoe 1	Kakegoe 2	Kakegoe 3	
		Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal	China Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Snare	Snare Tight	Snare Soft	Snare Roll
		Side Stick	Open Rim Shot		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Floor Tom L	Floor Tom H	Low Tom	Mid Tom L
		Mid Tom H	High Tom		
	BASS DRUM	Kick	Kick Tight	Kick Soft	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Wind Chimes
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		

Kit Name	Category	Percussion name (Voice name)			
Standard Kit 2	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Snare Short	Snare Tight H	Snare Soft 2	Snare Roll
		Side Stick Light	Open Rim Shot H		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Floor Tom L	Floor Tom H	Low Tom	Mid Tom L
		Mid Tom H	High Tom		
	BASS DRUM	Kick Short	Kick Tight	Kick Soft	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Hit Kit	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hi-Hat Open 2	Hi-Hat Closed 2	Hi-Hat Pedal 2	
	SNARE DRUM	Snare Ambient	Snare Tight 2	Snare Electro	Snare Roll
		Stick Ambient	Snare Pitched		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Hybrid Tom 1	Hybrid Tom 2	Hybrid Tom 3	Hybrid Tom 4
		Hybrid Tom 5	Hybrid Tom 6		
	BASS DRUM	Kick Tight H	Kick Wet	Kick Tight L	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Room Kit	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Snare Snappy	Snare Tight Snap	Snare Soft	Snare Roll
		Side Stick	Open Rim Shot		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Tom Room 1	Tom Room 2	Tom Room 3	Tom Room 4
		Tom Room 5	Tom Room 6		
	BASS DRUM	Kick	Kick Tight	Kick Soft	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		

Kit Name	Category	Percussion name (Voice name)			
Room Kit	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Rock Kit	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Snare Rock	Snare Rock Tight	Snare Noisy	Snare Roll
		Side Stick	Open Rim Shot		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Tom Rock 1	Tom Rock 2	Tom Rock 3	Tom Rock 4
		Tom Rock 5	Tom Rock 6		
	BASS DRUM	Kick Gate	Kick 2	Kick Soft	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Electro Kit 1	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Snare Noisy 2	Snare Noisy 3	Snare Snap Elec	Snare Roll
		Side Stick	Open Rim Shot		
		Brush Tap	Brush Slap	Brush Swirl	Reverse Cymbal
	TOM	Tom Electro 1	Tom Electro 2	Tom Electro 3	Tom Electro 4
		Tom Electro 5	Tom Electro 6		
	BASS DRUM	Kick Gate Heavy	Kick Gate	Kick 3	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Scratch H 2	Scratch L 2
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Hi Q 2	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Analog Kit	CYMBAL	Crash Analog	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hat Open Analog	Hat Close Analog	Hat Close Anlg 2	
	SNARE DRUM	Snare Analog	Snare Analog 2	Snare Noisy 4	Snare Roll
		Side Stick Anlg	Open Rim Shot		
		Brush Tap	Brush Slap	Brush Swirl	Reverse Cymbal
	TOM	Tom Analog 1	Tom Analog 2	Tom Analog 3	Tom Analog 4
		Tom Analog 5	Tom Analog 6		
	BASS DRUM	Kick Analog	Kick Anlg Short	Kick 3	

Kit Name	Category	Percussion name (Voice name)			
Analog Kit	PERCUSSION 1	Conga Analog M	Conga Analog L	Conga Analog H	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell Analog	Claves 2
		Guiro Long	Guiro Short	Maracas 2	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Scratch H 2	Scratch L 2
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Hi Q 2	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Dance Kit	CYMBAL	Crash Analog	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Analog	Ride Cymbal Cup	
		Hi-Hat Open 3	Hi-Hat Closed 3	Hat Close Anlg 3	
	SNARE DRUM	Snare Clap	Snare Dry	Snare Techno	Reverse Dance 2
		Side Stick Anlg	Rim Gate		
		Snare Analog 3	Snare Analog 4	Vinyl Noise	Reverse Cymbal
	TOM	Tom Dance 1	Tom Dance 2	Tom Dance 3	Tom Dance 4
		Tom Dance 5	Tom Dance 6		
	BASS DRUM	Kick Techno	Kick Techno L	Kick Techno Q	
	PERCUSSION 1	Conga Analog M	Conga Analog L	Conga Analog H	
		Bongo Analog H	Bongo Analog L		
		Timbale H	Timbale L	Cowbell Dance	Claves 2
		Guiro Long	Guiro Short	Maracas 2	Vibraslap Analog
	PERCUSSION 2	Kick Dance 1	Kick Dance 2	Dance Breath 1	Dance Breath 2
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine Anlg	Hi Q 2	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Dance Perc 3	Dance Perc 4
		Snare Dance 1	Whip Slap		
		Finger Snap	Dance Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch Dance 1	Scratch Dance 2		
		Dance Perc 2	Hi Q Dance 1		
		Dance Perc 1	Reverse Dance 1		
Jazz Kit	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Snare Jazz L	Snare Jazz M	Snare Jazz H	Snare Roll
		Side Stick Light	Open Rim Shot		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Floor Tom L	Floor Tom H	Low Tom	Mid Tom L
		Mid Tom H	High Tom		
	BASS DRUM	Kick Jazz	Kick Tight	Kick Soft	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		

Kit Name	Category	Percussion name (Voice name)			
Brush Kit	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Brush Slap 3	Brush Tap 2	Brush Slap 2	Snare Roll
		Side Stick Light	Open Rim Shot		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Tom Brush 1	Tom Brush 2	Tom Brush 3	Tom Brush 4
		Tom Brush 5	Tom Brush 6		
	BASS DRUM	Kick Jazz	Kick Tight	Kick Soft	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Symphony Kit	CYMBAL	Hand Cymbal 1	Hand Cymbal 2	Splash Cymbal	Chinese Cymbal
		Hand Cymbal 1 S	Hand Cymbal 2 S	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Band Snare	Band Snare 2	Snare Soft	Snare Roll
		Side Stick	Open Rim Shot		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Floor Tom L	Floor Tom H	Low Tom	Mid Tom L
		Mid Tom H	High Tom		
	BASS DRUM	Gran Cassa Mute	Gran Cassa	Kick Soft 2	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Live! Studio Kit	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal	Chinese Cymbal
		Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Snare Studio M	Snare Studio L	Snare Studio 2	Snare Roll
		Side Stick	Open Rim Shot		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Floor Tom L	Floor Tom H	Low Tom	Mid Tom L
		Mid Tom H	High Tom		
	BASS DRUM	Kick Studio	Kick Ambience L	Kick Ambience H	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		

Kit Name	Category	Percussion name (Voice name)			
Live! Studio Kit	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Live!AcousticKit	CYMBAL	CrashCymbalAco 1	CrashCymbalAco 2	SplashCymbal Aco	China Cymbal Aco
		RideCymbal Aco 1	RideCymbal Aco 2	RideCymbalCupAco	
		Hi-Hat Open Aco	Hi-Hat Close Aco	Hi-Hat Pedal Aco	
	SNARE DRUM	Snare Acoustic	Snare Rough Aco	Snare Soft Aco	Snare Roll Aco
		Stick Acoustic	Rim Acoustic		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Tom Acoustic 1	Tom Acoustic 2	Tom Acoustic 3	Tom Acoustic 4
		Tom Acoustic 5	Tom Acoustic 6		
	BASS DRUM	Kick Mute Aco	Kick Open Aco	Kick Soft Aco	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Wind Chimes
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap Power		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Live! PowerKit 1	CYMBAL	CrashCymbalAco 1	CrashCymbalAco 2	SplashCymbal Aco	China Cymbal Aco
		RideCymbal Aco 1	RideCymbal Aco 2	RideCymbalCupAco	
		Hi-HatOpen Power	Hi-HatClosePower	Hi-HatPedalPower	
	SNARE DRUM	Snare Power 1	Snare Rough 1	SnareSoftPower 1	Snare Roll
		Side Stick Power	Open Rim Power 1		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Tom Power 1	Tom Power 2	Tom Power 3	Tom Power 4
		Tom Power 5	Tom Power 6		
	BASS DRUM	Kick Power Mute	Kick Power Open	Kick Ambient+	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Wind Chime
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap Power		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Live! PowerKit 2	CYMBAL	CrashCymbalAco 1	CrashCymbalAco 2	SplashCymbal Aco	China Cymbal Aco
		RideCymbal Aco 1	RideCymbal Aco 2	RideCymbalCupAco	
		Hi-HatOpen Power	HH Closed PW Eg	Hi-HatPedalPower	
	SNARE DRUM	Snare Power 2	Snare Rough 2	SnareSoftPower 2	Snare Roll
		Side Stick Power	Open Rim Power 2		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Tom Power 1	Tom Power 2	Tom Power 3	Tom Power 4
		Tom Power 5	Tom Power 6		
	BASS DRUM	Kick Power Mute	Kick Power Open	Kick Ambient+	

Kit Name	Category	Percussion name (Voice name)			
Live! PowerKit 2	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Wind Chime
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap Power		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Live! Rock Kit	CYMBAL	CrashCymbalAco 1	CrashCymbalAco 2	SplashCymbal Aco	China Cymbal Aco
		RideCymbal Aco 1	RideCymbal Aco 2	RideCymbalCupAco	
		Hi-Hat Open Rock	Hi-HatClosedRock	Hi-HatPedal Rock	
	SNARE DRUM	Snare Rock	Snare Dry Rock	Snare Soft Rock	Snare Roll Rock
		Stick Rock	Rim Rock		
		Brush Tap	Brush Slap	Brush Swirl	Brush Tap Swirl
	TOM	Tom Rock 1	Tom Rock 2	Tom Rock 3	Tom Rock 4
		Tom Rock 5	Tom Rock 6		
	BASS DRUM	Kick Rock	Kick Rock Heavy	Kick Soft Rock	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Wind Chime
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Hand Clap Power		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		
Live! Real Drums	CYMBAL	CrashCymbalReal1	CrashCymbalReal2	SplashCymbalReal	ChinaCymbal Real
		RideCymbalReal 1	RideCymbalReal 2	RideCym Cup Real	
		Hi-Hat Open Real	Hi-HatClosedReal	Hi-Hat PedalReal	
	SNARE DRUM	Snare Real 1	Snare Real 2	Snare Tight	Snare Roll Rock
		Stick Real	Rim Real		
		Brush Tap	Brush Slap	Brush Tap Swirl	
	TOM	Tom Real 1	Tom Real 2	Tom Real 3	Tom Real 4
		Tom Real 5	Tom Real 6		
	BASS DRUM	Kick Real 1	Kick Real 2	Kick Genuine	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Castanet	Jingle Bells	Wind Chimes
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Clap Power		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Seq Click H	Seq Click L		
		Metronome Bell	Metronome Click		

Kit Name	Category	Percussion name (Voice name)			
Live!RealBrushes	CYMBAL	CrashCymbal RB 1	CrashCymbal RB 2	Splash Cymbal RB	China Cymbal RB
		Ride Cymbal RB	Ride Cup RB 1	Ride Cup RB 2	
		Hi-Hat Open RB	Hi-Hat Closed RB	Hi-Hat Pedal RB	
	SNARE DRUM	Vintage Slap 1	Vintage Slap 2	Vintage Slap 3	Vintage Slap 4
		Vintage Slap 5	VintageSlapSwirl		
		Vintage Swirl 1	Vintage Swirl 2	Vintage Swirl 3	Vintage TapSwirl
		Vintage Tip	Stick Brush	Open Rim Shot RB	
	TOM	TomRealBrushes 1	TomRealBrushes 2	TomRealBrushes 3	TomRealBrushes 4
		TomRealBrushes 5	TomRealBrushes 6		
	BASS DRUM	KickJazzAmbience	Kick Soft H	Kick Soft L	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Timbale H	Timbale L	Cowbell	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L		
	PERCUSSION 3	Tambourine	Jingle Bells	Wind Chimes	
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Sticks	Whip Slap		
		Finger Snap	Clap Power		
	PERCUSSION 4	Hi Q	Click Noise		
		Scratch H	Scratch L		
		Metronome Bell	Metronome Click		
Analog T8 Kit	CYMBAL	Crash Cymbal T8	Crash Cymbal 4	Splash Cymbal	China Cymbal 2
		Ride Cymbal T9	Ride Cymbal 3	RideCymbal Cup 2	
		Hi-Hat Open T8	Hi-Hat Closed T8	Hi-Hat Pedal T8	
	SNARE DRUM 1	Snare T8 1	Snare T8 2	Snare T8 3	Snare T8 4
		Snare T8 5	Snare T8 6	Snare T8 7	Snare T8 Rim
		Snare Analog CR	SnareClap Analog	Snare Break 1	
		Snare Garg L	Snare Fx 1	Snare Hammer	
	SNARE DRUM 2	Snare Hip 1	Snare Hip 2	Snare Hip Gate	
	TOM	Tom T8 1	Tom T8 2	Tom T8 3	Tom T8 4
		Tom T8 5	Tom T8 6	Tom T8 7	
	BASS DRUM	Kick T8 1	Kick T8 2	Kick T8 3	Kick T8 4
		T8 Kick Bass	Kick Slimy	Kick Blip	Kick Tek Power
		Kick Fx Hammer	Kick Zap Hard		
	PERCUSSION 1	Conga T8 1	Conga T8 2	Conga T8 3	Conga T8 4
		Conga T8 5			
		Timbale H	Timbale L	Cowbell T8	Claves T8
		Glass H	Glass L	Maracas T8	Vibraslap
	PERCUSSION 2	Surdo Mute	Surdo Open	Cabasa	
		Analog Shaker	Analog Shaker H	Analog Shaker L	
	PERCUSSION 3	Tambourine RX5	Jingle Bells	Wind Chimes	
		Triangle Open	Triangle Mute		
		Clap T9	Whip Slap		
	PERCUSSION 4	Hi Q	Hi Q 1	Hi Q 2	
		Scratch H	Scratch L	Scratch H 2	Scratch L 2
		Fx Gun 1	Fx Gun 2		
Analog T9 Kit	CYMBAL	Crash Cymbal T9	Splash Cymbal 2	Crash Cymbal 4	China Cymbal 2
		Ride Cymbal T9	Ride Cymbal 3	RideCymbal Cup 2	
		Hi-Hat Open T9	Hi-Hat Closed T9	Hi-Hat Pedal T9	
	SNARE DRUM 1	Snare T9 1	Snare T9 2	Snare T9 3	Snare T9 4
		Snare T9 5	Snare T9 6	Snare T8 7	
		Snare T9 Gate 1	Snare T9 Gate 2	Snare T9 Rim	
	SNARE DRUM 2	Snare Drum&Bass1	Snare Jungle 1	Snare Distortion	Snare Analog CR
		Snare Brush Mute	SnareRckRollDist	Snare Piccolo	Snare Rock Roll
	TOM	Tom T9 1	Tom T9 2	Tom T9 3	Tom T9 4
		Tom T9 5	Tom T9 6		
	BASS DRUM	Kick T9 1	Kick T9 2	Kick T9 3	Kick T9 4
		Kick Tek Power	Kick Sustain	Kick Blip Hard	KickDistortionRM
		Kick Break 2			
	PERCUSSION 1	Conga T8 1	Conga T8 4	Conga T8 5	
		Conga Open	Conga Open Slap	Conga Tip	
		Timbale H	Timbale L	Cowbell 1	Cowbell T8
		Maracas Slur 2			

Kit Name	Category	Percussion name (Voice name)			
Analog T9 Kit	PERCUSSION 2	Surdo Mute	Surdo Open		
		Cabasa	Analog Shaker		
	PERCUSSION 3	Tambourine RX5	Jingle Bells	Wind Chimes	
		Triangle Open	Triangle Mute		
		Clap T9	Clap Analog Sm	Analog Click	Whip Slap
	PERCUSSION 4	Hi Q	Hi Q 1	Hi Q 2	Hi Q 3
		Scratch H	Scratch H 2	Scratch H 3	
		Scratch L	Scratch L 2	Scratch Down	
		Fx Gun 1	Fx Gun 2		
House Kit	CYMBAL	Crash Cymbal T9	Crash Cymbal 1	Crash Cymbal 4	Splash Cymbal 2
		Ride Cymbal T9	Ride Cymbal 3	RideCymbal Cup 2	
		Hi-Hat Open T9	Hi-Hat Closed T8	Hi-Hat Pedal T9	
	SNARE DRUM	Snare T9 1	Snare T9 2	Snare T9 3	Snare T9 5
		Snare T9 Gate	Snare T9 Rim		
		Snare T8 1	Snare T8 5	Snare T8 Rim	
		Snare Garg L	Snare R&B 1	Snare Roll	Snare Break Roll
	TOM	Tom T9 1	Tom T9 2	Tom T9 3	Tom T9 4
		Tom T9 5	Tom T9 6		
	BASS DRUM	Kick T9 1	Kick T9 2	Kick T9 4	Kick T9 5
		W Kick	Filter Kick		
	NOISE	PinkNoise Down 1	PinkNoise Down 2	Pink Noise Up	PinkNoise Up Rel
		WhiteNoiseDown 1	WhiteNoiseDown 2	White Noise Up 1	White Noise Up 2
		WhiteNoiseUp Rel			
		Noise Burst	Disco Fx		
	PERCUSSION 1	Conga H Open 2	Conga H SlapOpen	Conga H Tip	
		Bongo H Open 1 F	Bongo L Open 3 F		
		Timbale H	Timbale L	Cowbell 1	Cowbell T8
		Claves	Guiro Long	Guiro Short	Maracas Slur 2
	PERCUSSION 2	Cuica H	Cuica L	Cabasa	
		Agogo H	Agogo L	Analog Shaker	
		Udu High			
	PERCUSSION 3	Tambourine Hit	Jingle Bells	Wind Chimes	
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Clap T9	Hand Clap		
		Vox Drum H	Vox Drum L	Vox Alk	Vox Bell
HipHop Kit	CYMBAL	Crash T8	Crash Cymbal 3	Ride Cymbal 3	
		Hi-Hat Open Hip	Hi-Hat Open T8 2	Hi-HatOpen Lo-Fi	
		Hi-HatClosed Hip	Hi-HatClosedT8 2	Hi-HatClosed Tek	
		Hi-Hat Pedal Hip	Hi-HatReverseD&B		
	SNARE DRUM	Snare HipHop 1	Snare HipHop 2	Snare HipHop 3	Snare HipHop 5
		Snare HipHop 6	Snare HipHop 7	Snare HipHop 11	
		Snare T8 1	Snare T8 1 H	Snare Clappy	SnareAnalogSmRim
		SnareHipHopRim 2	SnareHipHopRim 3	SnareHipHopRim 4	SnareHipHopRim 5
	TOM	Floor Tom L	Low Tom	Mid Tom L	High Tom
		Tom T8 1	Tom T8 2	Tom T8 3	Tom T8 6
	BASS DRUM	Kick HipHop 1	Kick HipHop 2	Kick HipHop 3	Kick HipHop 4
		Kick HipHop 5	Kick HipHop 8	Kick HipHop 9	Kick HipHop 10
		Kick Hip Deep	Kick Analog CR	Kick Gate	KickGranCasaOpen
	PERCUSSION 1	Conga H Open	Conga H Heel	Conga H Tip	
		Conga L Open 1	Conga L Open 2		
	PERCUSSION 2	Surdo Mute	Surdo Open	Shaker 2	
		HipHop Flex 1	HipHop Flex 2	HipHop Snap 1	HipHop Snap 2
	PERCUSSION 3	TambourineLight1	TambourineLight2	Handbell H	Wind Chimes
		Triangle Open	Triangle Mute	Whip Slap	
		HipHop Clap 2	HipHop Clap 3	HipHop Clap 5	HipHop Clap 6
		HipHop Clap 7	Electric Clap 1	Electric Clap 2	
	PERCUSSION 4	Hi Q			
		Scratch H	Scratch L	ScratchBDForward	ScratchBDRReverse
Drum Machine	CYMBAL	Crash Cymbal T9	Ride Cymbal T9	Hi-Hat Open T8 1	Hi-Hat Open T8 2
		Hi-Hat Open T9	Hi-Hat Open Aco	Hi-HatOpen Lo-Fi	Hi-Hat Open Syn
		Hi-HatClosedT8 1	Hi-HatClosedT8 2	Hi-Hat Closed T9	Hi-HatClosed Aco
		Hi-HatClosedLoFi	Hi-HatClosed Syn	Hi-Hat Pedal T9	Hi-Hat Pedal Aco
	SNARE DRUM	Snare T8 1	Snare T8 2	Snare T8 3	Snare T9 1
		Snare T9 4	Snare T9 Rim	Snare R&B 1	Snare R&B 2
		Snare Hip 1	Snare Timbre	Snare Wood	Snare Drum&Bass1
		Snare Drum&Bass2	Snare Jungle 1	Snare Analog CR	Snare Distortion

Kit Name	Category	Percussion name (Voice name)			
Drum Machine	TOM	Tom T9 1	Tom T9 2	Tom T9 3	Tom T9 4
		Tom T9 5			
	BASS DRUM	Kick T8 2	Kick T8 3	Kick T9 2	Kick T9 4
		Kick T9 HD 3	Kick Tek Power	Kick Break 2	KickDistortionRM
		BD Drum&Bass	Bass Drum Dist 1	Bass Drum Dist 3	Bass Drum Dist 5
		BassDrumTekPower	BassDrumHardLong	Bass Drum Blip	BassDrumAnalogSm
	PERCUSSION 1	Conga T8 1	Conga T8 2	Conga T8 3	
		Cowbell T8	CowbellAnalog CR		
		Claves T8 1	Claves T8 2	Maracas T8	
	PERCUSSION 2	Surdo Mute	Surdo Open		
		Analog Shaker	Analog Shaker 1	Analog Shaker 2	
	PERCUSSION 3	Tambourine RX5 2	Tambourine 1 Hit	TambourineAna CR	
		ElectricTriangle	Electric Cowbell		
		Clap T9	Whip Slap	Electric Clap 1	
	PERCUSSION 4	Hi Q			
		Scratch H	Scratch L	Analog Click	
Break Kit	CYMBAL	Crash Cymbal 1	Crash Cymbal 2	Splash Cymbal 2	China Cymbal 2
		Ride Cymbal 2	Ride Cymbal 3	RideCymbal Cup 2	
		Hi-HatClosedBrk1	Hi-HatClosedBrk2	Hi-HatClosedBrk3	
		HH HalfOpen Rock	HHClosedRockSoft	Hi-Hat PedalRock	
	SNARE DRUM 1	Snare Break 1	Snare Break 2	Snare Break 3	Snare Break 4
		Snare Break 5	Snare Break 6	Snare Break 7	Snare Break 8
		Snare Break 9	Snare Break Rim		
	SNARE DRUM 2	Snare Gate 1	Snare Clappy		
		Snare Hip	Snare Hip Rim 1	Snare Hip Rim 4	
		Snare LdwH Mono	Snare Lo-Fi	Snare Mid	Snare Rock Roll
	TOM	Tom Break 1	Tom Break 2	Tom Break 3	Tom Break 4
		Tom Break 5	Tom Break 6		
	BASS DRUM	Kick Break 1	Kick Break 2	Kick Break 3	Kick Break 4
		Kick Break 5	Kick Break 6	Kick Break 7	
		Kick Break Deep	Kick Break Heavy		
	PERCUSSION 1	Conga H Open	Conga H OpenSlap	Conga H Tip	Conga Open
		Bongo H	Bongo L	Bongo 2 H	Bongo 2 L
		Timbale H	Timbale L	Cowbell 1	Cowbell RX11
		Claves	Maracas Slur		
	PERCUSSION 2	Surdo Mute	Surdo Open	Cabasa	Agogo L
		Scratch H	Scratch L		
		Scratch H 2	Scratch L 2	Scratch H 3	
		Scratch Down			
	PERCUSSION 3	Tambourine 1 Hit			
		Hi Q			
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Whip Slap	Finger Snap		
SFX Kit 1	SFX	Cutting Noise 1	Cutting Noise 2	String Slap	Flute Key Click
		Shower	Thunder	Wind	Stream
		Bubble	Feed	Ghost	Maou
		Dog	Horse	Bird Tweet	
SFX Kit 2	SFX1	Phone Call	Telephone Ring	Wind Chimes	
		Door Squeak	Door Slam	Scratch Cut	Scratch Split
		Laugh	Scream	Punch	Heart Beat
		Foot Steps			
	SFX2	CarEngn Ignition	Car Tires Squeal	Car Passing	Car Crash
		Siren	Train	Jet Plane	Starship
		Burst	Roller Coaster	Submarine	
Live! SFX Kit 1	SFX	Machine Gun	Laser Gun	Explosion	Firework
		Cutting Noise 1	Cutting Noise 2	String Slap	Flute Key Click
		Shower 2	Thunder 2	Wind 2	Stream 2
		Bubble 2	Feed	Ghost	Maou
Live! SFX Kit 2	SFX 1	Dog	Horse	Bird Tweet	
		Phone Call 2	Telephone Ring 2	Wind Chime	
		Door Squeak 2	Door Slam 2	Scratch Cut	Scratch Split
		Laugh	Scream 2	Punch 2	Heart Beat
	SFX 2	Foot Steps 2			
		CarEngn Ignition	Car Tires Squeal	Car Passing	Car Crash
		Siren 2	Train 2	Jet Plane 2	Starship
		Burst	Roller Coaster	Submarine	
		Machine Gun 2	Laser Gun 2	Explosion 2	Firework

Kit Name	Category	Percussion name (Voice name)			
Noise Kit	NOISE	White Noise	WhiteNoiseDown 1	WhiteNoiseDown 2	
		White Noise Up 1	White Noise Up 2	WhiteNoiseUp Rel	WhiteNoiseUp LFO
		Pink Noise	PinkNoise Down 1	PinkNoise Down 2	
		Pink Noise Up	PinkNoise Up Rel	PinkNoise Up LFO	
VocalEffects Kit	FEMALE 1	Female Bh 1	Female Bh 2	Female Bh 3	Female Bh 4
		Female Ha 1	Female Ha 2		
		Female Kh 1	Female Kh 2	Female Kh 3	Female Kh 4
		Female Ph 1	Female Ph 2	Female Ph 3	Female Ph 4
	FEMALE 2	Female Th 1	Female Th 2	Female Th 3	Female Th 4
	MALE 1	Male Bh 1	Male Bh 2	Male Bh 3	Male Bh 4
		Male Ha 1	Male Ha 2	Male Ha 3	Male Ha 4
		Male Ha 5	Male Ha 6		
		Male Kh 1	Male Kh 2	Male Kh 3	Male Kh 4
	MALE 2	Male Ph 1	Male Ph 2	Male Ph 3	Male Ph 4
		Male Th 1	Male Th 2	Male Th 3	Male Th 4
GospelAdLibs	GOSPEL-ADLIBS 1	Aaoh	Aha!	Heeey	Hoo!
		Oh Yeah	Uhh Yeah	Yayayayayah	Yeah!
		C'mon	C'mon Now	Come On!	Alright Now!
		Everybody Now	Put Your Hands...	Stand Up On...	WithAllYourSoul
	GOSPEL-ADLIBS 2	One	Two	Three	Four
		One!	Two!	Three!	Four!
		Five!	Six!	Seven!	Eight!
		Clap!	ClapYourHands...	Gospel Clap 1	Gospel Clap 2
Wonderland Kit	SE	Laser Beam	Laser Shot		
		Water Phone	Bubble	Puddle	
	NATURE	Thunder	Shower	Beach	Stream
	DAILY	Footsteps	Door Squeak	Door Slam	Alarm Bell
		Cuckoo Clock	Big Clock	Bell	Telephone
		Camera	Gnaw	Applause	
	VEHICLE	Train	Horn 1	Horn 2	Siren
		CarEngn Ignition	Car Crash	Helicopter	Starship
	ANIMAL	Sheep	Goat	Cow	Whinny
		Hoofbeats	Lion	Dog	Cat
		Hen	Owl	Insects	Frog
		Tweet 1	Tweet 2		
	PERCUSSION 1	Cymbal	Snare	Snare Roll	
		Hi-Hat Open	Hi-Hat Closed		
		Tom 1	Tom 2	Bass Drum	Gran Cassa
	PERCUSSION 2	Tambourine	Castanet	Jingle Bells	Bell Tree
		Triangle Open	Triangle Mute	Wood Block H	Wood Block L
		Finger Snap	Hand Clap		
Pop Latin Kit 1	CONGA	Conga H Tip	Conga H Heel	Conga H Open	Conga H Mute
		Conga H SlapOpen	Conga H Slap	Conga H SlapMute	
		Conga L Tip	Conga L Heel	Conga L Open	Conga L Mute
		Conga L SlapOpen	Conga L Slap	Conga L Slide	
	BONGO	Bongo H Open 1 f	Bongo H Open 3 f	Bongo H Rim	
		Bongo H Tip	Bongo H Heel	Bongo H Slap	
		Bongo L Open 1 f	Bongo L Open 3 f	Bongo L Rim	
		Bongo L Tip	Bongo L Heel	Bongo L Slap	
	PERCUSSION 1	Timbale H	Timbale L	Paila H	Paila L
		Cowbell Top	Cowbell 1	Cowbell 2	Cowbell 3
		Cowbell High 1	Cowbell High 2	Claves High	Claves Low
		Guiro Long	Guiro Short	MetalGuiro Long	MetalGuiro Short
	PERCUSSION 2	Maracas	Cuica Open	Cuica Mute	
		Cabasa	Shaker		
		Tambourine	Tamborim Tip	Tamborim Open	Tamborim Mute
		Castanet	Triangle Open	Triangle Mute	Wind Chimes
	PERCUSSION 3	Hand Clap	Finger Snap	Shekere	Shekere Tone
		Cajon Low	Cajon Slap	Cajon Tip	

Kit Name	Category	Percussion name (Voice name)			
Arabic Kit	ARABIC 1	Nakarazan Dom	Nakarazan Edge	Hager Dom	Hager Edge
		Zagrouda H	Zagrouda L	Arabic Hand Clap	
		Duhulla Dom	Duhulla Tak	Duhulla Sak	
		Doff Dom	Doff Tak		
	ARABIC 2	Katem Dom	Katem Tak	Katem Sak	
		Tabla Dom	Tabla Tak 1	Tabla Tak 2	Tabla Sak
		Tabla Tik	Tabla Roll Edge	Tabla Flam	
		Tabel Dom	Tabel Tak		
	ARABIC 3	Sagat 1	Sagat 2	Sagat 3	
		Riq Dom	Riq Tak 1	Riq Tak 2	Riq Sak
		Riq Tik	Riq Finger 1	Riq Finger 2	Riq BrassTremolo
	CYMBAL/SNARE DRUM	Crash Cymbal 1	Crash Cymbal 2	Ride Cymbal 1	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
		Snare Drum	Snare Soft	Side Stick	
	TOM/BASS DRUM	Floor Tom L	Floor Tom H	Low Tom	
		Mid Tom L	Mid Tom H	High Tom	Kick Soft
	PERCUSSION	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L		
		Cowbell	Claves	Cabasa	
		Tambourine			
Turkish Kit	CYMBAL	Zil Right Open	Zil Right Close		
		Zil Left Open	Zil Left Close		
	BONGO	Bongo Tek	Bongo Tek Roll	Bongo Tek Flam	Bongo Dum
		Bongo Slap	Bongo Flam	Bongo Flam Hi	
	DAVUL	Asma Davul L	Asma Davul R	Asma Davul Side	Asma Davul Both
		KoltukDavul Teke	Koltuk Davul Tek	Koltuk Davul Dum	KoltukDavul Flam
	DARABUKA 1	Darbuka Tek 1	Darbuka Tek 2	Darbuka Tek Dead	DarbukaTekDamped
		DarbukaTekeFin 1	DarbukaTekeFin 2	DarbukaTekeFin 3	DarbukaTekeFin 4
		Darbuka Teke	DarbukaTekeFlamD	Darbuka TekeFlam	Darbuka Slap
		Darbuka Slap Med	Darbuka RollOpen	DarbukaRollClose	Darbuka Dum
	DARABUKA 2	Bass Darbuka Tek	BDarbuka TekDead	BDarbuka TekFlam	
		BassDarbuka Teke	BDarbukaTekeFin1	BDarbukaTekeFin2	
		BassDarbukaSlap1	BassDarbukaSlap2		
		Bass Darbuka Dum			
	BENDIR	Bendir Tek	Bendir Tek Dead		
		Bendir Teke	Bendir Teke Flam	Bendir Teke Dead	
		Bendir Slap			
		Bendir Dum			
	TEF	Tef Tek Flam	Tef Tek Open	Tef Tek Mute	TefTekMuteMedium
		Tef Tek Op Short	Tef Teke Flam	Tef Teke Damped	Tef Teke OpShort
		Tef Dum Open	Tef Dum Mute	Tef Cymbal	Tef Cymbal Mute
		Tef Shake 1	Tef Shake 2	Tef Full Open	Tef Tremolo
	PERCUSSION	Hollo FingerDead	Hollo Slap	Hollo Dum	
		Kasik	Kasik Flam		
Chinese Kit	CYMBAL	Da Cha 1	Da Cha 2	Da Cha Effect	Zhong Cha
		Xiao Cha	Xiao Cha Effect	Gong Batter	Luo Big
		Luo	Luo Mid-Low	Luo High 1	Luo High 2
		Jin Luo	Jin Luo Low	Mang Luo Low	Mang Luo Mid
	DRUM	Da Gu f	Da Gu mp		
		Da Gu Rim	Da Gu Roll	Da Gu Hand	
		Pai Gu 1	Pai Gu 2 High	Pai Gu 2	
		Pai Gu 3 High	Pai Gu 3	Pai Gu 4 High	Pai Gu 4
	GONG 1	Yun Luo F	Yun Luo F#	Yun Luo G	Yun Luo G#
		Yun Luo A	Yun Luo A#	Yun Luo B	Yun Luo C
		Yun Luo C#	Yun Luo D	Yun Luo D#	Yun Luo E
		Yun Luo High F	Yun Luo High F#	Yun Luo High G	Yun Luo High G#
	GONG 2	Yun Luo High A	Yun Luo High A#	Yun Luo High B	Yun Luo High C
	PERCUSSION	Mu Yu Low	Mu Yu Mid-Low	Mu Yu Mid	Mu Yu High
		Ban	Ban Gu	Ban Gu Roll	
		Nan Bang Zi	Nan Bang Zi Roll	Qing	Finger Bell
		ChineseOperaVo 1	ChineseOperaVo 2	ChineseOperaVo 3	

Kit Name	Category	Percussion name (Voice name)			
Orchestra Perc	CYMBAL	China Cymbal	Finger Cymbal		
		Orch Cymbal 1	OrchCymbal 1 ckd	Orch Cymbal 2	
		Ride Cymbal Tip	Ride Cymbal Cup	Splash Cymbal	
		Sus Cymbal 1	Sus Cym 1 Roll S	Sus Cymbal 2	Sus Cym 2 Roll L
	SNARE DRUM	ConcertSnareDrum	Snare Drum Light	Snare Ensemble	Snare Roll
	TOM	Concert Tom 1	Concert Tom 2	Concert Tom 3	Concert Tom 4
		Concert Tom 5			
		Rotating Tom 1	Rotating Tom 2	Rotating Tom 3	Rotating Tom 4
		Rotating Tom 5			
	BASS DRUM	Gran Cassa Hard	Gran Cassa Soft	Gran Cassa Hit	Gran Cassa Cresc
	GONG	Gong			
		Symphonic Gong 1	Symphonic Gong 2		
		Symphonic Gong L			
	TIMPANI	Timpani E	Timpani F	Timpani F#	Timpani G
		Timpani G#	Timpani A	Timpani A#	Timpani B
		Timpani C	Timpani C#	Timpani D	Timpani D#
		Timpani High E			
	PERCUSSION 1	Conga H Stick	Conga L Stick	Bongo H Stick	Bongo L Stick
		Cowbell	Claves	Bell Tree	Sleigh Bells
		Tubular Bell H	Tubular Bell M	Tubular Bell L	Wind Chimes
		Jingle Ring	Tambourine	Castanet Roll	Table Castanet
	PERCUSSION 2	Triangle Open	Triangle Mute	Triangle Roll	
		Wood Block H	Wood Block L	Temple Block H	Temple Block L
		Anvil	Whip		
Ambi Pop Drums	CYMBAL	Crash 1 PD	Crash 2 PD	Splash Cymbal PD	China Cymbal PD
		Ride Tip 1 PD	Ride Tip 2 PD	Ride Cup PD	
	HI-HAT	Hat Edge 00 PD	Hat Edge 10 PD	Hat Edge 25 PD	Hat Edge 50 PD
		Hat Edge 75 PD	Hat Edge 99 PD		
		Hat Tip 00 PD	Hat Tip 10 PD		
		Hat Pdl Close PD	Hat Pdl Splash		
	SNARE DRUM	Snare 1 PD	Snare 2 PD	Snare 3 PD	Snare 4 PD
		Snare 1 OpRim PD	Snare 2 noRim PD	Snare 3 noRim PD	Snare 4 noRim PD
		SB Mt Off Ed Prs	Snare Roll PD	Snare 1 Stick PD	
	TOM	Tom 1 PD	Tom 2 PD	Tom 3 PD	Tom 4 PD
		Tom 5 PD	Tom 6 PD		
	BASS DRUM	Kick 1 PD	Kick 2 PD	Kick 3 PD	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L	Timbale H	Timbale L
		Cowbell 1 JB	Claves	Guiro Long	Guiro Short
		Maracas	Vibraslap		
	PERCUSSION 2	Cuica Mute	Cuica Open	Cabasa	Shaker
		Agogo H	Agogo L	Samba Whistle H	Samba Whistle L
		Wood Block H	Wood Block L	Tambourine	
	PERCUSSION 3	Triangle Open	Triangle Mute	Jingle Bells	Wind Chimes
		Stick Count VO	Clap Power		
		Seq Click H	Seq Click L		
Ambi Rock Drums	CYMBAL	Crash 1 RD	Crash 2 RD	Splash Cymbal RD	China Cymbal RD
		Ride Tip 1 RD	Ride Tip 2 PD	Ride Cup RD	
	HI-HAT	Hat Edge 00 RD	Hat Edge 10 RD	Hat Edge 25 RD	Hat Edge 50 RD
		Hat Edge 75 RD	Hat Edge 99 RD		
		Hat Tip 00 RD	Hat Tip 10 RD		
		Hat Pdl Close RD	Hat Pdl Splash		
	SNARE DRUM	Snare 1 RD	Snare 2 RD	Snare 3 RD	Snare 4 RD
		Snare 1 OpRim RD	Snare 2 noRim RD	Snare 3 noRim RD	Snare 4 noRim RD
		SB Mt Off Ed Prs	Snare Roll RD	Snare 1 Stick RD	
	TOM	Tom 1 RD	Tom 2 RD	Tom 3 RD	Tom 4 RD
		Tom 5 RD	Tom 6 RD		
	BASS DRUM	Kick 1 RD	Kick 2 RD	Kick 3 RD	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L	Timbale H	Timbale L
		Cowbell RD	Claves	Guiro Long	Guiro Short
		Maracas	Vibraslap		
	PERCUSSION 2	Cuica Mute	Cuica Open	Cabasa	Shaker
		Agogo H	Agogo L	Samba Whistle H	Samba Whistle L
		Wood Block H	Wood Block L	Tambourine	

Kit Name	Category	Percussion name (Voice name)			
Ambi Rock Drums	PERCUSSION 3	Triangle Open	Triangle Mute	Jingle Bells	Wind Chimes
		Stick Count VO	Clap Power		
		Seq Click H	Seq Click L		
Ambi VintageOpen	CYMBAL	Crash 1 VO	Crash 2 VO	Splash Cymbal PD	China Cymbal PD
		Ride Tip 1 VO	Ride Tip 2 PD	Ride Cup VO	
	HI-HAT	Hat Edge 00 VO	Hat Edge 10 VO	Hat Edge 25 VO	Hat Edge 50 VO
		Hat Edge 75 VO	Hat Edge 99 VO		
		Hat Tip 00 VO	Hat Tip 10 VO		
		Hat Pdl Close VO	Hat Pdl Splash		
	SNARE DRUM	Snare 1 VO	Snare 2 VO	Snare 3 VO	Snare 4 VO
		Snare 1 OpRim VO	Snare 2 noRim VO	Snare 3 noRim VO	Snare 4 noRim VO
		Snare Roll PD	Snare 1 Stick VO		
	TOM	Tom 1 VO	Tom 2 VO	Tom 3 VO	Tom 4 VO
		Tom 5 VO	Tom 6 VO		
	BASS DRUM	Kick 1 VO	Kick 2 VO	Kick 3 VO	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L	Timbale H	Timbale L
		Cowbell 1 JB	Claves	Guiro Long	Guiro Short
		Maracas	Vibraslap		
	PERCUSSION 2	Cuica Mute	Cuica Open	Cabasa	Shaker
		Agogo H	Agogo L	Samba Whistle H	Samba Whistle L
		Wood Block H	Wood Block L	Tambourine	Tambourine Stick
	PERCUSSION 3	Triangle Open	Triangle Mute	Jingle Bells	Wind Chimes
		Stick Count VO	Clap Power		
		Seq Click H	Seq Click L		
Ambi VintageMute	CYMBAL	Crash 1 VM	Crash 2 VM	Splash Cymbal PD	China Cymbal PD
		Ride Real	Ride Tip VM	Ride Cup VM	
	HI-HAT	Hat Edge 00 VM	Hat Edge 10 VM	Hat Edge 25 VM	Hat Edge 50 VM
		Hat Edge 75 VM	Hat Edge 99 VM		
		Hat Tip 00 VM	Hat Tip 10 VM		
		Hat Pdl Close VM	Hat Pdl Splash		
	SNARE DRUM	Snare 1 VM	Snare 2 VM	Snare 3 VM	Snare 4 VM
		Snare 1 OpRim VM	Snare 2 noRim VM	Snare 3 noRim VM	Snare 4 noRim VM
		Snare Roll PD	Snare 1 Stick VM		
	TOM	Tom 1 VM	Tom 2 VM	Tom 3 VM	Tom 4 VM
		Tom 5 VM	Tom 6 VM		
	BASS DRUM	Kick 1 VM	Kick 2 VM	Kick 3 VM	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L	Timbale H	Timbale L
		Cowbell 1 JB	Claves	Guiro Long	Guiro Short
		Maracas	Vibraslap		
	PERCUSSION 2	Cuica Mute	Cuica Open	Cabasa	Shaker
		Agogo H	Agogo L	Samba Whistle H	Samba Whistle L
		Wood Block H	Wood Block L	Tambourine	Tambourine Stick
	PERCUSSION 3	Triangle Open	Triangle Mute	Jingle Bells	Wind Chimes
		Stick Count VM	Clap Power		
		Seq Click H	Seq Click L		
Ambi Jazz Stick	CYMBAL	Crash 1 JS	Crash 2 JS	Splash Cymbal JS	China Cymbal PD
		Ride Tip 1 JS	Ride Tip 2 PD	Ride Cup JS	
	HI-HAT	Hat Edge 00 JS	Hat Edge 10 JS	Hat Edge 25 JS	Hat Edge 50 JS
		Hat Edge 75 JS	Hat Edge 99 JS		
		Hat Tip 00 JS	Hat Tip 10 JS		
		Hat Pdl Close JS	Hat Pdl Splash		
	SNARE DRUM	Snare 1 JS	Snare 3 JS	Snare 2 OpRim JS	Snare 2 Off JS
		Snare 1 noRim JS	Snare 3 noRim JS	Snare 2 noRim JS	SD2 noRim Off JS
		Snare Roll JS	Snare 2 Stick JS	Snare Off Stk JS	
	TOM	Tom 1 JS	Tom 2 JS	Tom 3 JS	Tom 4 JS
		Tom 5 JS	Tom 6 JS		
	BASS DRUM	Kick 1 JS	Kick 2 JS	Kick 3 VM	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L	Timbale H	Timbale L
		Cowbell 1 JB	Cowbell 2 JB	Cowbell 1 Tip JB	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Cuica Mute	Cuica Open	Cabasa	Shaker
		Samba Whistle H	Samba Whistle L	Wood Block H	Wood Block L
		Tambourine			

Kit Name	Category	Percussion name (Voice name)			
Ambi Jazz Stick	PERCUSSION 3	Triangle Open	Triangle Mute	Jingle Bells	Wind Chimes
		Stick Count VO	Clap Power		
		Seq Click H	Seq Click L		
Ambi Jazz Brush	CYMBAL	Crash 1 JB	Crash 2 JB	Splash Cymbal JB	China Cymbal RB
		Ride Tip JB	Ride Cup JB	Ride Backend JB	
	HI-HAT	Hat Edge 75 JB	Hat Center 00 JB	Hat Pdl Close JB	
	SNARE DRUM	SB Pressed	SB Prs Low Range	SB Off Ed Prs	
		SB with Shaft	SB Mute Shaft	SB Mt only Shaft	SB Op Cntr Sh JB
		SB Swirl 1 Atk	SB Swirl 2 Atk	SB Lin Sweep Ln	SB Lin Sweep Sh
		SB Dyn Sweep	SB Swirl Loop 1	Snare 2 Stick JS	
	TOM	Tom 1 JB	Tom 2 JB	Tom 3 JB	Tom 4 JB
		Tom 5 JB	Tom 6 JB		
	BASS DRUM	Kick 1 JB	Kick 2 JB	Kick 3 VM	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L	Timbale H	Timbale L
		Cowbell 1 JB	Claves	Guiro Long	Guiro Short
		Maracas	Vibraslap		
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L	Wood Block H	Wood Block L
		Tambourine	Whip Slap		
	PERCUSSION 3	Triangle Open	Triangle Mute	Jingle Bells	Wind Chimes
		Stick Count VO	Clap Power	Finger Snap	
		Hi Q	Click Noise	Scratch H	Scratch L
		Metronome Bell	Metronome Click		
Ambi JazzBrushEx	CYMBAL	Crash 1 JB	Crash 2 JB	Crash 1 JS	
		Splash Cymbal JB	Splash Cymbal JS	China Cymbal RB	China Cymbal PD
		Ride Tip JB	Ride Tip JS	Ride Cup JB	Ride Cup JS
		Ride Backend JB			
	HI-HAT	Hat Edge 00 JB	Hat Edge 10 JB	Hat Edge 25 JB	Hat Edge 50 JB
		Hat Edge 75 JB	Hat Edge 99 JB		
		Hat Edge 00 JS	Hat Edge 50 JS	Hat Edge 99 JS	
		Hat Center 00 JB	Hat Center 10 JB	Hat Pdl Close JB	Hat Pdl Splash
	SNARE BRUSH 1	SB Swirl Loop 1	SB Swirl Loop 2	SB Swish L	SB Swish R
		SB Lin Swp Ln L	SB Lin Swp Ln R	SB Lin Swp Sh L	SB Lin Swp Sh R
		SB Dyn Sweep Ln	SB Dyn Sweep Md	SB Dyn Sweep Sh	
	SNARE BRUSH 2	SB Pressed	SB with Shaft	SB Mute Shaft	SB Op Cntr Sh JB
		SB Off Prs	SB Mt Off Prs	SB Off Ed Prs	SB Mt Off Ed Prs
		SB Snappy Off	SB Mt Snappy Off	SB Off Edge	SB Mt Off Edge
		SB Roll			
	SNARE DRUM	Snare 2 noRim JS	Snare 2 Off JS	Snare 2 Stick JS	Snare Off Stk JS
	TOM	Tom 1 JB	Tom 2 JB	Tom 3 JB	Tom 4 JB
		Tom 5 JB	Tom 6 JB		
		Tom 1 JS	Tom 2 JS	Tom 3 JS	Tom 4 JS
		Tom 5 JS	Tom 6 JS		
	BASS DRUM	Kick 1 JB	Kick 2 JB	Kick 2 JS	Kick 3 JB
		Kick 3 VM			
	PERCUSSION	Cowbell 1 JB	Cowbell 1 Tip JB	Shaker	Tambourine
		Stick Count VO	Clap Power	Clap AF	

Kit Name	Category	Percussion name (Voice name)			
Ambi Production	CYMBAL	Crash 1 PF	Crash 2 PF	Splash Cymbal PF	China Cymbal PD
		Ride Tip PF	Ride Tip 2 PD	Ride Cup PF	
	HI-HAT	Hat Edge 00 PF	Hat Edge 10 PF	Hat Edge 25 PF	Hat Edge 50 PF
		Hat Edge 75 PF	Hat Edge 99 PF		
		Hat Tip 00 PF	Hat Tip 10 PF		
		Hat Pdl Close PF	Hat Pedal Splash		
	SNARE DRUM	Snare 1 PF	Snare 2 PF	Snare 3 PF	Snare 4 PF
		Snare 3 noRim PF	Snare 4 noRim PD	Snare 5 noRim PF	Snare 5 OpRim PF
		SB Op Cntr Sh JB	Snare Roll PF	Side-Stick PF	
	TOM	Tom 1 PF	Tom 2 PF	Tom 3 PF	Tom 4 PF
		Tom 5 PF	Tom 6 PF		
	BASS DRUM	Kick 1 PF	Kick 2 PF	Kick 3 PF	Kick 4 PF
		Kick 5 PF	Kick 6 PF	Kick 7 PF	Kick 8 PF
		Kick 9 PF	Kick 10 PF	Kick 11 PF	Kick 12 PF
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L	Timbale H	Timbale L
		Cowbell 1 JB	Cowbell 2 JB	Cowbell 1 Tip JB	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Cuica Mute	Cuica Open	Cabasa	Shaker
		Samba Whistle H	Samba Whistle L	Wood Block H	Wood Block L
		Tambourine			
	PERCUSSION 3	Triangle Open	Triangle Mute	Jingle Bells	Wind Chimes
		Stick Count VO	Clap Power		
		Seq Click H	Seq Click L		
Ambi Dirty Kit	CYMBAL	Crash 1 DK	Crash 2 DK	Splash Cymbal DK	China Cymbal DK
		Ride Tip DK	Ride Tip 2 PD	Ride Cup DK	
	HI-HAT	Hat Edge 00 DK	Hat Edge 10 DK	Hat Edge 25 DK	Hat Edge 50 DK
		Hat Edge 75 DK	Hat Edge 99 DK		
		Hat Tip 00 DK	Hat Tip 10 DK		
		Hat Pdl Close DK	Hat Pedal Splash		
	SNARE DRUM	Snare 1 DK	Snare 2 DK	Snare 3 DK	Snare 4 DK
		Snare 5 DK	Snare 1	Snare 1 noRim DK	Snare 3 OpRim DK
		SB Op Cntr Sh JB	Snare Roll DK	Side-Stick DK	
	TOM	Tom 1 DK	Tom 2 DK	Tom 3 DK	Tom 4 DK
		Tom 5 DK	Tom 6 DK		
	BASS DRUM	Kick 1 DK	Kick 2 DK	Kick 3 DK	Kick 4 DK
		Kick 5 DK	Kick 6 DK	Kick 7 DK	Kick 8 DK
		Kick 9 DK	Kick 10 DK	Kick 11 DK	Kick 12 DK
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L	Timbale H	Timbale L
		Cowbell DK	Cowbell 1 JB	Cowbell 1 Tip JB	Claves
		Guiro Long	Guiro Short	Maracas	Vibraslap
	PERCUSSION 2	Cuica Open	Cuica Mute	Cabasa	Shaker
		Samba Whistle H	Samba Whistle L	Wood Block H	Wood Block L
		Tambourine DK			
	PERCUSSION 3	Triangle Open	Triangle Mute	Jingle Bells	Wind Chimes
		Stick Count DK	Clap Power		
		Seq Click H	Seq Click L		

Kit Name	Category	Percussion name (Voice name)			
Ambi Symphonic	CYMBAL	Hand Cymbal 1	Hand Cymbal 1 S	Hand Cymbal 2	Hand Cymbal 2 S
		Splash Cymbal	China Cymbal	Ride Cymbal Cup	
		Hi-Hat Open	Hi-Hat Closed	Hi-Hat Pedal	
	SNARE DRUM	Band Snare 1	Band Snare 2	Snare Soft	Open Rim Shot
		Snare Roll	Side Stick		
		Brush Slap	Brush Tap	Brush Swirl	Brush Tap Swirl
	TOM	High Tom	Mid Tom H	Mid Tom L	Low Tom
		Floor Tom H	Floor Tom L		
	BASS DRUM	Kick Soft	Gran Cassa	Gran Cassa Mute	
	PERCUSSION 1	Conga H Open	Conga L	Conga H Mute	
		Bongo H	Bongo L	Timbale H	Timbale L
		Cowbell	Claves	Guiro Long	Guiro Short
		Maracas	Vibraslap		
	PERCUSSION 2	Surdo Mute	Surdo Open	Cuica Mute	Cuica Open
		Cabasa	Shaker	Agogo H	Agogo L
		Samba Whistle H	Samba Whistle L	Wood Block H	Wood Block L
		Tambourine	Castanet	Whip Slap	
	PERCUSSION 3	Triangle Open	Triangle Mute	Sleigh Bells	Wind Chimes
		Sticks	Hand Clap	Finger Snap	
		Hi Q	Click Noise	Scratch H	Scratch L
		Seq Click H	Seq Click L	Metronome Bell	Metronome Click
Revo Tight EDM	CYMBAL	Crash 1 TEDM	Crash 2 TEDM	Crash 3 TEDM	Crash 4 TEDM
		Crash 5 TEDM	Crash 6 TEDM	Ride TEDM	
	HI-HAT	Hat Open 1 TEDM	Hat Open 2 TEDM	Hat Open 3 TEDM	Hat Open 4 TEDM
		Hat Open 5 TEDM	Hat Close 1 TEDM	Hat Close 2 TEDM	Hat Close 3 TEDM
		Hat Close 4 TEDM	Hat Close 5 TEDM	Hat Close 6 TEDM	Hat Close 7 TEDM
		Hat Close 8 TEDM	Hat Pedal TEDM		
	SNARE DRUM	Snare 1 TEDM	Snare 2 TEDM	Snare 3 TEDM	Snare 4 TEDM
		Snare 5 TEDM	Snare 6 TEDM	Snare 7 TEDM	
	TOM	Tom 1 TEDM	Tom 2 TEDM	Tom 3 TEDM	Tom 4 TEDM
		Tom 5 TEDM	Tom 6 TEDM	Tom 7 TEDM	Tom 8 TEDM
		Tom 9 TEDM	Tom 10 TEDM	Tom 11 TEDM	
	BASS DRUM	Kick 1 TEDM	Kick 2 TEDM	Kick 3 TEDM	Kick 4 TEDM
		Kick 5 TEDM			
	VOICE	Voice 1 TEDM	Voice 2 TEDM	Voice 3 TEDM	Voice 4 TEDM
		Voice 5 TEDM	Voice 6 TEDM	Voice 7 TEDM	Voice 8 TEDM
		Voice 9 TEDM	Voice 10 TEDM	Voice 11 TEDM	Voice 12 TEDM
	PERCUSSION	Clap 1 TEDM	Clap 2 TEDM	Clap 3 TEDM	Clap 4 TEDM
		Clap 5 TEDM	Clap 6 TEDM	Clap 7 TEDM	
		Cowbell TEDM	Shaker TEDM	Clock TEDM	Click TEDM
		Reverse 1 TEDM	Reverse 2 TEDM	Impact TEDM	
	SE	SE 1 TEDM	SE 2 TEDM	SE 3 TEDM	SE 4 TEDM
		SE 5 TEDM	SE 6 TEDM	SE 7 TEDM	SE 8 TEDM
		SE 9 TEDM	Sub SE 1 TEDM	Sub SE 2 TEDM	
		SideChain 1 TEDM	SideChain 2 TEDM		
EDM Kit	CYMBAL	Crash Cymbal T9	Crash Cymbal 2	Crash Cymbal 4	Splash Cymbal 2
		Ride Cymbal 3	Ride Cup 2	Ride Shank EDM	
	HI-HAT	Hat Open 1 EDM	Hat Open 2 EDM	Hat Shank EDM	
		Hat Close 1 EDM	Hat Close 2 EDM	Hat Close 3 EDM	Hat Close 4 EDM
	SNARE DRUM	Snare 1 EDM	Snare 2 EDM	Snare 3 EDM	Snare 4 EDM
		Snare 5 EDM	Snare 6 EDM	Snare 7 EDM	Snare 8 EDM
		Snare 9 EDM	Snare 10 EDM	Snare 11 EDM	Snare 12 EDM
		Snare 13 EDM	Snare 14 EDM	Snare 15 EDM	Fill Snare EDM
	TOM	Tom B1 80P	Tom B2 80P	Tom B3 80P	Tom B4 80P
		Tom B5 80P	Tom B6 80P	Fill Tom EDM	
	BASS DRUM	Kick 1 EDM	Kick 2 EDM	Kick 3 EDM	Kick 4 EDM
		Kick 5 EDM	Kick 6 EDM	Kick 7 EDM	Kick 8 EDM
		Kick 9 EDM	Kick 10 EDM		
	PERCUSSION 1	Conga H Open 2	Conga H SlapOpen	Conga H Tip	Tambourine Hit
		Bongo H Open 1F	Bongo L Open 3F	Timbale H	Timbale L
		Cowbell 1	Claves	Guiro Long	Guiro Short
		Maracas Slur	Cabasa	Agogo H	Agogo L
	PERCUSSION 2	Glitch 1 EDM	Glitch 2 EDM	Glitch 3 EDM	Bump EDM
		Clap 1 EDM	Clap 2 EDM	Clap 3 EDM	Thump EDM
		Rev Hit EDM	Rev Shot EDM	Impact Hi EDM	Impact Lo EDM
		Vox Drum H	Vox Drum L	Cowbell T8	White Noise Up

Kit Name	Category	Percussion name (Voice name)			
Punchy EDM Kit	CYMBAL	Crash 1 PE	Crash 2 PE	Crash 3 PE	
		Ride 1 PE	Ride 2 PE		
	HI-HAT	Hat Open PE			
		Hat Close 1 PE	Hat Close 2 PE	Hat Close 3 PE	Hat Close 4 PE
		Hat Close 5 PE	Hat Close 6 PE	Hat Close 7 PE	Hat Close 8 PE
		Hat Close 9 PE	Hat Close 10 PE		
	SNARE DRUM 1	Snare 1 PE	Snare 2 PE	Snare 3 PE	Snare 4 PE
		Snare 5 PE	Snare 6 PE	Snare 7 PE	Snare 8 PE
		Snare 9 PE	Snare 10 PE	Snare 11 PE	Snare 12 PE
		Snare 13 PE	Snare 14 PE	Snare 15 PE	Snare 16 PE
	SNARE DRUM 2	Snare 17 PE	Snare 18 PE	Snare 19 PE	Snare 20 PE
		Snare 21 PE	Snare 22 PE	Snare 23 PE	Snare 24 PE
		Snare 25 PE	Snare 26 PE	Snare 27 PE	Snare 28 PE
		Snare 29 PE	Snare 30 PE	Snare 31 PE	Snare 32 PE
	SNARE DRUM 3	Side-Stick 1 PE	Side-Stick 2 PE	Side-Stick 3 PE	
		Clap+Snare PE	Brush Snare PE		
	TOM	Tom 1 PE	Tom 2 PE	Tom 3 PE	
		Tom 4 PE	Tom 5 PE	Tom 6 PE	Tom 7 PE
		Tom 8 PE	Tom 9 PE	Tom 10 PE	Tom 11 PE
		Tom 12 PE	Tom 13 PE	Tom 14 PE	
	BASS DRUM	Kick 1 PE	Kick 2 PE	Kick 3 PE	Kick 4 PE
		Kick 5 PE	Kick 6 PE	Kick 7 PE	Kick 8 PE
		Kick 9 PE	Kick 10 PE	Kick 11 PE	Kick 12 PE
		Kick 13 PE	Kick 14 PE	Kick 15 PE	Kick 16 PE
	PERCUSSION 1	Shaker 1 PE	Shaker 2 PE	Shaker 3 PE	
		Wood Block PE	Tambourine PE		
		Snap 1 PE	Snap 2 PE	Snap 3 PE	
		Clap 1 PE	Clap 2 PE	Clap 3 PE	Clap 4 PE
	PERCUSSION 2	Click 1 PE	Click 2 PE	Click 3 PE	Click 4 PE
		Sine Drop 1	Sine Drop 2		
		Impact 1 PE	Impact 2 PE	Impact 3 PE	
	SLICE	Slice 1 PE	Slice 2 PE	Slice 3 PE	Slice 4 PE
		Slice 5 PE	Slice 6 PE	Slice 7 PE	Slice 8 PE
		Slice 9 PE	Slice 10 PE	Slice 11 PE	Slice 12 PE
		Slice 13 PE	Slice 14 PE		
	LOOP	Loop Hi-Hat PE	Loop Snare PE	Loop Kick PE	
	NOISE	Noise Crash 1 PE	Noise Crash 2 PE	Noise Sweep PE	
		Noise Build 1 PE	Noise Build 2 PE	Noise Build 3 PE	Noise Build 4 PE
Electro Kit 2	CYMBAL	Crash Cymbal T9	Crash Cymbal 2	Crash Cymbal 4	Splash Cymbal 2
		Ride Cymbal T9	Ride Cymbal 3	Ride Cup 2	
	HI-HAT	Hat Open 1 EK	Hat Open 2 EK	Hat Open 3 EK	Hat Open 4 EK
		Hat Close 1 EK	Hat Close 2 EK		
	SNARE DRUM	Snare 1 EK	Snare 2 EK	Snare 3 EK	Snare 4 EK
		Snare 5 EK	Snare 6 EK	Snare 7 EK	Snare 8 EK
		Snare 9 EK	Snare 10 EK	Snare 11 EK	Snare T9 1
		Rim Shot EK			
	TOM	Tom 1 EK	Tom 2 EK	Tom 3 EK	Tom 4 EK
		Tom 5 EK	Tom 6 EK		
	BASS DRUM	Kick 1 EK	Kick 2 EK	Kick 3 EK	Kick 4 EK
		Kick 5 EK	Kick 6 EK	Kick 7 EK	Kick 8 EK
		Kick 9 EK	Kick 10 EK	Kick 11 EK	Kick 12 EK
		Filter Kick			
	PERCUSSION 1	Conga H 80R	Conga L 80R	Conga Mute 80R	
		Bongo H 80R	Bongo L 80R	Timbale H	Timbale L
		Cowbell 80R	Cowbell T8	Cabasa 80R	Cabasa 81R
		Agogo H 80R	Agogo L 80R	Tambourine 82P	
	PERCUSSION 2	Clap 1 EK	Clap 2 EK	Clap 4 EK	Clap 5 EK
		Clap 6 EK	Clap 8 EK	Vox Drum H	Vox Drum L
	SFX	SFX 1 EK	SFX 2 EK	SFX 3 EK	SFX 4 EK
		SFX 5 EK	SFX 6 EK	SFX 7 EK	SFX 8 EK
		SFX 9 EK	SFX 10 EK	SFX 11 EK	SFX 12 EK

Kit Name	Category	Percussion name (Voice name)			
Dubstep Kit	CYMBAL	Crash Cymbal T9	Crash Cymbal 2	Crash Cymbal 4	Splash Cymbal 2
		Ride Cym T9	Ride Cymbal 3	Ride Cup 2	
	HI-HAT	Hat Open 1 DS	Hat Open 2 DS		
		Hat Close 1 DS	Hat Close 2 DS	Hat Close 3 DS	
		Hat Pedal DS			
	SNARE DRUM	Snare 1 DS	Snare 2 DS	Snare 3 DS	Snare 4 DS
		Snare 5 DS	Snare 6 DS	Snare 7 DS	Snare 8 DS
		Snare 9 DS	Snare 10 DS	Snare 11 DS	Snare T9 3
		Rim Shot DS	RevFlngrSnare DS		
	TOM	Tom T9 1	Tom T9 2	Tom T9 3	Tom T9 4
		Tom T9 5	Tom T9 6		
	BASS DRUM	Kick 1 DS	Kick 2 DS	Kick 3 DS	Kick 4 DS
		Kick 5 DS	Kick 6 DS	Kick 7 DS	Kick 8 DS
		Kick 9 DS	Kick 10 DS	Filter Kick	
	PERCUSSION 1	Conga H 82P	Conga L 82P	Conga Mute 82P	Claves 83P
		Bongo H 82P	Bongo L 82P	Timbale H	Timbale L
		Cowbell T8	Cowbell H 82P	Cowbell M 82P	Cowbell L 82P
		Tin Cowbell DS	Maracas Slur	Guiro Long	Guiro Short
	PERCUSSION 2	Cabasa 81P	Tambourine 82P	Wood Block H	Wood Block L
		Triangle Open	Triangle Mute		
		Clap 1 DS	Clap 2 DS	Clap 3 DS	Clap 4 DS
	PERCUSSION 3	Digital DS	Boomer DS	Synth Scratch DS	Bouncer DS
		Vox Drum H	Vox Drum L		
	NOISE	WhiteNoiseDown 2	PinkNoise Down 1	PinkNoise Down 2	
Trap Kit 1	CYMBAL	Crash 1 NT	Crash 2 NT	Crash 3 NT	Crash 4 NT
		Ride 1 NT	Ride 2 NT		
	HI-HAT	Hat Open NT			
		Hat Close 1 NT	Hat Close 2 NT	Hat Close 3 NT	
	SNARE DRUM	Snare 1 NT	Snare 2 NT	Snare 3 NT	Snare 4 NT
		Side-Stick NT			
	TOM	Tom 1 NT	Tom 2 NT	Tom 3 NT	Tom 4 NT
		Tom 5 NT			
	BASS DRUM	Kick 1 NT	Kick 2 NT	Kick 3 NT	Kick 4 NT
		Kick 5 NT	Kick 6 NT	Kick 7 NT	Kick 8 NT
		Kick 9 NT			
	VOICE	Voice 1 NT	Voice 2 NT	Voice 3 NT	Voice 4 NT
		Voice 5 NT	Voice 6 NT	Voice 7 NT	Voice 8 NT
		Voice 9 NT	Voice 10 NT	Dab Vox 1 NT	Dab Vox 2 NT
	SNAP/CLAP	Snap 1 NT	Snap 2 NT	Snap 3 NT	Snap 4 NT
		Snap 5 NT	Snap 6 NT		
		Clap 1 NT	Clap 2 NT	Clap 3 NT	Clap 4 NT
		Clap 5 NT	Clap 6 NT	Clap 7 NT	Clap 8 NT
	PERCUSSION	Perc Pipe NT	Perc Echo NT	Perc Low NT	
		Knock NT	Strike NT	Crash FX NT	
	SE	SE 1 NT	SE 2 NT	SE 3 NT	SE 4 NT

Kit Name	Category	Percussion name (Voice name)			
Trap Kit 2	CYMBAL	Crash Cymbal T9	Crash Cymbal 2	Crash Cymbal 4	Splash Cymbal 2
		Ride Cymbal T9	Ride Cymbal 3	Ride Cup 2	
	HI-HAT	Hat Open 1 TP	Hat Open 2 TP		
		Hat Close 1 TP	Hat Close 2 TP	Hat Close 3 TP	Hat Close 4 TP
	SNARE DRUM	Snare 1 TP	Snare 2 TP	Snare 3 TP	Snare 4 TP
		Snare 5 TP	Snare 6 TP	Snare 7 TP	Snare 8 TP
		Snare 9 TP	Snare 10 TP	Snare T9 3	Rim Shot TP
	TOM	Tom 1 TP	Tom 2 TP	Tom 3 TP	Tom 4 TP
		Tom 5 TP	Tom 6 TP		
	BASS DRUM	Kick 1 TP	Kick 2 TP	Kick 4 TP	Kick 5 TP
		Kick 6 TP	Kick 7 TP	Kick 8 TP	Kick 9 TP
		Kick 10 TP	Kick 11 TP		
	SNAP/CLAP	FNS 1 TP	FNS 2 TP		
		Clap 1 TP	Clap 2 TP	Clap 3 TP	Clap 4 TP
		Clap 5 TP	Clap 1 83P		
	PERCUSSION 1	Conga H Open 2	Conga H SlapOpen	Conga H Tip	
		Bongo H Open 1F	Bongo L Open 3F	Timbale H	Timbale L
		Cowbell 1 TP	Cowbell 2 TP	Cowbell T8	Maracas Slur
		Guiro Long	Guiro Short		
	PERCUSSION 2	Agogo H	Agogo L	Cabasa	Tambourine Hit
		Wood Block H	Wood Block L	Triangle Open	Triangle Mute
		Vox Drum H	Vox Drum L		
	SFX	SFX 1 TP	SFX 2 TP	SFX 3 TP	
		WhiteNoiseDown 1	WhiteNoiseDown 2	PinkNoise Down 1	PinkNoise Down 2
Schlager Kit	CYMBAL	Crash 1 SC	Crash 2 SC	Crash 3 SC	
		Ride Acoustic 1			
	HI-HAT	Hat Open 1 SC	Hat Open 2 SC		
		Hat Close 1 SC	Hat Close 2 SC	Hat Close 3 SC	Hat Close 4 SC
		Hat Close 5 SC			
	SNARE DRUM	Snare 1 SC	Snare 2 SC	Snare 3 SC	Snare 4 SC
		Snare 5 SC	Snare 6 SC	Snare 7 SC	Snare 8 SC
		Snare 9 SC	Snare 10 SC		
		Snare 1 83P	Long Snare SC	Side Stick Power	
	TOM	Tom 1 SC	Tom 2 SC	Tom 3 SC	Tom 4 SC
		Tom 5 SC	Tom 6 SC		
	BASS DRUM	Kick 1 SC	Kick 2 SC	Kick 2 81P	Kick TB SC
	PERCUSSION 1	Shaker 1 SC	Shaker 2 SC	Shaker 3 SC	Shaker 4 SC
		Shaker 5 SC	Shaker 6 SC	Cowbell 1	Tambourine
		Clap 1 SC	Clap 2 SC	Clap 3 SC	Clap 4 SC
		Clap 5 SC	Clap 6 SC	Clap 7 SC	
	PERCUSSION 2	Echo Shot 1 SC	Echo Shot 2 SC	Echo Shot 3 SC	Echo Shot 4 SC
		Reverse 1 SC	Reverse 2 SC	Rev Snare SC	NoiseUp SC
		Impact SC	Crash Impact SC		
	LOOP 1	LpElement 1a SC	LpElement 1b SC	LpElement 1c SC	LpElement 1d SC
		LpElement 1e SC	LpElement 1f SC	LpElement 1g SC	LpElement 1h SC
		LpElement 1i SC			
	LOOP 2	LpElement 2a SC	LpElement 2b SC	LpElement 2c SC	LpElement 2d SC
		LpElement 2h SC	LpElement 2i SC		
		LpDrums Hat 1 SC	LpDrums Hat 2 SC	LpDrums Snare SC	LpDrums Kick SC

Kit Name	Category	Percussion name (Voice name)			
Club Kit	CYMBAL	Crash 1 CL	Crash 2 CL	Crash 3 CL	China Cymbal CL
		Ride 1 CL	Ride 2 CL	Ride 3 CL	
	HI-HAT	Hat Open CL	Hat Close CL	Hat Pedal CL	
	SNARE DRUM	Snare 1 CL	Snare 2 CL	Snare 3 CL	Snare 4 CL
		Snare 5 CL	Snare 6 CL	Snare 7 CL	Snare 8 CL
	TOM	Tom 1 CL	Tom 2 CL	Tom 3 CL	Tom 4 CL
		Tom 5 CL	Tom 6 CL		
	BASS DRUM	Kick 1 CL	Kick 2 CL	Kick 3 CL	Kick 4 CL
		Kick 5 CL	Kick 6 CL	Kick 7 CL	Kick 8 CL
		Kick 9 CL	Kick 10 CL	Kick 11 CL	Kick 12 CL
		Kick 13 CL	Kick 14 CL	Kick 15 CL	
	PERCUSSION 1	Tambourine 1 CL	Tambourine 2 CL	Tambourine 3 CL	Claves CL
		Wood Block CL			
		Clap 1 CL	Clap 2 CL	Clap 3 CL	Clap 4 CL
		Clap 5 CL			
	PERCUSSION 2	Percussion 1 CL	Percussion 2 CL	Percussion 3 CL	Percussion 4 CL
		Percussion 5 CL	Percussion 6 CL	Percussion 7 CL	Percussion 8 CL
		Percussion 9 CL	Percussion 10 CL		
	SE	SE 1 CL	SE 2 CL	SE 3 CL	SE 4 CL
		SE 5 CL	SE 6 CL	SE 7 CL	SE 8 CL
		SE 9 CL	SE 10 CL	SE 11 CL	SE 12 CL
		SE 13 CL	SE 14 CL		
Chill Kit	CYMBAL	Crash 1 CH	Crash 2 CH	Crash 3 CL	Splash CH
		Ride 1 CL	Ride 2 CL	Ride 3 CL	
	HI-HAT	Hat Open CH	Hat Close 1 CH	Hat Close 2 CH	
	SNARE DRUM	Snare 1 CH	Snare 2 CH	Snare 3 CH	Snare 4 CH
		Side-Stick CH			
	TOM	Tom 1 CH	Tom 2 CH	Tom 3 CH	Tom 4 CH
		Tom 5 CH	Tom 6 CH		
	BASS DRUM	Kick 1 CH	Kick 2 CH	Kick 3 CH	Kick 4 CH
		Kick 5 CH	Kick 6 CH	Kick 7 CH	Kick 8 CH
		Kick 9 CH	Kick 10 CH	Kick 11 CH	Kick 12 CH
		Kick 13 CH	Kick 14 CH	Kick 15 CH	
	VOICE	Voice 1 CH	Voice 2 CH	Voice 3 CH	
	PERCUSSION 1	Conga CH	Cowbell CH	Timbales 1 CH	Timbales 2 CH
		Claves CL	Cabasa CH	Shaker CH	Tambourine 1 CL
		Wood Block 1 CH	Wood Block 2 CH	Wood Block CL	
		Snap 1 CH	Clap 3 CL		
	PERCUSSION 2	Percussion 1 CH	Percussion 2 CH	Percussion 3 CH	Percussion 4 CH
		Percussion 5 CH	Percussion 6 CH		
		Percussion 1 CL	Percussion 2 CL	Percussion 4 CL	Percussion 8 CL
		Percussion 9 CL			
	SE	SE 1 CH	SE 2 CH	SE 3 CH	SE 4 CH
		Knock CH	Swarm CH	Turn Table CH	Granular CH
		Noise Rise CH	Sweep CH		

Kit Name	Category	Percussion name (Voice name)			
80s Pop Kit	CYMBAL	Crash 1 PD	Crash 2 PD	Splash 82P	China Cymbal 82P
		Ride 1 82P	Ride 2 82P	Ride Bell 82P	
	HI-HAT	Hat 1 Open 82P	Hat 1 Open 83P	Hat 2 Open 81P	Hat 3 Open 81P
		Hat 1 Close 82P	Hat 1 Close 83P	Hat 2 Close 81P	Hat 3 Close 81P
		Hat 1 Pedal 82P			
	SNARE DRUM	Snare 1 82P	Snare 1 83P	Snare 2 82P	Snare 2 83P
		Snare 3 81P	Snare 4 81P		
		Side Stick 1 82P	Side Stick 1 83P	Side Stick 2 81P	Side Stick 3 82P
		Side Stick 4 81P			
	TOM 1	Tom A1 81P	Tom A2 81P	Tom A3 81P	Tom A4 81P
		Tom A5 81P	Tom A6 81P		
		Tom A1 82P	Tom A2 82P	Tom A3 82P	Tom A4 82P
		Tom A5 82P	Tom A6 82P		
	TOM 2	Tom B1 80P	Tom B2 80P	Tom B3 80P	Tom B4 80P
		Tom B5 80P	Tom B6 80P		
		Tom B1 83P	Tom B2 83P	Tom B3 83P	Tom B4 83P
		Tom B5 83P			
	BASS DRUM	Kick 1 82P	Kick 1 83P	Kick 2 81P	Kick 2 83P
	PERCUSSION 1	Conga H 82P	Conga L 82P	Conga Mute 82P	
		Bongo H 82P	Bongo L 82P	Timbale H	Timbale L
		Cowbell 82P	Cowbell T8	Claves 83P	
	PERCUSSION 2	Cabasa 81P	Cabasa 82P	Agogo H 82P	Agogo L 82P
		Tambourine 82P	Jingle Bells	Wind Chimes	
		Clap 1 82P	Clap 1 83P	Clap 2 81P	Clap 3 81P
		Clap 1 P-Up 82P	Metronome 1 83P	Metronome 2 83P	
80s R&B Kit	CYMBAL	Crash 1 81R	Crash 2 81R	Crash 1 RD	Splash 80R
		China Cymbal 81R	Ride Cymbal 81R	Ride Bell 80R	
	HI-HAT	Hat 1 Open 80R	Hat 1 Open 81R	Hat 2 Open 81R	Hat 3 Open 80R
		Hat 3 Open 81R			
		Hat 1 Close 80R	Hat 1 Close 81R	Hat 2 Close 81R	Hat 3 Close 80R
		Hat 3 Close 81R	Hat 2 Pedal 81R		
	SNARE DRUM	Snare 1 80R	Snare 2 80R	Snare 3 81R	Snare 4 81R
		Side Stick 1 80R	Side Stick 2 81R	Side Stick 3 80R	Side Stick 4 80R
		Side Stick 4 81R			
	TOM 1	Tom A1 80R	Tom A2 80R	Tom A3 80R	Tom A4 80R
		Tom A5 80R	Tom A6 80R		
		Tom A1 81R	Tom A2 81R	Tom A3 81R	Tom A4 81R
		Tom A5 81R	Tom A6 81R		
	TOM 2	Tom T8 1	Tom T8 2	Tom T8 3	Tom T8 4
		Tom T8 5			
	BASS DRUM	Kick 1 80R	Kick 2 80R	Kick 2 81R	Kick 3 81R
	PERCUSSION 1	Conga H 80R	Conga L 80R	Conga Mute 80R	
		Bongo H 80R	Bongo L 80R	Timbale H	Timbale L
		Cowbell 80R	Claves T8	Vibraslap	
	PERCUSSION 2	Cabasa 80R	Cabasa 81R	Agogo H 80R	Agogo L 80R
		Tambourine 80R	Clap 1 80R	Clap 1 81R	Clap 2 80R
		Clap 3 80R	Clap 3 81R	Metronome 1 81R	Metronome 2 81R
Massive Dance	CYMBAL	Crash T8 MD	Crash T9 MD	Crash 1 NT	Crash 1 PE
		Crash Noise MD	Crash Trap MD	CrashDancePop MD	
		Ride T9 MD	Ride Cup RX5 MD		
	HI-HAT	Hat Open T8 MD	Hat Open T9 MD	HatOp HipHop MD	Hat Open R&B MD
		HatOp Elect MD			
		Hat Closed T8 MD	Hat Closed T9 MD	HatClose Anlg MD	HatCls HipHop MD
		Hat Close R&B MD	HatCls Elect MD	Hat Close 4 PE	
	SNARE DRUM 1	Snare T9 1 MD	Snare T9 2 MD	Snare Elec MD	Snare RX5 MD
		Snare Elec 1 MD	Snare Elec 2 MD	Snare Elec 3 MD	Snare Elec 4 MD
		Snare T8 Rim MD	Snare T9 Rim MD	Snare ElecRim MD	
	SNARE DRUM 2	Snare 14 PE	Snare 23 PE	Snare 33 PE	Snare 3 TEDM
		Snare Jungle MD	Snare Bounce MD	Snare Gate 1 MD	Snare Gate 2 MD
		Snare DS Rim MD	Snare Hip Rim MD	Brush Snare PE	
		Tom T8 1 MD	Tom T8 2 MD	Tom T8 3 MD	
	TOM	Tom Analog 1 MD	Tom Analog 2 MD	Tom Analog 3 MD	Tom Analog 4 MD
		Tom Gate 1 MD	Tom Gate 2 MD	Tom Gate 3 MD	
		Tom PopRock 1 MD	Tom PopRock 2 MD	Tom PopRock 3 MD	

Kit Name	Category	Percussion name (Voice name)			
Massive Dance	BASS DRUM	Kick RX11 MD	Kick T9 MD	KickThickSkin MD	Kick Dist MD
		Kick Zap Hard MD	Kick Blip MD	Kick Dub Step MD	
		Kick Elec 1 MD	Kick Elec 2 MD	Kick Elec 3 MD	Kick Elec 4 MD
		Kick 6 PE	Kick 8 NT	Kick 9 CL	
	REVERSE	Reverse 1 TEDM	Reverse 2 TEDM	Reverse Cym 1 MD	Reverse Cym 2 MD
		RevFnglrSnare DS	Rev BD Electro	Rev BD Analog90	
	VOCAL	Vocal 1 MD	Vocal 2 MD	Vocal 3 MD	Vocal 4 MD
		Beat Box 1 MD	Beat Box 2 MD	Beat Box 3 MD	
	PERCUSSION 1	Cowbell T8 MD	Cowbell MD	Shaker 1 SC	Shaker 3 SC
		Tambourine 82P	Tambourine S PE	Tambourine H PE	Tambourine Op MD
		Tambourine Hit	Claves 83P	Cabasa 81P	
		Triangle Open MD	Triangle Mute MD	Wind Chime Up MD	Wind Chime Dn MD
	PERCUSSION 2	Scratch L 2	ScratchBDForward	ScratchBDRReverse	Tape Stop MD
		Sine Drop MD	Super Low MD	Clock Tick MD	Clock Tack MD
		Electric Perc MD	Percussion 6 CH		
	SNAP/CLAP	Snap 1 CH	Snap 1 PE	Snap 3 NT	Snap Hip Hop MD
		Clap 1 NT	Clap 1 EDM	Clap 3 NT	Clap 4 CL
		Clap 6 EK	Clap Hip Hop MD	Clap House 1 MD	Clap House 2 MD
	IMPACT/NOISE	Impact MD	Impact Hi MD	Crash Impact MD	Impact Zap MD
		Noise Build 1 PE	Noise Build 3 PE	Turn Table CH	
Chinese Pop Drum	CYMBAL	Crash 1 PD	Crash 2 PD	Splash Cymbal PD	China Cymbal PD
		Ride Acoustic 2	Ride Tip PD	Ride Cup PD	
	HI-HAT	Hat Edge 00 PD	Hat Edge 10 PD	Hat Edge 25 PD	Hat Edge 50 PD
		Hat Edge 75 PD	Hat Edge 99 PD		
		Hat Tip 00 PD	Hat Tip 10 PD		
		Hat Pdl Close PD	Hat Pedal Splash		
	SNARE DRUM	Snare 1 PD	Snare 2 PD	Snare 3 PD	Snare 4 PD
		Snare 1 OpRim PD	Snare 2 noRim PD	Snare 3 noRim PD	Snare 4 noRim PD
		SB Mt Off Ed Prs	Snare Roll PD	Snare 1 Stick PD	
	TOM	Tom 1 PD	Tom 2 PD	Tom 3 PD	Tom 4 PD
		Tom 5 PD	Tom 6 PD		
	BASS DRUM	Kick 1 PD	Kick 2 PD	Kick 3 PD	
	PERCUSSION	Cowbell 1 JB	Vibraslap	Tambourine	Jingle Bells
		Wind Chimes	Stick Count VO	Clap Power	
		Seq Click H	Seq Click L		
	CHINESE DRUM	Da Gu 2 Hard	Da Gu 2 Soft	Da Gu Ens Center	Da Gu Ens Rim
		Pai Gu 1	Pai Gu 2	Pai Gu 3	Pai Gu 4
		Pai Gu 5	Ban Gu Left	Shou Gu 1 Center	Shou Gu 2 Center
	CHINESE GONG	Da Luo	Da Luo Crash	Xiao Luo 2	
		Jing Luo 1	Jing Luo 2	Jing Luo 3	
	CHINESE PERCUSS	Xiao Bo 1	Xiao Bo 1 Muted	Xiao Bo 2	Xiao Bo 2 Muted
		Nao Bo	Nao Bo Muted		
		Mu Yu 1	Mu Yu 2	Mu Yu 3	Mu Yu 4
		Mu Yu 5	Kuai Ban Big		
Ambi Cinematic	CYMBAL 1	Hand Cym High	Hand Cym High S	Hand Cym Med	Hand Cym Med S
		Hand Cym Low	Hand Cym Low S	Crash Low	
		Splash Cymbal	Splash Short	Ride Top	Ride Cup
	CYMBAL 2	Cymbal Top High	Cymbal Top Med	Cymbal Top Low	
		Cymbal Roll High	Cymbal Roll Med	Cymbal Roll Low	Bow Low
	SNARE BRUSH 1	Snare LH	Snare RH	Snare Flam	Snare Roll
		March Snare LH	March Snare RH	March Snare Flam	March Snare Roll
		Orch Snare LH	Orch Snare RH	Orch Snare Flam	Orch Snare Roll
		Sidestick	March Snare Stck	Orch Snare Stick	
	SNARE BRUSH 2	Snare Ensemble	Snare Ens Flam	Snare Ens Roll	Snare Ens Cresc
		Piccl Snare LH	Piccl Snare RH	Piccl Snare Flam	Piccl Snare Roll
		Piccl Snare Stck			
	TOM	High Tom	Mid Tom High	Mid Tom Low	Floor Tom High
		Floor Tom Low			
		Roto Tom High	Roto Tom Med H	Roto Tom Med L	Roto Tom Low
		Roto Tom Low L			
	GRAN CASSA	GranCassa H Soft	GranCassa H Lthr	GranCassa H Wood	
		GranCassa M Soft	GranCassa M Wood		
		GranCassa L Soft	GranCassa L Lthr	GranCassa L Wood	
	GONG	Tam-tam	Tam-tam High	Tam-tam Low	Gong
		Handmade Tam-tam	Asian Tam-tam		

Kit Name	Category	Percussion name (Voice name)			
Ambi Cinematic	DRUM	Hammer High	Hammer Med High	Hammer Med Low	Hammer Low
		Taiko Gong Front	Taiko Gong Back	Taiko High	Taiko Medium
		Taiko Low			
	PERCUSSION 1	Conga H	Conga L	Bongo H	Bongo L
		Cowbell Top	Cowbell Tip	Shaker H	Shaker L
		Cuica	Castanets	Castanets Roll	
		Tambourine 1	Tambourine 2	Tambourine1 Roll	Tambourine2 Roll
	PERCUSSION 2	Wood Block H	Wood Block L	Block	
		Whip H	Whip L		
		Triangle	Triangle Mute	Triangle Roll 1	Triangle Roll 2
		Sleigh Bells			
	PERCUSSION 3	Finger Cymbal	Fngr Cym Rub Tip	Fngr Cym Hammer	Fngr Cym Roll
		Bell Tree Up	Bell Tree Down	Wind Chimes 1	Wind Chimes 2
	PERCUSSION 4	Boobam Tuned 1	Boobam Tuned 2	Boobam Tuned 3	Boobam Tuned 4
		Boobam Tuned 5	Boobam Tuned 6	Boobam Tuned 7	Boobam Tuned 8
		Boobam Tuned 9	Metal Shaker	Rainmaker Fast	Rainmaker Slow
		Anvil	Spiral	Lion's Roar	
Revo Pop Percus	CONGA	Conga H Open BR	Conga H Tip BR	Conga H Heel BR	Conga H Bass BR
		Conga H SlpOp BR	Conga H SlpCl BR	Conga H SlpMt BR	
		Conga L Open BR	Conga L Close BR	Conga L SlpOp BR	Conga L SlpMt BR
	BONGO	Bongo H Tip AF	Bongo H Heel AF	Bongo H Slap AF	Bongo H Mute1 AF
		Bongo H OpRm1 AF	Bongo H OpRm3 AF		
		Bongo L Open3 AF	Bongo L Cls3 AF	Bongo L Slap AF	Bongo L OpRm1 AF
	SHAKER	Shaker1 Up BR	Shaker1 Down BR	Shaker2 Up BR	Shaker2 Down BR
		Shaker3 Up BR	Shaker3 Down BR	Shaker4 Up BR	Shaker4 Down BR
		Shaker5 Up PP	Shaker5 Down PP		
		Shaker1 Long BR	Shaker2 Long BR	Shaker3 Long BR	Shaker4 Long BR
	CLAP	Palmas L Open AF	Palmas R Open AF	Palmas L Mute AF	Palmas R Mute AF
		Claps Hi PP	Claps Lo PP		
	PERCUSSION 1	Cowbell RD	Cowbell1 Mth AF	Cowbell2 Mth AF	Chabell Open AF
		Wood Clave AF	African Clave AF	Fibre Clave PP	
		Wood Block AF	Temp Block L PP	Temp Block M PP	Temp Block H PP
		Cabasa L BR	Cabasa R BR		
	PERCUSSION 2	Tamb1 Hit PP	Tamb2 Hit PP	Tamb3 Hit PP	
		Tamb1 Shake PP	Tamb2 Shake PP		
		Triangle OpUp BR	Triangle OpDn BR	Triangle ClUp BR	Triangle ClDn BR
		Chimes Up AF	Chimes Down AF	Crash Cymbal AF	
	PERCUSSION 3	Djembe Bass AF	Djembe Open AF	Djembe Close AF	Djembe Slap AF
		Cajon Bass PP	Cajon Hi PP	Cajon Mid PP	
		Udu Bass Open PP	Udu Bass PP	Udu Tip PP	Udu Heel PP
		Udu Body PP	Udu Top PP		
Revo Afro Cuban	CONGA	Conga H Open AF	Conga H Tip AF	Conga H Heel AF	Conga H Bass AF
		Conga H SlpOp AF	Conga H SlpCl AF	Conga H SlpMt AF	
		Conga L Open AF	Conga L Cls AF	Conga L SlpOp AF	Conga L SlpMt AF
	BONGO	Bongo H Tip AF	Bongo H Heel AF	Bongo H Slap AF	Bongo H Mute1 AF
		Bongo H OpRm1 AF	Bongo H OpRm3 AF		
		Bongo L Open3 AF	Bongo L Cls3 AF	Bongo L Slap AF	Bongo L OpRm1 AF
	TIMBALES	Timb H Open AF	Timb H Rim AF	Timb H Cask AF	
		Timb L Open AF	Timb L Rim AF	Timb L Cask AF	Timb L Stick AF
		Timb Fg L Op AF	Timb Fg L Mt AF		
	COWBELL	Cowbell1 Top1 AF	Cowbell1 Top2 AF	Cowbell2 Top1 AF	Cowbell2 Top2 AF
		Cowbell1 Mth AF	Cowbell2 Mth AF	Cowbell1 Edge AF	Cowbell2 Edge AF
		Chabell Open AF	Chabell Top AF	Chabell Mute AF	
		Mambobell Ctr AF	Mambobell Edg AF		
	PERCUSSION 1	Maracas1 H AF	Maracas1 L AF	Maracas2 H AF	Maracas2 L AF
		Wood Clave AF	African Clave AF	Wood Block AF	
		Guiro Up Slow AF	Guiro Up Fast AF	Guiro Up Shrt AF	Guiro Dn Shrt AF
		M Guiro Long AF	M Guiro Up Sh AF	M Guiro Dn Sh AF	
	PERCUSSION 2	Palmas L Open AF	Palmas C Open AF	Palmas R Open AF	
		Palmas L Mute AF	Palmas C Mute AF	Palmas R Mute AF	
		Chimes Up AF	Chimes Down AF	Crash Cymbal AF	
	PERCUSSION 3	Djembe Bass AF	Djembe Open AF	Djembe Close AF	Djembe Slap AF
		Cajon Bass AF	Cajon Hi AF	Cajon Mid AF	
		Shekere1 Tone AF	Shekere1 Up AF	Shekere1 Down AF	
		Shekere2 Tone AF	Shekere2 Up AF	Shekere2 Down AF	

Kit Name	Category	Percussion name (Voice name)			
Revo Brazilian	CONGA	Conga H Open BR	Conga H Tip BR	Conga H Heel BR	Conga H Bass BR
		Conga H SlpOp BR	Conga H SlpCl BR	Conga H SlpMt BR	
		Conga L Open BR	Conga L Close BR	Conga L SlpOp BR	Conga L SlpMt BR
	BONGO	Bongo H Tip AF	Bongo H Heel AF	Bongo H Slap AF	Bongo H Mute1 AF
		Bongo H OpRm1 AF	Bongo H OpRm3 AF		
		Bongo L Open3 AF	Bongo L Cls3 AF	Bongo L Slap AF	Bongo L OpRm1 AF
	PANDEIRO	Pandeir1 TmOp BR	Pandeir1 ToOp BR	Pandeir1 ThCl BR	Pandeir1 ToCl BR
		Pandeir1 Heel BR	Pandeir1 Slap BR		
		Pandeir2 TmOp BR	Pandeir2 ToOp BR	Pandeir2 TmCl BR	Pandeir2 ToCl BR
	SHAKER	Pandeir2 Heel BR	Pandeir2 Slap BR		
		Shaker1 Up BR	Shaker1 Down BR	Shaker1 Long BR	
		Shaker2 Up BR	Shaker2 Down BR	Shaker2 Long BR	
		Shaker3 Up BR	Shaker3 Down BR	Shaker3 Long BR	
	PERCUSSION 1	Shaker4 Up BR	Shaker4 Down BR	Shaker4 Long BR	
		Surdo Open BR	Surdo Mute BR	Surdo Stop BR	
		Cabasa L BR	Cabasa R BR		
		Agogo1 Bell 1 BR	Agogo1 Bell 2 BR	Agogo1 Close BR	
	PERCUSSION 2	Agogo2 Bell 1 BR	Agogo2 Bell 2 BR	Agogo2 Close BR	
		Tamborim1 Op BR	Tamborim1 Cls BR	Tamborim1 Rim BR	Tamborim1 Bck BR
		Tamborim2 Up BR	Tamborim2 Dn BR		
		Triangle OpUp BR	Triangle OpDn BR	Triangle ClUp BR	Triangle ClDn BR
	PERCUSSION 3	Chimes Up AF	Chimes Down AF	Crash Cymbal AF	
		Djembe Bass AF	Djembe Open AF	Djembe Close AF	Djembe Slap AF
		Shekere1 Tone AF	Shekere1 Up AF	Shekere1 Down AF	
		Reco Scrape BR	Reco Long BR	Reco Short BR	
Bass Drum Kit	ANALOG 1	BD Analog 70	BD Analog 70 L	BD Analog 80	BD Analog 80Long
		BD Analog 82	BD Analog 83	BD Analog 90	BD Analog 91
		BD Analog 92	BD Analog 93	BD Analog 94	
	ANALOG 2	BD Analog Power	BD Analog Tight	BD Analog Hard 1	BD Analog Hard 2
		BD Analog Blip 1	BD Analog Blip 2	BD Analog Rubb 1	BD Analog Rubb 2
		BD Analog Deep	BD Analog Loose		
	ANALOG DIST	BD Analog Dist 1	BD Analog Dist 2	BD Analog Dist 3	BD Analog Dist 4
		BD Analog Dist 5	BD Analog Dist 6	Ripper	
	ELECTRO	BD Electro	BD FX Gate	BD Hammer	BD Hip Deep
		BD Synth 1	BD Synth 2	BD D&B 1	BD D&B 2
		BD Jungle 1	BD Jungle 2	BD Jungle 3	
	ACOUSTIC	BD Dry	BD Dry Hard	BD Soft	BD Power Gate
		BD RX5 1	BD RX5 2	BD R&B 1	BD R&B 2
		BD Room 1	BD Room 2	BD Room 3	
		Big Drum	Taiko Drum	Surdo Open	
	BREAK	BD Break Lo-fi 1	BD Break Lo-fi 2	BD Break Deep	BD Break Heavy
		BD Break Hard	BD Lo-fi	BD&Hi-Hat Open	
	SFX	BD Human	BD Human Deep	Vox Buh!	Vox Muh!
		BD Industrial	Door Slam	Feet 1	Feet 2
		Punch	Heart		
Reverse BD Kit	ANALOG 1	Rev BD Analog 70	Rev BD Analog 81	Rev BD Analog 82	Rev BD Analog 83
		Rev BD Analog 90	Rev BD Analog 91	Rev BD Analog 93	Rev BD Analog 94
	ANALOG 2	Rev BD AnaPower	Rev BD AnaTight	Rev BD AnaHard	
		Rev BD AnaBlip 1	Rev BD AnaBlip 2	Rev BD AnaRubb 1	Rev BD AnaRubb 2
		Rev BD AnaDeep	Rev BD AnaLoose		
	ANALOG DIST	Rev BD AnaDist 1	Rev BD AnaDist 2	Rev BD AnaDist 3	Rev BD AnaDist 4
		Reverse Ripper			
	ELECTRO	Rev BD Electro	Rev BD Fx Gate	Rev BD Hammer	
		Rev BD Synth 1	Rev BD Synth 2	Reverse BD D&B 1	Reverse BD D&B 2
		Rev BD Jungle			
	ACOUSTIC	Reverse BD Dry	Reverse BD Soft	Rev BD Pwr Gate	
		Reverse BD RX5 1	Reverse BD RX5 2	Reverse BD R&B 1	Reverse BD R&B 2
		Rev BD Room 1	Rev BD Room 2		
		Reverse Big Drum	Rev Taiko Drum	Rev Surdo Open	
	BREAK	Rev BD BrkLofi 1	Rev BD BrkLofi 2	Rev BD Brk Deep	Rev BD Brk Heavy
		Rev BD Brk Hard	Reverse BD Lo-fi	Rev BD&HH Open	
	SFX	Reverse BD Human	Rev BD Human Dp	Reverse Vox Buh!	Reverse Vox Muh!
		Rev Tom Indust	Rev Door Slam	Reverse Feet 1	Reverse Feet 2
		Reverse Punch			

Kit Name	Category	Percussion name (Voice name)			
Cymbal Kit	CRASH CYMBAL	Crash Cymbal A	Crash Cymbal B1	Crash Cymbal B2	Crash Cymbal C
		Crash Cymbal D1	Crash Cymbal D2	Crash Cymbal D3	Crash Cymbal E1
		Crash Cymbal E2	Crash Cymbal F1	Crash Cymbal F2	Crash Cymbal F3
		Crash Cymbal F4	Crash Cymbal F5		
	BRUSH CYMBAL	Brush CrashCymF1	Brush CrashCymF2	Brush Ride Cym C	Brush SizzlCym C
	RIDE CYMBAL	Ride Cymbal A	Ride Cymbal B	Ride Cymbal C	Ride Cymbal D
		Ride Cymbal E	Ride Cymbal F1	Ride Cymbal F2	Jazz Ride Cym F1
		Jazz Ride Cym F2			
	SPLASH/CHINA	Splash Cymbal A	Splash Cymbal D	China Cymbal A	
	HI-HAT	HiHat HalfOpen E	Hi-Hat Splash F		
	PERCUSSION	Kick A	Timbale A		
Industrial Kit	HI-HAT	Metal HiHat 1	Metal HiHat 2	Metal HiHat 3	Metal HiHat 4
		Metal HiHat 5	Metal HiHat 6		
	DRUM	Industrial Snare	Metal Tom		
		Dist Bass Drum 1	Dist Bass Drum 2	Dist Bass Drum 3	Giant Bass Drum
		Woodbox Kick 1	Woodbox Kick 2	Woodbox Kick 3	Plastic Box Kick
		Canned Kick			
	IMPACT	Impact FX 1	Impact FX 2	Impact FX 3	Impact FX 4
		Impact FX 5	Alpha Impact	Bravo Impact	Charlie Impact
	HIT	Mixed Hit 1	Mixed Hit 2	Mixed Hit 3	Mixed Hit 4
		Mixed Hit 5	Mixed Hit 6	Mixed Hit 7	
		T.Bell Hard	T.Bell Soft	T.Bell Rim	T.Bell Muffle
	SFX 1	Metal Shot FX	Metal Sneeze FX	Metal Door 1	Metal Door 2
		Metal Rainpipe	Small Metal Box	Metal Spring	Metal Clap
		Iron Filings	Iron Spring	Iron Bar Hi	Iron Bar Lo
		Iron Sledge			
	SFX 2	Oil Barrell 1	Oil Barrell 2	Oil Barrell 3	Oil Barrell 4
		Oil Barrell 5	Oil Barrell 6	Oil Barrell 7	Oil Barrell 8
		Woodlog 1	Woodlog 2	Woodlog 3	
	SFX 3	Boxplosion	Dancing Can	Stone Bag	Stone Shelf
		Knuckle Hit	Ladder Hit	Ladder Clap	Key Chain
		Pump	Click		
	SFX 4	Barn Door	Car Door Slam	Glass Break	Duct Tape Rip
		Gas Lighter	Gas Lighter On	Measure Tape	MeasureTape Snap
		Water Drop	Clock		
	SWEEP	Noise Sweep	Cinematic Sweep	Scifi Sweep	Wheelsweep
Vocal Beatbox	CYMBAL	Crash Hi 1 BB	Crash Hi 2 BB	Crash Lo 1 BB	Crash Lo 2 BB
		China Cym 1 BB	China Cym 2 BB	FX Cymbal Hi BB	
	HI-HAT	Hat 1 Z-Style BB	Hat 2 S-Style BB	Hat 3 NZ-Sty BB	Hat 4 F-Style BB
		Hat 5 Tch-Sty BB	Hat 6 Wd-Sty BB	Hat 7 Open BB	Hat 8 Pedal BB
	SNARE DRUM	Snare 1 Class BB	Snare 2 Clap BB	Snare 3 Stick BB	Snare 4 T-Sty BB
		Snare 5 KCH BB	Snare 6 ISCH BB	Snare 7 TSCH BB	Snare 8 KUCH BB
	TOM	Tom 1 Classic BB	Tom 2 Classic BB	Tom 3 Classic BB	Tom 4 Classic BB
		Tom 5 Classic BB	Tom 6 Classic BB		
		Tom 1 Rim BB	Tom 2 Rim BB	Tom 3 Rim BB	Tom 4 Rim BB
		Tom 5 Rim BB			
	TOM ELECTRO	Tom 1 Electro BB	Tom 2 Electro BB	Tom 3 Electro BB	Tom 4 Electro BB
		Tom 5 Electro BB			
	BASS DRUM	Kick 1 Class BB	Kick 2 Class BB	Kick 3 Ftbm 1 BB	Kick 3 Ftbm 2 BB
		Kick 4 Throat BB	Kick 5 Throat BB	Kick 6 Elec 1 BB	Kick 6 Elec 2 BB
		Kick 7 Throat BB			
	INSTURMENT	Can 1 BB	Can 2 BB	Trumpet BB	Fanfare BB
		Shaker BB			
	SCRATCH	Scratch 1 BB	Scratch 2 BB	Scratch 3 BB	Scratch 4 BB
		Scratch 5 BB	Scratch 6 BB	Scratch 7 BB	Scratch 8 BB
		Scratch 9 BB	Scratch 10 BB	Scratch 11 BB	Scratch 12 BB
	VOICE	Now BB	GetReady BB	Laughter BB	Vibrato BB
		ZtkPauu 1 BB	ZtkPauu 2 BB	Peeptkp 1 BB	Peeptkp 2 BB
		Breath1 BB	Breath2 BB	Breath3 BB	Breath4 BB

Kit Name	Category	Percussion name (Voice name)			
ElectroVocal&SFX	MALE 1	M Dub Step VX	M Electro VX	M Future Bass VX	M Hip Hop VX
		M House VX	M Lo-fi VX	M Feel it VX	M DJ VX
		M One VX	M Two VX	M Three VX	M Some noise VX
		M Feels good VX	M Turn it up VX	M Popping VX	M Louder VX
	MALE 2	M Beat it VX	M Fire VX	M Stop VX	M One more VX
		M Oh my Gosh VX	M Fly away VX	M Bring it VX	M Congrats VX
		M Birthday VX	M Heat it up VX	M Scratch VX	M Skrrr skrrr VX
		M What's up VX	M Yo VX		
	FEMALE 1	F One VX	F Two VX	F Three VX	F Let's go VX
		F Come on VX	F All right VX	F Hands up VX	F Uh huh VX
		F Yeah VX	F Ready go VX	F Ready? VX	F Clap your VX
		F Jump VX	F Power VX	F Ok VX	F Ahaha VX
	FEMALE 2	F Good time VX	F Chill VX	F Click VX	F Close eyes VX
		F Day VX	F Fight VX	F Future VX	F Good VX
		F Hey VX	F What VX	F Sing it VX	F Look at me VX
		F Ikuyo VX	F Hai VX	F Yoisho VX	F Huh VX
	ANALOG	Analog G 1 VX	Analog G 2 VX	Analog G 3 VX	Analog J 1 VX
		Analog J 2 VX	Analog J 3 VX	Analog J 4 VX	Analog J 5 VX
		Analog J 6 VX	Analog J 7 VX	Analog J 8 VX	Analog J 9 VX
		Analog M 1 VX	Analog M 2 VX		
	SFX 1	Trap One VX	Trap Two VX	Trap Three VX	Trap Come on VX
		Trap 2 VX	Trap 3 VX	Dance Pop VX	Hey! VX
		Vocoder 1 VX	Vocoder 2 VX	Vocoder 3 VX	Accent VX
	SFX 2	Pitch 1 VX	Pitch 2 VX	Pitch 3 VX	Pitch 4 VX
		Pitch 5 VX	Pitch 6 VX	Pitch 7 VX	
		Fantastic 1 VX	Fantastic 2 VX	Fantastic 3 VX	
		Impact 1 VX	Impact 2 VX	Synth VX	Raspberry VX
	SFX 3	Dance 1 VX	Dance 2 VX	Dance 3 VX	Trap 1 VX
		Dub Step 1 VX	Dub Step 2 VX	House 1 VX	House 2 VX
		Big Room 1 VX	Big Room 2 VX		
		Pop Rock 1 VX	Pop Rock 2 VX	Pop Rock 3 VX	Pop Rock 4 VX
	SFX 4	Clap HipHop 1 VX	Clap HipHop 2 VX	Clap House VX	Clap DancePop VX
		Horn DJ VX	Horn Cheer VX	Applause VX	Cheers VX
		Question! VX	Right VX	Wrong VX	Depressed VX
Pop Latin Kit 2	CONGA	Conga H Open	Conga H Tip	Conga H Heel	Conga H Mute
		Conga H SlapOpen	Conga H Slap	Conga H SlapMute	
		Conga L Open	Conga L Tip	Conga L Heel	Conga L Mute
		Conga L SlapOpen	Conga L Slap	Conga L Slide	
	BONGO	Bongo H Open 1F	Bongo H Open 3F	Bongo H Rim	Bongo H Tip
		Bongo H Heel	Bongo H Slap		
		Bongo L Open 1F	Bongo L Open 3F	Bongo L Rim	Bongo L Tip
		Bongo L Heel	Bongo L Slap		
	PERCUSSION 1	Timbale H	Timbale L	Paila H	Paila L
		Cowbell Top	Cowbell 1	Cowbell 2	Cowbell 3
		Cowbell High 1	Cowbell High 2	Claves High	Claves Low
		Guiro Long	Guiro Short	MetalGuiro Long	MetalGuiroShort
	PERCUSSION 2	Maracas	Cabasa	Cuica Open	Cuica Mute
		Tamborim Open	Tamborim Tip	Tamborim Mute	Shaker
		Tambourine	Castanet	Triangle Open	Triangle Mute
		Wind Chimes			
	PERCUSSION 3	Cajon Low	Cajon Tip	Cajon Slap	
		Shekere	Shekere Tone		
		Hand Clap Open 1	Hand Clap Open 2	Hand Clap Mute 1	Hand Clap Mute 2
		Hand Clap	Finger Snap		
Pop Latin 2 Comp	CONGA	Conga H Open LC	Conga H Tip LC	Conga H Heel LC	Conga H Mute LC
		Conga H SlpOp LC	Conga H Slap LC	Conga H SlpMt LC	
		Conga L Open LC	Conga L Tip LC	Conga L Heel LC	Conga L Mute LC
		Conga L SlpOp LC	Conga L Slap LC	Conga L Slide LC	
	BONGO	Bongo H Op 1F LC	Bongo H Op 3F LC	Bongo H Rim LC	Bongo H Tip LC
		Bongo H Heel LC	Bongo H Slap LC		
		Bongo L Op 1F LC	Bongo L Op 3F LC	Bongo L Rim LC	Bongo L Tip LC
		Bongo L Heel LC	Bongo L Slap LC		
	PERCUSSION 1	Timbale H LC	Timbale L LC	Paila H LC	Paila L LC
		Cowbell Top LC	Cowbell 1 LC	Cowbell 2 LC	Cowbell 3 LC
		Cowbell Hi 1 LC	Cowbell Hi 2 LC	Claves High LC	Claves Low LC
		Guiro Long LC	Guiro Short LC	Metal Guiro L LC	Metal Guiro S LC

Kit Name	Category	Percussion name (Voice name)			
Pop Latin 2 Comp	PERCUSSION 2	Maracas LC	Cabasa LC	Cuica Open LC	Cuica Mute LC
		Tamborim Op LC	Tamborim Tip LC	Tamborim Mt LC	Shaker LC
		Tambourine LC	Castanet LC	Triangle Open LC	Triangle Mute LC
		Wind Chimes LC			
	PERCUSSION 3	Cajon Low LC	Cajon Tip LC	Cajon Slap LC	
		Shekere LC	Shekere Tone LC		
		Clap Open 1 LC	Clap Open 2 LC	Clap Mute 1 LC	Clap Mute 2 LC
		Hand Clap LC	Finger Snap LC		
Indian Kit	TABLA	Tabla na	Tabla tin		
		Baya ge	Baya ke	Baya ghe	Baya ka
		Tablabaya dha			
	MRIDANGAM	Mridangam na	Mridangam din	Mridangam ki	Mridangam ta
		Mridangam Chapu	Mridangam Lo Op	Mridangam Lo Cls	
	DHOL	Dhol 1 Open	Dhol 1 Slap	Dhol 1 Mute	Dhol 1 Open Slap
		Dhol 1 Roll	Dhol 2 Open	Dhol 2 Slap	Dhol 2 Rim
	DHOLAK	Dholak 1 Open	Dholak 1 Slap	Dholak 1 Mute	
		Dholak 2 Open	Dholak 2 Slide	Dholak 2 Slap	Dholak 2 Ring
		Dholak 2 Rim 1	Dholak 2 Rim 2		
	DHOLKI	Dholki Hi Open	Dholki Hi Slap	Dholki Hi Mute	
		Dholki Lo Open	Dholki Lo Slide		
	PERCUSSION 1	Khol Open	Khol Slide	Khol Mute	
		Thavil Open	Thavil Slap	Thavil Mute	
		Khomokh Normal	Khomokh Flam	Khomokh Mute	
	PERCUSSION 2	Khanjira Open	Khanjira Slap	Khanjira Mute	
		Khanjira Bend Up	Khanjira Bend Dn		
		Duff Open	Duff Slap	Duff Rim	
		Dafli Open	Dafli Slap	Dafli Rim	
	PERCUSSION 3	Hatheli Long	Hatheli Short	Chimta Normal	Chimta Ring
		Chipri	Khartaal	Dandia Long	Dandia Short
		Chutki	Indian Hand Clap		
	PERCUSSION 4	Manjira Open	Manjira Close	Mondira Open	Mondira Close
		Jhanji Open	Jhanji Close		
	SCAT	Bhangra Scat 1	Bhangra Scat 2	Bhangra Scat 3	Bhangra Scat 4
Chinese Percus	CYMBAL	Da Bo	Da Bo Effect	Da Bo Muted	
		Zhong Bo 1 Hard	Zhong Bo 1 Soft	Zhong Bo 2 Hard	Zhong Bo 2 Soft
		Xiao Bo 1	Xiao Bo 1 Muted	Xiao Bo 2	Xiao Bo 2 Muted
		Nao Bo	Nao Bo Muted		
	GONG 1	Da Luo	Da Luo Crash	Da Luo Effect 1	Da Luo Effect 2
		Da Luo Effect 3	Da Luo Stick	Zhong Luo 1	Zhong Luo 2
		Xiao Luo 1	XiaoLuo 1 Muffle	Xiao Luo 2	XiaoLuo 2 Muffle
		Mang Luo 1	Mang Luo 2	Mang Luo 3	Mang Luo 4
	GONG 2	Jing Luo 1	Jing Luo 1 Muted	Jing Luo 2	Jing Luo 2 Muted
		Jing Luo 3	Jing Luo 3 Muted	Shi Mian Luo 1	Shi Mian Luo 2
		Shi Mian Luo 3	Shi Mian Luo 4	Shi Mian Luo 5	Shi Mian Luo 6
		Shi Mian Luo 7	Shi Mian Luo 8	Shi Mian Luo 9	Shi Mian Luo 10
	DRUM	Da Gu 1	Da Gu 2 Hard	Da Gu 2 Soft	Da Gu 1 Rim
		Da Gu 2 Rim	Da Gu Ens Center	Da Gu Ens Rim	Da Gu Ens Shout
		Pai Gu 1	Pai Gu 2	Pai Gu 3	Pai Gu 4
		Pai Gu 5	Xiao Gu		
	PERCUSSION 1	Ban Gu Left	Ban Gu Right	Ban Gu Roll	
		Pai Ban 1	Pai Ban 2	Kuai Ban Big	Kuai Ban Small
		Mu Yu 1	Mu Yu 2	Mu Yu 3	Mu Yu 4
		Mu Yu 5			
	PERCUSSION 2	Shou Gu 1 Center	Shou Gu 1 Edge	Shou Gu 1 Side	
		Shou Gu 2 Center	Shou Gu 2 Edge 1	Shou Gu 2 Edge 2	Shou Gu 2 Edge 3
		Peng Ling			

Rhythm Pattern Program Kit List

- Percussion sounds or sound effects marked with “*” in the Key-off column require Gate Time (note length) to be set.
- Percussion sounds marked with “●” in the Revo column (pages 122–129 and 146–149) use the “Revo Drums” sound source technology.
-  : Indicates the positions of the Upper Keyboard and Lower Keyboard.

		DRUMS [1]					
		EL Kit 1	Key off	EL Kit 2	Key off	Standard Kit 1	Key off
Lower Keyboard	Upper Keyboard	C-2	C#-2				
		D-2	D#-2				
		E-2					
		F-2	F#-2				
		G-2	G#-2				
		A-2	A#-2				
		B-2					
		C-1	C#-1	Scratch	Maracas High	Surdo Mute	
		D-1	D#-1	Concert BD	Surdo Mute	Surdo Open	
		E-1		Noise Percussion	Maracas Low	Hi Q	
		F-1	F#-1	Bass Drum March	Surdo Muff	Whip Slap	
		G-1	G#-1	Analog BD Short	Surdo Rim	Scratch H	
		A-1	A#-1	Synth Tom 3	Cuica High	Scratch L	
		B-1		Analog BD Long	Surdo Open	Finger Snap	
		C0	C#0	Synth Tom 2	Cuica Middle	Click Noise	
		D0	D#0	Synth Bass Drum	Tamborim Mute	Metronome Click	
		E0		Synth Tom 1	Cuica Low	Metronome Bell	
		F0	F#0	Bass Drum Attack	Tamborim Open	Seq Click L	
		G0	G#0	Bass Drum Heavy	Pandeiro	Seq Click H	
		A0	A#0	Tom 4	Bongo High	Brush Tap	
		B0		Bass Drum Light	Conga Slide	Brush Swirl	*
		C1	C#1	Tom 3	Bongo Low	Brush Slap	
		D1	D#1	Orch Snare Drum	Conga Slap	Brush Tap Swirl	*
		E1		Snare Drum Roll	* Conga Muff	Snare Roll	*
		F1	F#1	Tom 2	Bongo Mute	Castanet	
		G1	G#1	SD Brush Roll	Conga High	Snare Soft	
		A1	A#1	Tom 1	Bongo Slap	Sticks	
		B1		SD Brush Shot 2	Conga Low	Kick Soft	
C2	C#2	Tom Brush Shot 4		Open Rim Shot			
D2	D#2	SD Brush Shot 1	Timbale 1 High	Kick Tight			
E2		SD Heavy	Timbale 1 Low	Kick			
F2	F#2	Tom Brush Shot 3		Side Stick			
G2	G#2	Snare Drum Light	Timbale 2 High	Snare			
A2	A#2	Tom Brush Shot 2		Hand Clap			
B2		SD Accent 2	Timbale 2 Low	Snare Tight			
		SD Accent 1	Timbale 3 High	Floor Tom L			
		Tom Brush Shot 1	Wood Block High	Hi-Hat Closed			
		SD Reverb 2	Timbale 3 Low	Floor Tom H			
		Snare Drum Rim 2	Wood Block Mid	Hi-Hat Pedal			
		SD Reverb 1	Timbale 4 High	Low Tom			
		Snare Drum Rim 1	Wood Block Low	Hi-Hat Open			
		Synth Snare Drum	Timbale 4 Low	Mid Tom L			
		Analog SD	Vibraslap	Mid Tom H			
		Triangle Mute	Triangle Mute	Crash Cymbal 1			
		Tambourine	Tambourine	High Tom			
		Triangle Open	Triangle Open	Ride Cymbal 1			
		Castanet	Castanet	China Cymbal			
		Claves	Claves	Ride Cymbal Cup			
				Tambourine			
		Cabasa	Cabasa	Splash Cymbal			
				Cowbell			
		Finger Snap	Finger Snap	Crash Cymbal 2			
				Vibraslap			
		Hand Claps	Hand Claps	Ride Cymbal 2			

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [1]					
Standard Kit 2	Key off	Hit Kit	Key off	Room Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute	
D-1	D#-1	Surdo Open	Surdo Open	Surdo Open	
E-1		Hi Q	Hi Q	Hi Q	
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	
G-1	G#-1	Scratch H	Scratch H	Scratch H	
A-1	A#-1	Scratch L	Scratch L	Scratch L	
B-1		Finger Snap	Finger Snap	Finger Snap	
C0	C#0	Click Noise	Click Noise	Click Noise	
D0	D#0	Metronome Click	Metronome Click	Metronome Click	
E0		Metronome Bell	Metronome Bell	Metronome Bell	
F0	F#0	Seq Click L	Seq Click L	Seq Click L	
G0	G#0	Seq Click H	Seq Click H	Seq Click H	
A0	A#0	Brush Tap	Brush Tap	Brush Tap	
B0		Brush Swirl	* Brush Swirl	* Brush Swirl	* Brush Swirl
C1	C#1	Brush Slap	Brush Slap	Brush Slap	
D1	D#1	Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl
E1		Snare Roll	* Snare Roll	* Snare Roll	* Snare Roll
F1	F#1	Castanet	Castanet	Castanet	
G1	G#1	Snare Soft 2	Snare Electro	Snare Soft	
A1	A#1	Sticks	Sticks	Sticks	
B1		Kick Soft	Kick Tight L	Kick Soft	
C2	C#2	Open Rim Shot H	Snare Pitched	Open Rim Shot	
D2	D#2	Kick Tight	Kick Wet	Kick Tight	
E2		Kick Short	Kick Tight H	Kick	
F2	F#2	Side Stick Light	Stick Ambient	Side Stick	
G2	G#2	Snare Short	Snare Ambient	Snare Snappy	
A2	A#2	Hand Clap	Hand Clap	Hand Clap	
B2		Snare Tight H	Snare Tight 2	Snare Tight Snap	
C-2	C#-2	Floor Tom L	Hybrid Tom 1	Tom Room 1	
D-2	D#-2	Hi-Hat Closed	Hi-Hat Closed 2	Hi-Hat Closed	
E-2		Floor Tom H	Hybrid Tom 2	Tom Room 2	
F-2	F#-2	Hi-Hat Pedal	Hi-Hat Pedal 2	Hi-Hat Pedal	
G-2	G#-2	Low Tom	Hybrid Tom 3	Tom Room 3	
A-2	A#-2	Hi-Hat Open	Hi-Hat Open 2	Hi-Hat Open	
B-2		Mid Tom L	Hybrid Tom 4	Tom Room 4	
C-2	C#-2	Mid Tom H	Hybrid Tom 5	Tom Room 5	
D-2	D#-2	Crash Cymbal 1	Crash Cymbal 1	Crash Cymbal 1	
E-2		High Tom	Hybrid Tom 6	Tom Room 6	
F-2	F#-2	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	
G-2	G#-2	China Cymbal	China Cymbal	China Cymbal	
A-2	A#-2	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup	
B-2		Tambourine	Tambourine Light	Tambourine	
C-2	C#-2	Splash Cymbal	Splash Cymbal	Splash Cymbal	
D-2	D#-2	Cowbell	Cowbell	Cowbell	
E-2		Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	
F-2	F#-2	Vibraslap	Vibraslap	Vibraslap	
G-2	G#-2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [1]					
Rock Kit	Key off	Electro Kit 1	Key off	Analog Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute	
D-1	D#-1	Surdo Open	Surdo Open	Surdo Open	
E-1		Hi Q	Hi Q	Hi Q	
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	
G-1	G#-1	Scratch H	Scratch H	Scratch H	
A-1	A#-1	Scratch L	Scratch L	Scratch L	
B-1		Finger Snap	Finger Snap	Finger Snap	
C0	C#0	Click Noise	Click Noise	Click Noise	
D0	D#0	Metronome Click	Metronome Click	Metronome Click	
E0		Metronome Bell	Metronome Bell	Metronome Bell	
F0	F#0	Seq Click L	Seq Click L	Seq Click L	
G0	G#0	Seq Click H	Seq Click H	Seq Click H	
A0	A#0	Brush Tap	Brush Tap	Brush Tap	
B0		Brush Swirl	Brush Swirl	Brush Swirl	*
C1	C#1	Brush Slap	Brush Slap	Brush Slap	
D1	D#1	Brush Tap Swirl	Reverse Cymbal	Reverse Cymbal	*
E1		Snare Roll	Snare Roll	Snare Roll	*
F1	F#1	Castanet	Hi Q 2	Hi Q 2	
G1	G#1	Snare Noisy	Snare Snap Elec	Snare Noisy 4	
A1	A#1	Sticks	Sticks	Sticks	
B1		Kick Soft	Kick 3	Kick 3	
C2	C#2	Open Rim Shot	Open Rim Shot	Open Rim Shot	
D2	D#2	Kick 2	Kick Gate	Kick Anlg Short	
E2		Kick Gate	Kick Gate Heavy	Kick Analog	
F2	F#2	Side Stick	Side Stick	Side Stick Anlg	
G2	G#2	Snare Rock	Snare Noisy 2	Snare Analog	
A2	A#2	Hand Clap	Hand Clap	Hand Clap	
B2		Snare Rock Tight	Snare Noisy 3	Snare Analog 2	
C-2	C#-2	Tom Rock 1	Tom Electro 1	Tom Analog 1	
D-2	D#-2	Hi-Hat Closed	Hi-Hat Closed	Hat Close Analog	
E-2		Tom Rock 2	Tom Electro 2	Tom Analog 2	
F-2	F#-2	Hi-Hat Pedal	Hi-Hat Pedal	Hat Close Anlg 2	
G-2	G#-2	Tom Rock 3	Tom Electro 3	Tom Analog 3	
A-2	A#-2	Hi-Hat Open	Hi-Hat Open	Hat Open Analog	
B-2		Tom Rock 4	Tom Electro 4	Tom Analog 4	
C-2	C#-2	Tom Rock 5	Tom Electro 5	Tom Analog 5	
D-2	D#-2	Crash Cymbal 1	Crash Cymbal 1	Crash Analog	
E-2		Tom Rock 6	Tom Electro 6	Tom Analog 6	
F-2	F#-2	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	
G-2	G#-2	China Cymbal	China Cymbal	China Cymbal	
A-2	A#-2	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup	
B-2		Tambourine	Tambourine	Tambourine	
C-2	C#-2	Splash Cymbal	Splash Cymbal	Splash Cymbal	
D-2	D#-2	Cowbell	Cowbell	Cowbell Analog	
E-2		Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	
F-2	F#-2	Vibraslap	Vibraslap	Vibraslap	
G-2	G#-2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [1]					
Dance Kit	Key off	Jazz Kit	Key off	Brush Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Kick Dance 1	Surdo Mute	Surdo Mute	
D-1	D#-1	Kick Dance 2	Surdo Open	Surdo Open	
E-1		Hi Q	Hi Q	Hi Q	
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	
G-1	G#-1	Scratch Dance 1	Scratch H	Scratch H	
A-1	A#-1	Scratch Dance 2	Scratch L	Scratch L	
B-1		Finger Snap	Finger Snap	Finger Snap	
C0	C#0	Click Noise	Click Noise	Click Noise	
D0	D#0	Dance Perc 1	Metronome Click	Metronome Click	
E0		Reverse Dance 1	Metronome Bell	Metronome Bell	
F0	F#0	Dance Perc 2	Seq Click L	Seq Click L	
G0	G#0	Hi Q Dance 1	Seq Click H	Seq Click H	
A0	A#0	Snare Analog 3	Brush Tap	Brush Tap	
B0		Vinyl Noise	Brush Swirl	Brush Swirl	*
C1	C#1	Snare Analog 4	Brush Slap	Brush Slap	
D1	D#1	Reverse Cymbal	Brush Tap Swirl	Brush Tap Swirl	*
E1		Reverse Dance 2	Snare Roll	Snare Roll	*
F1	F#1	Hi Q 2	Castanet	Castanet	
G1	G#1	Snare Techno	Snare Jazz H	Brush Slap 2	
A1	A#1	Snare Dance 1	Sticks	Sticks	
B1		Kick Techno Q	Kick Soft	Kick Soft	
C2	C#2	Rim Gate	Open Rim Shot	Open Rim Shot	
D2	D#2	Kick Techno L	Kick Tight	Kick Tight	
E2		Kick Techno	Kick Jazz	Kick Jazz	
F2	F#2	Side Stick Anlg	Side Stick Light	Side Stick Light	
G2	G#2	Snare Clap	Snare Jazz L	Brush Slap 3	
A2	A#2	Dance Clap	Hand Clap	Hand Clap	
B2		Snare Dry	Snare Jazz M	Brush Tap 2	
C-2	C#-2	Tom Dance 1	Floor Tom L	Tom Brush 1	
D-2	D#-2	Hi-Hat Closed 3	Hi-Hat Closed	Hi-Hat Closed	
E-2		Tom Dance 2	Floor Tom H	Tom Brush 2	
F-2	F#-2	Hat Close Anlg 3	Hi-Hat Pedal	Hi-Hat Pedal	
G-2	G#-2	Tom Dance 3	Low Tom	Tom Brush 3	
A-2	A#-2	Hi-Hat Open 3	Hi-Hat Open	Hi-Hat Open	
B-2		Tom Dance 4	Mid Tom L	Tom Brush 4	
C-2	C#-2	Tom Dance 5	Mid Tom H	Tom Brush 5	
D-2	D#-2	Crash Analog	Crash Cymbal 1	Crash Cymbal 1	
E-2		Tom Dance 6	High Tom	Tom Brush 6	
F-2	F#-2	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	
G-2	G#-2	China Cymbal	China Cymbal	China Cymbal	
A-2	A#-2	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup	
B-2		Tambourine Anlg	Tambourine	Tambourine	
C-2	C#-2	Splash Cymbal	Splash Cymbal	Splash Cymbal	
D-2	D#-2	Cowbell Dance	Cowbell	Cowbell	
E-2		Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	
F-2	F#-2	Vibraslap Analog	Vibraslap	Vibraslap	
G-2	G#-2	Ride Analog	Ride Cymbal 2	Ride Cymbal 2	

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [1]				DRUMS [2]	
Symphony Kit	Key off	Chinese Mix Kit	Key off	Live! Std Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute	
D-1	D#-1	Surdo Open	Surdo Open	Surdo Open	
E-1		Hi Q	Hi Q	Hi Q	
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	
G-1	G#-1	Scratch H	Scratch H	Scratch H	
A-1	A#-1	Scratch L	Scratch L	Scratch L	
B-1		Finger Snap	Finger Snap	Finger Snap	
C0	C#0	Click Noise	Click Noise	Click Noise	
D0	D#0	Metronome Click	Metronome Click	Metronome Click	
E0		Metronome Bell	Metronome Bell	Metronome Bell	
F0	F#0	Seq Click L	Seq Click L	Seq Click L	
G0	G#0	Seq Click H	Seq Click H	Seq Click H	
A0	A#0	Brush Tap	Brush Tap	Brush Tap	
B0		Brush Swirl	* Brush Swirl	* Brush Swirl	* Brush Swirl
C1	C#1	Brush Slap	Brush Slap	Brush Slap	
D1	D#1	Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl
E1		Snare Roll	* Snare Roll	* Snare Roll	* Snare Roll
F1	F#1	Castanet	Castanet	Castanet	
G1	G#1	Snare Soft	Snare Soft	Snare Soft	
A1	A#1	Sticks	Sticks	Sticks	
B1		Kick Soft 2	Kick Soft	Kick Soft	
C2	C#2	Open Rim Shot	Open Rim Shot	Open Rim Shot	
D2	D#2	Gran Cassa	Kick Tight	Kick Tight	
E2		Gran Cassa Mute	Kick	Kick	
F2	F#2	Side Stick	Side Stick	Side Stick	
G2	G#2	Band Snare	Snare	Snare	
A2	A#2	Hand Clap	Hand Clap	Hand Clap	
B2		Band Snare 2	Snare Tight	Snare Tight	
C-2	C#-2	Floor Tom L	Floor Tom L	Floor Tom L	
D-2	D#-2	Hi-Hat Closed	Hi-Hat Closed	Hi-Hat Closed	
E-2		Floor Tom H	Floor Tom H	Floor Tom H	
F-2	F#-2	Hi-Hat Pedal	Hi-Hat Pedal	Hi-Hat Pedal	
G-2	G#-2	Low Tom	Low Tom	Low Tom	
A-2	A#-2	Hi-Hat Open	Hi-Hat Open	Hi-Hat Open	
B-2		Mid Tom L	Mid Tom L	Mid Tom L	
C-2	C#-2	Mid Tom H	Mid Tom H	Mid Tom H	
D-2	D#-2	Hand Cymbal 1	Crash Cymbal 1	Crash Cymbal 1	
E-2		High Tom	High Tom	High Tom	
F-2	F#-2	Hand Cymbal 1 S	Ride Cymbal 1	Ride Cymbal 1	
G-2	G#-2	China Cymbal	China Cymbal	China Cymbal	
A-2	A#-2	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup	
B-2		Tambourine	Tambourine	Tambourine	
C-2	C#-2	Splash Cymbal	Splash Cymbal	Splash Cymbal	
D-2	D#-2	Cowbell	Cowbell	Cowbell	
E-2		Hand Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	
F-2	F#-2	Vibraslap	Vibraslap	Vibraslap	
G-2	G#-2	Hand Cymbal 2 S	Ride Cymbal 2	Ride Cymbal 2	

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [2]					
Live! Std+P Kit	Key off	Live! Funk Kit	Key off	Live! Funk+P Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute	
D-1	D#-1	Surdo Open	Surdo Open	Surdo Open	
E-1		Hi Q	Hi Q	Hi Q	
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	
G-1	G#-1	Scratch H	Scratch H	Scratch H	
A-1	A#-1	Scratch L	Scratch L	Scratch L	
B-1		Finger Snap	Finger Snap	Finger Snap	
C0	C#0	Click Noise	Click Noise	Click Noise	
D0	D#0	Metronome Click	Metronome Click	Metronome Click	
E0		Metronome Bell	Metronome Bell	Metronome Bell	
F0	F#0	Seq Click L	Seq Click L	Seq Click L	
G0	G#0	Seq Click H	Seq Click H	Seq Click H	
A0	A#0	Brush Tap	Brush Tap	Brush Tap	
B0		Brush Swirl	* Brush Swirl	* Brush Swirl	* Brush Swirl
C1	C#1	Brush Slap	Brush Slap	Brush Slap	
D1	D#1	Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl
E1		Snare Roll	* Snare Roll	* Snare Roll	* Snare Roll
F1	F#1	Castanet	Castanet	Castanet	
G1	G#1	Snare Soft	Snare Soft 2	Snare Soft 2	
A1	A#1	Sticks	Sticks	Sticks	
B1		Kick Soft	Kick Soft	Kick Soft	
C2	C#2	Open Rim Shot	Open Rim Shot H	Open Rim Shot H	
D2	D#2	Kick Tight	Kick Tight	Kick Tight	
E2		Kick	Kick Short	Kick Short	
F2	F#2	Side Stick	Side Stick Light	Side Stick Light	
G2	G#2	Snare	Snare Short	Snare Short	
A2	A#2	Hand Clap	Hand Clap	Hand Clap	
B2		Snare Tight	Snare Tight H	Snare Tight H	
C-2	C#-2	Floor Tom L	Floor Tom L	Floor Tom L	
D-2	D#-2	Hi-Hat Closed	Hi-Hat Closed	Hi-Hat Closed	
E-2		Floor Tom H	Floor Tom H	Floor Tom H	
F-2	F#-2	Hi-Hat Pedal	Hi-Hat Pedal	Hi-Hat Pedal	
G-2	G#-2	Low Tom	Low Tom	Low Tom	
A-2	A#-2	Hi-Hat Open	Hi-Hat Open	Hi-Hat Open	
B-2		Mid Tom L	Mid Tom L	Mid Tom L	
C-2	C#-2	Mid Tom H	Mid Tom H	Mid Tom H	
D-2	D#-2	Crash Cymbal 1	Crash Cymbal 1	Crash Cymbal 1	
E-2		High Tom	High Tom	High Tom	
F-2	F#-2	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	
G-2	G#-2	China Cymbal	China Cymbal	China Cymbal	
A-2	A#-2	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup	
B-2		Tambourine	Tambourine	Tambourine	
C-2	C#-2	Splash Cymbal	Splash Cymbal	Splash Cymbal	
D-2	D#-2	Cowbell	Cowbell	Cowbell	
E-2		Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	
F-2	F#-2	Vibraslap	Vibraslap	Vibraslap	
G-2	G#-2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	

Oct.+3

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [2]					
Live! Brush Kit	Key off	Live!Brush+P Kit	Key off	Live! Studio Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute	
D-1	D#-1	Surdo Open	Surdo Open	Surdo Open	
E-1		Hi Q	Hi Q	Hi Q	
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	
G-1	G#-1	Scratch H	Scratch H	Scratch H	
A-1	A#-1	Scratch L	Scratch L	Scratch L	
B-1		Finger Snap	Finger Snap	Finger Snap	
C0	C#0	Click Noise	Click Noise	Click Noise	
D0	D#0	Metronome Click	Metronome Click	Metronome Click	
E0		Metronome Bell	Metronome Bell	Metronome Bell	
F0	F#0	Seq Click L	Seq Click L	Seq Click L	
G0	G#0	Seq Click H	Seq Click H	Seq Click H	
A0	A#0	Brush Tap	Brush Tap	Brush Tap	
B0		Brush Swirl	* Brush Swirl	* Brush Swirl	* Brush Swirl
C1	C#1	Brush Slap	Brush Slap	Brush Slap	
D1	D#1	Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl
E1		Snare Roll	* Snare Roll	* Snare Roll	* Snare Roll
F1	F#1	Castanet	Castanet	Castanet	
G1	G#1	Brush Slap 2	Brush Slap 2	Snare Studio 2	
A1	A#1	Sticks	Sticks	Sticks	
B1		Kick Soft	Kick Soft	Kick Ambience H	
C2	C#2	Open Rim Shot	Open Rim Shot	Open Rim Shot	
D2	D#2	Kick Tight	Kick Tight	Kick Ambience L	
E2		Kick Jazz	Kick Jazz	Kick Studio	
F2	F#2	Side Stick Light	Side Stick Light	Side Stick	
G2	G#2	Brush Slap 3	Brush Slap 3	Snare Studio M	
A2	A#2	Hand Clap	Hand Clap	Hand Clap	
B2		Brush Tap 2	Brush Tap 2	Snare Studio L	
C-2	C#-2	Tom Brush 1	Tom Brush 1	Floor Tom L	
D-2	D#-2	Hi-Hat Closed	Hi-Hat Closed	Hi-Hat Closed	
E-2		Tom Brush 2	Tom Brush 2	Floor Tom H	
F-2	F#-2	Hi-Hat Pedal	Hi-Hat Pedal	Hi-Hat Pedal	
G-2	G#-2	Tom Brush 3	Tom Brush 3	Low Tom	
A-2	A#-2	Hi-Hat Open	Hi-Hat Open	Hi-Hat Open	
B-2		Tom Brush 4	Tom Brush 4	Mid Tom L	
C-2	C#-2	Tom Brush 5	Tom Brush 5	Mid Tom H	
D-2	D#-2	Crash Cymbal 1	Crash Cymbal 1	Crash Cymbal 1	
E-2		Tom Brush 6	Tom Brush 6	High Tom	
F-2	F#-2	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	
G-2	G#-2	China Cymbal	China Cymbal	China Cymbal	
A-2	A#-2	Ride Cymbal Cup	Ride Cymbal Cup	Ride Cymbal Cup	
B-2		Tambourine	Tambourine	Tambourine	
C-2	C#-2	Splash Cymbal	Splash Cymbal	Splash Cymbal	
D-2	D#-2	Cowbell	Cowbell	Cowbell	
E-2		Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	
F-2	F#-2	Vibraslap	Vibraslap	Vibraslap	
G-2	G#-2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	

Oct.+3

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [2]					
Live!AcousticKit	Key off	Live! PowerKit 1	Key off	Live! PowerKit 2	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute	
D-1	D#-1	Surdo Open	Surdo Open	Surdo Open	
E-1		Hi Q	Hi Q	Hi Q	
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	
G-1	G#-1	Scratch H	Scratch H	Scratch H	
A-1	A#-1	Scratch L	Scratch L	Scratch L	
B-1		Finger Snap	Finger Snap	Finger Snap	
C0	C#0	Click Noise	Click Noise	Click Noise	
D0	D#0	Metronome Click	Metronome Click	Metronome Click	
E0		Metronome Bell	Metronome Bell	Metronome Bell	
F0	F#0	Seq Click L	Seq Click L	Seq Click L	
G0	G#0	Seq Click H	Seq Click H	Seq Click H	
A0	A#0	Brush Tap	Brush Tap	Brush Tap	
B0		Brush Swirl	* Brush Swirl	* Brush Swirl	* Brush Swirl
C1	C#1	Brush Slap	Brush Slap	Brush Slap	
D1	D#1	Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl	* Brush Tap Swirl
E1		Snare Roll Aco	* Snare Roll	* Snare Roll	* Snare Roll
F1	F#1	Castanet	Castanet	Castanet	
G1	G#1	Snare Soft Aco	SnareSoftPower 1	SnareSoftPower 2	
A1	A#1	Sticks	Sticks	Sticks	
B1		Kick Soft Aco	Kick Ambient+	Kick Ambient+	
C2	C#2	Rim Acoustic	Open Rim Power 1	Open Rim Power 2	
D2	D#2	Kick Mute Aco	Kick Power Open	Kick Power Open	
E2		Kick Open Aco	Kick Power Mute	Kick Power Mute	
F2	F#2	Stick Acoustic	Side Stick Power	Side Stick Power	
G2	G#2	Snare Acoustic	Snare Power 1	Snare Power 2	
A2	A#2	Hand Clap Power	Hand Clap Power	Hand Clap Power	
B2		Snare Rough Aco	Snare Rough 1	Snare Rough 2	
C3	C#3	Tom Acoustic 1	Tom Power 1	Tom Power 1	
D3	D#3	Hi-Hat Close Aco	Hi-HatClosePower	HH Closed PW Eg	
E3		Tom Acoustic 2	Tom Power 2	Tom Power 2	
F3	F#3	Hi-Hat Pedal Aco	Hi-HatPedalPower	Hi-HatPedalPower	
G3	G#3	Tom Acoustic 3	Tom Power 3	Tom Power 3	
A3	A#3	Hi-Hat Open Aco	Hi-HatOpen Power	Hi-HatOpen Power	
B3		Tom Acoustic 4	Tom Power 4	Tom Power 4	
C4	C#4	Tom Acoustic 5	Tom Power 5	Tom Power 5	
D4	D#4	CrashCymbalAco 1	CrashCymbalAco 1	CrashCymbalAco 1	
E4		Tom Acoustic 6	Tom Power 6	Tom Power 6	
F4	F#4	RideCymbal Aco 1	RideCymbal Aco 1	RideCymbal Aco 1	
G4	G#4	China Cymbal Aco	China Cymbal Aco	China Cymbal Aco	
A4	A#4	RideCymbalCupAco	RideCymbalCupAco	RideCymbalCupAco	
B4		Tambourine	Tambourine	Tambourine	
C5	C#5	SplashCymbal Aco	SplashCymbal Aco	SplashCymbal Aco	
D5	D#5	Cowbell	Cowbell	Cowbell	
E5		CrashCymbalAco 2	CrashCymbalAco 2	CrashCymbalAco 2	
F5	F#5	Vibraslap	Vibraslap	Vibraslap	
G5	G#5	RideCymbal Aco 2	RideCymbal Aco 2	RideCymbal Aco 2	

Oct.+3

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [2]					
Live! Rock Kit	Key off	Live! Real Drums	Key off	Live!RealBrushes	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute	
D-1	D#-1	Surdo Open	Surdo Open	Surdo Open	
E-1		Hi Q	Hi Q	Hi Q	
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	
G-1	G#-1	Scratch H	Scratch H	Scratch H	
A-1	A#-1	Scratch L	Scratch L	Scratch L	
B-1		Finger Snap	Finger Snap	Finger Snap	
C0	C#0	Click Noise	Click Noise	Click Noise	
D0	D#0	Metronome Click	Metronome Click	Metronome Click	
E0		Metronome Bell	Metronome Bell	Metronome Bell	
F0	F#0	Seq Click L	Seq Click L	Vintage Tip	
G0	G#0	Seq Click H	Seq Click H	Vintage Swirl 1	*
A0	A#0	Brush Tap	Brush Tap	Vintage Slap 1	
B0		Brush Swirl	* Brush Tap Swirl	* Vintage Swirl 2	*
C1	C#1	Brush Slap	Brush Slap	Vintage Slap 2	
D1	D#1	Brush Tap Swirl	* Brush Tap Swirl	* Vintage TapSwirl	*
E1		Snare Roll Rock	* Snare Roll Rock	* VintageSlapSwirl	*
F1	F#1	Castanet	Castanet	Vintage Swirl 3	*
G1	G#1	Snare Soft Rock	Snare Tight	Vintage Slap 3	
A1	A#1	Sticks	Sticks	Sticks	
B1		Kick Soft Rock	Kick Genuine	Kick Soft L	
C2	C#2	Rim Rock	Rim Real	Open Rim Shot RB	
D2	D#2	Kick Rock Heavy	Kick Real 1	Kick Soft H	
E2		Kick Rock	Kick Real 2	KickJazzAmbience	
F2	F#2	Stick Rock	Stick Real	Stick Brush	
G2	G#2	Snare Rock	Snare Real 1	Vintage Slap 4	
A2	A#2	Hand Clap Power	Clap Power	Clap Power	
B2		Snare Dry Rock	Snare Real 2	Vintage Slap 5	
C3	C#3	Tom Rock 1	Tom Real 1	TomRealBrushes 1	
D3	D#3	Hi-HatClosedRock	Hi-HatClosedReal	Hi-Hat Closed RB	
E3		Tom Rock 2	Tom Real 2	TomRealBrushes 2	
F3	F#3	Hi-HatPedal Rock	Hi-Hat PedalReal	Hi-Hat Pedal RB	
G3	G#3	Tom Rock 3	Tom Real 3	TomRealBrushes 3	
A3	A#3	Hi-Hat Open Rock	Hi-Hat Open Real	Hi-Hat Open RB	
B3		Tom Rock 4	Tom Real 4	TomRealBrushes 4	
C4	C#4	Tom Rock 5	Tom Real 5	TomRealBrushes 5	
D4	D#4	CrashCymbalAco 1	CrashCymbalReal1	CrashCymbal RB 1	
E4		Tom Rock 6	Tom Real 6	TomRealBrushes 6	
F4	F#4	RideCymbal Aco 1	RideCymbalReal 1	Ride Cymbal RB	
G4	G#4	China Cymbal Aco	ChinaCymbal Real	China Cymbal RB	
A4	A#4	RideCymbalCupAco	RideCym Cup Real	Ride Cup RB 1	
B4		Tambourine	Tambourine	Tambourine	
C5	C#5	SplashCymbal Aco	SplashCymbalReal	Splash Cymbal RB	
D5	D#5	Cowbell	Cowbell	Cowbell	
E5		CrashCymbalAco 2	CrashCymbalReal2	CrashCymbal RB 2	
F5	F#5	Vibraslap	Vibraslap	Vibraslap	
G5	G#5	RideCymbal Aco 2	RideCymbalReal 2	Ride Cup RB 2	

Lower
KeyboardUpper
Keyboard

Oct.–1

DRUMS [3]					
Analog T8 Kit		Key off	Analog T9 Kit		Key off
House Kit					
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1				
D-1	D#-1				
E-1					
F-1	F#-1				
G-1	G#-1				
A-1	A#-1				
B-1					
C0	C#0				
D0	D#0				
E0					
F0	F#0				
G0	G#0				
A0	A#0				
B0					
C1	C#1				
D1	D#1				
E1					
F1	F#1				
G1	G#1				
A1	A#1				
B1					
C2	C#2				
D2	D#2				
E2					
F2	F#2				
G2	G#2				
A2	A#2				
B2					
		Surdo Mute	Surdo Mute	W Kick	*
		Surdo Open	Surdo Open	Disco Fx	*
		Hi Q	Hi Q	WhiteNoiseDown 1	*
		Whip Slap	Whip Slap	PinkNoise Down 1	*
		Scratch H	Scratch H	WhiteNoiseDown 2	*
		Scratch L	Scratch L	PinkNoise Down 2	*
		Snare Hammer	Snare Drum&Bass1	White Noise Up 2	*
		Kick Zap Hard	Kick Break 2	White Noise Up 1	*
		Snare Garg L	Snare Distortion	Pink Noise Up	*
		Kick Tek Power	Kick Tek Power	WhiteNoiseUp Rel	*
		Kick Slimy	KickDistortionRM	PinkNoise Up Rel	*
		Kick T8 4	Kick T9 2	Kick T9 4	
		Snare Analog CR	Snare Analog CR	Snare T8 Rim	
		Snare T8 7	Snare T9 5	Snare T8 5	
		SnareClap Analog	Clap Analog Sm	Hand Clap	
		Snare T8 6	Snare T9 Gate 1	Snare Garg L	
		Tom T8 5	Snare Rock Roll	Snare Roll	*
		Snare T8 5	Snare T9 3	Snare T9 3	
		Kick T8 3	Snare T9 4	Snare T8 1	
		Snare T8 4	Snare T9 Gate 2	Snare T9 5	
		Kick T8 2	Kick T9 4	Kick T9 1	
		Snare T8 3	Snare T9 6	Snare T9 Gate	
		T8 Kick Bass	Kick T9 1	Kick T9 2	
		Kick T8 1	Kick T9 3	Kick T9 5	
		Snare T8 Rim	Snare T9 Rim	Snare T9 Rim	
		Snare T8 2	Snare T9 1	Snare T9 1	
		Clap T9	Clap T9	Clap T9	
		Snare T8 1	Snare T9 2	Snare T9 2	
		Tom T8 1	Tom T9 1	Tom T9 1	
		Hi-Hat Closed T8	Hi-Hat Closed T9	Hi-Hat Closed T8	
		Tom T8 2	Tom T9 2	Tom T9 2	
		Hi-Hat Pedal T8	Hi-Hat Pedal T9	Hi-Hat Pedal T9	
		Tom T8 3	Tom T9 3	Tom T9 3	
		Hi-Hat Open T8	Hi-Hat Open T9	Hi-Hat Open T9	
		Tom T8 4	Tom T9 4	Tom T9 4	
		Tom T8 6	Tom T9 5	Tom T9 5	
		Crash Cymbal T8	Crash Cymbal T9	Crash Cymbal T9	
		Tom T8 7	Tom T9 6	Tom T9 6	
		Ride Cymbal T9	Ride Cymbal T9	Ride Cymbal T9	
		China Cymbal 2	China Cymbal 2	Crash Cymbal 4	
		RideCymbal Cup 2	RideCymbal Cup 2	RideCymbal Cup 2	
		Tambourine RX5	Tambourine RX5	Tambourine Hit	
		Splash Cymbal	Splash Cymbal 2	Splash Cymbal 2	
		Cowbell T8	Cowbell 1	Cowbell 1	
		Crash Cymbal 4	Crash Cymbal 4	Crash Cymbal 1	
		Vibraslap	Cowbell T8	Cowbell T8	
		Ride Cymbal 3	Ride Cymbal 3	Ride Cymbal 3	

Oct.+3

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [3]					
HipHop Kit	Key off	Drum Machine	Key off	Break Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Surdo Mute	Surdo Mute	Surdo Mute	
D-1	D#-1	Surdo Open	Surdo Open	Surdo Open	
E-1		Hi Q	Hi Q	Hi Q	
F-1	F#-1	Whip Slap	Whip Slap	Whip Slap	
G-1	G#-1	Scratch H	Scratch H	Scratch H	
A-1	A#-1	Scratch L	Scratch L	Scratch L	
B-1		Hi-HatClosedT8 2	Snare Drum&Bass1	Finger Snap	
C0	C#0	Tom T8 3	Kick Break 2	Snare Break 8	
D0	D#0	Hi-Hat Open T8 2	Snare Distortion	Snare Break 9	
E0		Tom T8 6	Kick Tek Power	Hi-HatClosedBrk1	*
F0	F#0	Crash T8	KickDistortionRM	Hi-HatClosedBrk2	*
G0	G#0	Triangle Mute	BassDrumHardLong	Kick Break Deep	
A0	A#0	Triangle Open	BassDrumTekPower	Snare Hip	
B0		Wind Chimes	Bass Drum Dist 5	Snare Lo-Fi	
C1	C#1	TambourineLight2	Bass Drum Dist 3	Snare Clappy	
D1	D#1	TambourineLight1	Bass Drum Dist 1	Snare LdwH Mono	
E1		Kick HipHop 9	BD Drum&Bass	Snare Rock Roll	*
F1	F#1	Hi-HatClosed Tek	Bass Drum Blip	Snare Gate 1	
G1	G#1	Kick Gate	BassDrumAnalogSm	Snare Mid	
A1	A#1	Hi-HatOpen Lo-Fi	Kick T8 2	Snare Break Rim	
B1		KickGranCasaOpen	Kick T8 3	Kick Break Heavy	
C2	C#2	Hi-HatReverseD&B	Kick T9 HD 3	Snare Hip Rim 4	
D2	D#2	Kick HipHop 1	Kick T9 2	Kick Break 2	
E2		Kick Analog CR	Kick T9 4	Kick Break 1	
F2	F#2	SnareAnalogSmRim	Snare T9 Rim	Snare Hip Rim 1	
G2	G#2	Snare HipHop 1	Snare T9 1	Snare Break 3	
A2	A#2	Snare Clappy	Clap T9	Snare Break 1	
B2		Snare HipHop 2	Snare T9 4	Snare Break 2	
		Floor Tom L	Tom T9 1	Tom Break 1	
		Hi-HatClosed Hip	Hi-Hat Closed T9	HHClosedRockSoft	
		Low Tom	Tom T9 2	Tom Break 2	
		Hi-Hat Pedal Hip	Hi-Hat Pedal T9	Hi-Hat PedalRock	
		Mid Tom L	Tom T9 3	Tom Break 3	
		Hi-Hat Open Hip	Hi-Hat Open T9	HH HalfOpen Rock	
		High Tom	Tom T9 4	Tom Break 4	
		Ride Cymbal 3	Tom T9 5	Tom Break 5	
		Crash Cymbal 3	Crash Cymbal T9	Crash Cymbal 1	
		Shaker 2	Conga T8 1	Tom Break 6	
		ScratchBDForward	Ride Cymbal T9	Ride Cymbal 3	
		ScratchBDRReverse	Conga T8 2	China Cymbal 2	
		Kick HipHop 2	Analog Click	RideCymbal Cup 2	
		SnareHipHopRim 2	Claves T8 1	Tambourine 1 Hit	
		HipHop Clap 2	Maracas T8	Splash Cymbal 2	
		HipHop Snap 1	TambourineAna CR	Cowbell 1	
		Snare HipHop 3	Analog Shaker	Crash Cymbal 2	
		Electric Clap 2	Cowbell T8	Cowbell RX11	
		Kick Hip Deep	CowbellAnalog CR	Ride Cymbal 2	

Lower
Keyboard

Upper
Keyboard

DRUMS [3]					
HipHop Kit	Key off	Drum Machine	Key off	Break Kit	Key off
C3	C#3	Kick HipHop 3	Snare T8 1	Bongo H	
D3	D#3	SnareHipHopRim 3	Snare T8 2	Bongo L	
E3		Snare HipHop 5	Snare T8 3	Conga H Tip	
F3	F#3	Electric Clap 1	Snare Analog CR	Conga H OpenSlap	
G3	G#3	Handbell H	Snare Jungle 1	Conga H Open	
A3	A#3	Kick HipHop 4	Snare Drum&Bass2	Bongo 2 H	
B3		HipHop Clap 3	Snare Hip 1	Bongo 2 L	
C4	C#4	HipHop Snap 2	Snare R&B 1	Conga Open	
D4	D#4	SnareHipHopRim 5	Snare R&B 2	Agogo L	
E4		HipHop Flex 1	Snare Hip 1	Cabasa	
F4	F#4	HipHop Flex 2	Snare Wood	Maracas Slur	
G4	G#4	Shaker 2	Snare Timbre	Timbale H	
A4	A#4	Kick HipHop 5	Hi-HatClosedT8 1	Timbale L	
B4		SnareHipHopRim 4	Hi-Hat Open T8 1	Scratch H 3	*
C5	C#5	Snare HipHop 6	Hi-HatClosedT8 2	Scratch Down	*
D5	D#5	Snare HipHop 11	Hi-Hat Open T8 2	Claves	
E5		Kick HipHop 10	Hi-Hat Pedal Aco	Wood Block H	
F5	F#5	Snare HipHop 7	Hi-HatClosed Aco	Wood Block L	
G5	G#5	HipHop Clap 5	Hi-Hat Open Aco	Scratch H 2	
A5	A#5	Conga H Tip	Hi-HatClosedLoFi	Scratch L 2	
B5		Conga H Heel	Hi-HatOpen Lo-Fi	Triangle Mute	
C6	C#6	Conga H Open	Hi-HatClosed Syn	Triangle Open	
D6	D#6	Conga L Open 1	Hi-Hat Open Syn	Kick Break 3	
E6		Conga L Open 2	Analog Shaker 1	Kick Break 4	
F6	F#6	Kick HipHop 8	Tambourine RX5 2	Kick Break 5	*
G6	G#6	HipHop Clap 6	Tambourine 1 Hit	Kick Break 6	
A6	A#6	Snare T8 1	Electric Cowbell	Kick Break 7	
B6		Snare T8 1 H	Conga T8 3	Hi-HatClosedBrk3	
C7	C#7	HipHop Clap 7	ElectricTriangle	Snare Break 4	
D7	D#7	Tom T8 1	Claves T8 2	Snare Break 5	
E7		Hi-HatClosedT8 2	Analog Shaker 2	Snare Break 6	
F7	F#7	Tom T8 2	Electric Clap 1	Snare Break 7	
G7	G#7				
A7	A#7				
B7					
C8	C#8				
D8	D#8				
E8					
F8	F#8				
G8					

Oct.+3

124

Oct.+3

Oct.+3127

Oct.+3

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [5]					
Punchy EDM Kit	Key off	Electro Kit 2	Key off	Dubstep Kit	Key off
C-2	C#-2	Slice 1 PE			
D-2	D#-2	Slice 2 PE			
E-2		Slice 3 PE			
F-2	F#-2	Slice 4 PE			
G-2	G#-2	Slice 5 PE			
A-2	A#-2	Slice 6 PE			
B-2		Slice 7 PE			
C-1	C#-1	Slice 8 PE			
D-1	D#-1	Slice 9 PE			
E-1		Slice 10 PE			
F-1	F#-1	Slice 11 PE			
G-1	G#-1	Slice 12 PE			
A-1	A#-1	Slice 13 PE			
B-1		Slice 14 PE			
C0	C#0	Loop Kick PE	Kick 5 EK	Kick 4 DS	
D0	D#0	Loop Hi-Hat PE	Kick 6 EK	Kick 5 DS	
E0		Loop Snare PE	SFX 6 EK	Digital DS	*
F0	F#0	Kick 1 PE	SFX 7 EK	PinkNoise Down 1	*
G0	G#0	Hat Close 1 PE	Kick 3 EK	WhiteNoiseDown 2	*
A0	A#0	Snare 1 PE	Kick 4 EK	PinkNoise Down 2	*
B0		Clap+Snare PE	SFX 12 EK	Boomer DS	*
C1	C#1	Snare 2 PE	SFX 11 EK	Synth Scratch DS	*
D1	D#1	Tom 1 PE	SFX 10 EK	Bouncer DS	*
E1		Tom 2 PE	SFX 9 EK	Tin Cowbell DS	
F1	F#1	Kick 2 PE	SFX 8 EK	RevFIngrSnare DS	*
G1	G#1	Snare 3 PE	Kick 2 EK	Kick 10 DS	
A1	A#1	Snare 4 PE	Snare 2 EK	Snare 3 DS	
B1		Tom 3 PE	Snare 3 EK	Clap 4 DS	
C2	C#2	Tom 4 PE	Clap 6 EK	Snare 4 DS	
D2	D#2	Tom 5 PE	Snare 1 EK	Snare 11 DS	*
E2		Tom 6 PE	Snare 4 EK	Snare 5 DS	
F2	F#2	Snare 5 PE	Snare 10 EK	Snare T9 3	
G2	G#2	Snare 6 PE	Snare 5 EK	Snare 6 DS	
A2	A#2	Kick 3 PE	Clap 5 EK	Clap 3 DS	
B2		Snare 7 PE	Kick 11 EK	Kick 2 DS	*
		Kick 4 PE	Clap 2 EK	Clap 2 DS	
		Kick 5 PE	Kick 1 EK	Kick 3 DS	
		Snap 1 PE	Kick 8 EK	Kick 1 DS	*
		Snare 8 PE	Rim Shot EK	Rim Shot DS	
		Clap 1 PE	Snare 9 EK	Snare 1 DS	
		Snare 9 PE	Clap 1 EK	Clap 1 DS	
		Tom 7 PE	Snare T9 1	Snare 2 DS	
		Hat Close 2 PE	Tom 1 EK	Tom T9 1	
		Tom 8 PE	Hat Close 1 EK	Hat Close 1 DS	
		Hat Close 3 PE	Tom 2 EK	Tom T9 2	
		Tom 9 PE	Hat Close 2 EK	Hat Pedal DS	
		Hat Open PE	Tom 3 EK	Tom T9 3	
		Tom 10 PE	Hat Open 3 EK	Hat Open 1 DS	
		Tom 11 PE	Tom 4 EK	Tom T9 4	
		Crash 1 PE	Tom 5 EK	Tom T9 5	
		Snare 10 PE	Crash Cymbal T9	Crash Cymbal T9	
		Ride 1 PE	Tom 6 EK	Tom T9 6	
		Impact 1 PE	Ride Cymbal T9	Ride Cym T9	
		Ride 2 PE	Crash Cymbal 4	Crash Cymbal 4	
		Tambourine PE	Ride Cup 2	Ride Cup 2	
		Crash 2 PE	Tambourine 82P	Tambourine 82P	
		Wood Block PE	Splash Cymbal 2	Splash Cymbal 2	
		Crash 3 PE	Cowbell 80R	Cowbell L 82P	
		Snare 11 PE	Crash Cymbal 2	Crash Cymbal 2	
		Snare 12 PE	Cowbell T8	Cowbell T8	
			Ride Cymbal 3	Ride Cymbal 3	

Lower
Keyboard

Upper
Keyboard

Oct.+1

Oct.+2

Oct.+3

C3	C#3
D3	D#3
E3	
F3	F#3
G3	G#3
A3	A#3
B3	
C4	C#4
D4	D#4
E4	
F4	F#4
G4	G#4
A4	A#4
B4	
C5	C#5
D5	D#5
E5	
F5	F#5
G5	G#5
A5	A#5
B5	
C6	C#6
D6	D#6
E6	
F6	F#6
G6	G#6
A6	A#6
B6	
C7	C#7
D7	D#7
E7	
F7	F#7
G7	G#7
A7	A#7
B7	
C8	C#8
D8	D#8
E8	
F8	F#8
G8	

DRUMS [5]					
Punchy EDM Kit	Key off	Electro Kit 2	Key off	Dubstep Kit	Key off
Snare 13 PE		Bongo H 80R		Bongo H 82P	
Snare 14 PE		Bongo L 80R		Bongo L 82P	
Snare 15 PE		Conga Mute 80R		Conga Mute 82P	
Clap 2 PE		Conga H 80R		Conga H 82P	
Snap 2 PE		Conga L 80R		Conga L 82P	
Snap 3 PE		Timbale H		Timbale H	
Snare 16 PE	*	Timbale L		Timbale L	
Snare 17 PE		Agogo H 80R		Cowbell H 82P	
Snare 18 PE		Agogo L 80R		Cowbell M 82P	
Shaker 1 PE		Cabasa 80R		Cabasa 81P	
Shaker 2 PE		Cabasa 81R	*	Maracas Slur	
Snare 19 PE		Vox Drum L		Vox Drum L	
Snare 20 PE		Vox Drum H		Vox Drum H	
Snare 21 PE		SFX 5 EK		Guero Short	
Snare 22 PE		SFX 4 EK	*	Guero Long	*
Snare 23 PE		SFX 1 EK		Claves 83P	
Hat Close 4 PE		SFX 2 EK		Wood Block H	
Hat Close 5 PE		SFX 3 EK		Wood Block L	
Hat Close 6 PE		Clap 8 EK		Hat Close 2 DS	
Hat Close 7 PE		Clap 4 EK		Hat Close 3 DS	
Hat Close 8 PE		Hat Open 1 EK	*	Triangle Mute	
Hat Close 9 PE		Hat Open 2 EK	*	Triangle Open	
Hat Close 10 PE		Hat Open 4 EK	*	Hat Open 2 DS	
Shaker 3 PE		Kick 7 EK		Kick 6 DS	
Click 1 PE		Kick 10 EK		Kick 7 DS	
Side-Stick 1 PE		Kick 12 EK		Kick 8 DS	
Side-Stick 2 PE		Kick 9 EK		Kick 9 DS	
Click 2 PE		Snare 6 EK		Snare 7 DS	
Click 3 PE		Snare 8 EK		Snare 8 DS	
Click 4 PE		Snare 11 EK		Snare 9 DS	
Snare 24 PE		Snare 7 EK		Snare 10 DS	*
Brush Snare PE		Filter Kick		Filter Kick	
Snare 25 PE					
Snare 26 PE					
Clap 3 PE					
Clap 4 PE					
Snare 27 PE					
Side-Stick 3 PE					
Snare 28 PE					
Snare 29 PE					
Snare 30 PE					
Snare 31 PE					
Snare 32 PE					
Kick 6 PE					
Kick 7 PE					
Kick 8 PE					
Kick 9 PE					
Kick 10 PE					
Kick 11 PE					
Kick 12 PE					
Kick 13 PE					
Kick 14 PE					
Kick 15 PE					
Kick 16 PE					
Tom 12 PE					
Tom 13 PE					
Tom 14 PE					
Impact 2 PE					
Impact 3 PE					
Noise Build 1 PE	*				
Noise Build 2 PE	*				
Noise Build 3 PE	*				
Noise Build 4 PE	*				
Noise Sweep PE	*				
Noise Crash 1 PE					
Noise Crash 2 PE					
Sine Drop 1	*				
Sine Drop 2	*				

Lower
Keyboard

Upper
Keyboard

Oct.–1

DRUMS [5]					
Trap Kit 1	Key off	Trap Kit 2	Key off	Schlager Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1				
D-1	D#-1				
E-1					
F-1	F#-1				
G-1	G#-1				
A-1	A#-1				
B-1					
C0	C#0	Dab Vox 1 NT	Kick 5 TP	LpElement 1a SC	
D0	D#0	Perc Pipe NT	Kick 6 TP	LpElement 1b SC	
E0		Crash FX NT	WhiteNoiseDown 1	LpElement 1c SC	
F0	F#0	Ride 1 NT	PinkNoise Down 1	LpElement 1d SC	
G0	G#0	Hat Close 1 NT	WhiteNoiseDown 2	LpElement 1e SC	
A0	A#0	Kick 1 NT	PinkNoise Down 2	LpElement 1f SC	
B0		Kick 2 NT	FNS 1 TP	LpElement 1g SC	
C1	C#1	Kick 3 NT	FNS 2 TP	LpElement 1h SC	
D1	D#1	Kick 4 NT	SFX 1 TP	LpElement 1i SC	
E1		Kick 5 NT	SFX 2 TP	LpElement 1f SC	
F1	F#1	Kick 6 NT	SFX 3 TP	NoiseUp SC	*
G1	G#1	Kick 7 NT	Kick 11 TP	Kick TB SC	
A1	A#1	Kick 8 NT	Perc 4 TP	LpElement 2a SC	
B1		Side-Stick NT	Clap 1 TP	LpElement 2b SC	
C2	C#2	Snare 1 NT	Clap 1 83P	LpElement 2c SC	
D2	D#2	Clap 1 NT	Snare 5 TP	LpElement 2d SC	
E2		Snare 2 NT	Snare 6 TP	LpElement 2h SC	
F2	F#2	Tom 1 NT	Snare T9 3	LpElement 2i SC	
G2	G#2	Hat Close 2 NT	Snare 3 TP	Snare 1 SC	
A2	A#2	Tom 2 NT	Clap 2 TP	Snare 1 83P	
B2		Hat Close 3 NT	Kick 2 TP	Kick 2 81P	
		Kick 9 NT	Clap 3 TP	Snare 4 SC	
		Hat Open NT	Kick 1 TP	Kick 2 SC	
		Tom 3 NT	Kick 4 TP	Kick 1 SC	
		Tom 4 NT	Rim Shot TP	Side Stick Power	
		Crash 1 NT	Snare 1 TP	Snare 2 SC	
		Tom 5 NT	Clap 5 TP	Snare 3 SC	
		Ride 2 NT	Snare 2 TP	Snare 6 SC	
		Dab Vox 1 NT	Tom 1 TP	Tom 1 SC	
		Knock NT	Hat Close 3 TP	Hat Close 1 SC	
		Perc Low NT	Tom 2 TP	Tom 2 SC	
		Strike NT	Hat Close 4 TP	Hat Close 2 SC	
		Perc Echo NT	Tom 3 TP	Tom 3 SC	
		Crash 2 NT	Hat Open 1 TP	Hat Open 1 SC	
		Crash 3 NT	Tom 4 TP	Tom 4 SC	
		Crash 4 NT	Tom 5 TP	Tom 5 SC	
			Crash Cymbal T9	Crash 1 SC	
			Tom 6 TP	Tom 6 SC	
			Ride Cymbal T9	Ride Acoustic 1	
			Crash Cymbal 4	Impact SC	
			Ride Cup 2	Crash Impact SC	
			Tambourine Hit	Tambourine	
			Splash Cymbal 2	Crash 2 SC	
			Cowbell 1 TP	Cowbell 1	
			Crash Cymbal 2	Crash 3 SC	
			Cowbell T8	Snare 5 SC	
			Ride Cymbal 3	Snare 7 SC	

Oct.+3

Lower
Keyboard

Upper
Keyboard

Oct.-1

DRUMS [5]					
Club Kit	Key off	Chill Kit	Key off	80s Pop Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1			Hat 2 Close 81P	
D-1	D#-1			Hat 2 Open 81P	
E-1				Hat 3 Close 81P	
F-1	F#-1			Hat 3 Open 81P	
G-1	G#-1			Hat 1 Close 83P	
A-1	A#-1			Hat 1 Open 83P	
B-1				Clap 1 83P	
C0	C#0	Claves CL	Claves CL	Clap 3 81P	
D0	D#0	Clap 1 CL	Swarm CH	Metronome 2 83P	
E0		Clap 2 CL	Turn Table CH	Metronome 1 83P	
F0	F#0	Clap 3 CL	SE 1 CH	Side Stick 1 83P	
G0	G#0	Clap 4 CL	SE 2 CH	Kick 2 83P	*
A0	A#0	Snare 1 CL	SE 3 CH	Side Stick 3 82P	
B0		Snare 2 CL	SE 4 CH	Clap 1 82P	
C1	C#1	Snare 3 CL	Snap 1 CH	Clap 2 81P	
D1	D#1	Snare 4 CL	Snare 1 CH	Side Stick 4 81P	
E1		Kick 1 CL	Kick 1 CH	Side Stick 2 81P	
F1	F#1	Snare 5 CL	Snare 2 CH	Snare 4 81P	
G1	G#1	Kick 2 CL	Kick 2 CH	Snare 3 81P	
A1	A#1	Kick 3 CL	Kick 3 CH	Snare 1 83P	
B1		Snare 6 CL	Side-Stick CH	Kick 2 81P	
C2	C#2	Snare 7 CL	Snare 3 CH	Snare 2 83P	
D2	D#2	Clap 5 CL	Clap 3 CL	Kick 1 83P	
E2		Snare 8 CL	Snare 4 CH	Kick 1 82P	
F2	F#2	Tom 1 CL	Tom 1 CH	Side Stick 1 82P	
G2	G#2	Hat Close CL	Hat Close 1 CH	Snare 2 82P	
A2	A#2	Tom 2 CL	Tom 2 CH	Clap 1 P-Up 82P	
B2		Hat Pedal CL	Hat Close 2 CH	Snare 1 82P	
C2	C#2	Tom 3 CL	Tom 3 CH	Tom A6 82P	
D2	D#2	Hat Open CL	Hat Open CH	Hat 1 Close 82P	*
E2		Tom 4 CL	Tom 4 CH	Tom A5 82P	
F2	F#2	Tom 5 CL	Tom 5 CH	Hat 1 Pedal 82P	
G2	G#2	Crash 1 CL	Crash 1 CH	Tom A4 82P	
A2	A#2	Tom 6 CL	Tom 6 CH	Hat 1 Open 82P	
B2		Ride 1 CL	Ride 1 CL	Tom A3 82P	
		China Cymbal CL	Crash 2 CH	Tom A2 82P	
		Ride 2 CL	Ride 2 CL	Crash 1 PD	
		Tambourine 1 CL	Tambourine 1 CL	Tom A1 82P	
		Crash 2 CL	Splash CH	Ride 1 82P	
		Wood Block CL	Wood Block 1 CH	China Cymbal 82P	
		Crash 3 CL	Crash 3 CL	Ride Bell 82P	
		SE 14 CL	Percussion 4 CL	Tambourine 82P	
		Ride 3 CL	Ride 3 CL	Splash 82P	
				Cowbell 82P	
				Crash 2 PD	
				Cowbell T8	
				Ride 2 82P	

Lower
KeyboardUpper
Keyboard

Oct.–1

DRUMS [5]					
80s R&B Kit	Key off	Massive Dance	Key off	Chinese Pop Drum	Key off
C-2	C#-2	Scratch L 2	*		
D-2	D#-2	ScratchBDForward			
E-2		ScratchBDReverse			
F-2	F#-2	Tape Stop MD	*		
G-2	G#-2	Turn Table CH	*		
A-2	A#-2	Impact MD	*		
B-2		Impact Hi MD	*		
C-1	C#-1	Crash Impact MD	*		
D-1	D#-1	Noise Build 1 PE	*		
E-1		Noise Build 3 PE	*		
F-1	F#-1	Impact Zap MD			
G-1	G#-1	Sine Drop MD			
A-1	A#-1	Super Low MD	*		
B-1		Hat 3 Close 80R		Hat Tip 00 PD	
C0	C#0	Hat 3 Open 80R		Hat Edge 00 PD	
D0	D#0	Hat 1 Close 80R		Hat Tip 10 PD	
E0		Hat 1 Open 80R		Hat Edge 10 PD	
F0	F#0	Hat 3 Close 81R		Hat Edge 25 PD	
G0	G#0	Hat 3 Open 81R		Hat Edge 50 PD	
A0	A#0	Hat 1 Close 81R		Hat Edge 75 PD	
B0		Hat 1 Open 81R		Hat Edge 99 PD	
C1	C#1	Metronome 2 81R		Hat Pdl Close PD	
D1	D#1	Metronome 1 81R		Hat Pedal Splash	
E1		Side Stick 4 81R		Seq Click L	
F1	F#1	Kick 3 81R	*	Seq Click H	
G1	G#1	Side Stick 2 81R		SB Mt Off Ed Prs	
A1	A#1	Clap 3 81R		Snare 4 noRim PD	
B1		Clap 1 81R		Snare 3 noRim PD	
C2	C#2	Clap 2 80R		Snare 2 noRim PD	
D2	D#2	Side Stick 4 80R		Snare Roll PD	*
E2		Clap 3 80R		Snare 4 PD	
F2	F#2	Snare 4 81R		Snare 3 PD	
G2	G#2	Side Stick 3 80R		Stick Count VO	
A2	A#2	Kick 2 81R		Kick 3 PD	
B2		Snare 3 81R		Snare 1 OpRim PD	
		Kick 2 80R		Kick 2 PD	
		Kick 1 80R		Kick 1 PD	
		Side Stick 1 80R		Snare 1 Stick PD	
		Snare 2 80R		Snare 1 PD	
		Clap 1 80R		Clap Power	
		Snare 1 80R		Snare 2 PD	
		Tom A6 81R		Tom 1 PD	
		Hat 2 Close 81R	*	Hat Edge 00 PD	
		Tom A5 81R		Tom 2 PD	
		Hat 2 Pedal 81R		Hat Pdl Close PD	
		Tom A4 81R		Tom 3 PD	
		Hat 2 Open 81R		Hat Edge 75 PD	
		Tom A3 81R		Tom 4 PD	
		Tom A2 81R		Tom 5 PD	
		Crash 1 81R		Crash 1 PD	
		Tom A1 81R		Tom 6 PD	
		Ride Cymbal 81R		Ride Tip PD	
		China Cymbal 81R		China Cymbal PD	
		Ride Bell 80R		Ride Cup PD	
		Tambourine 80R		Tambourine	
		Splash 80R		Splash Cymbal PD	
		Cowbell 80R		Cowbell 1 JB	
		Crash 2 81R		Crash 2 PD	
		Vibraslap		Vibraslap	
		Crash 1 RD		Ride Acoustic 2	

Lower
Keyboard

Upper
Keyboard

C3	C#3
D3	D#3
E3	
F3	F#3
G3	G#3
A3	A#3
B3	
C4	C#4
D4	D#4
E4	
F4	F#4
G4	G#4
A4	A#4
B4	
C5	C#5
D5	D#5
E5	
F5	F#5
G5	G#5
A5	A#5
B5	
C6	C#6
D6	D#6
E6	
F6	F#6
G6	G#6
A6	A#6
B6	
C7	C#7
D7	D#7
E7	
F7	F#7
G7	G#7
A7	A#7
B7	
C8	C#8
D8	D#8
E8	
F8	F#8
G8	

Oct.+1

Oct.+2

Oct.+3

DRUMS [5]					
80s R&B Kit	Key off	Massive Dance	Key off	Chinese Pop Drum	Key off
Bongo H 80R		Snare DS Rim MD		Da Gu 2 Soft	
Bongo L 80R		Snare T8 Rim MD		Da Gu 2 Hard	
Conga Mute 80R		Snare T9 Rim MD		Da Gu Ens Center	
Conga H 80R		Snare Hip Rim MD		Da Gu Ens Rim	
Conga L 80R		Snare Jungle MD		Da Luo	
Timbale H		Snare T9 1 MD		Pai Gu 1	
Timbale L		Snare Elec MD		Da Luo Crash	
Agogo H 80R		Snare RX5 MD		Pai Gu 2	
Agogo L 80R		Snare 3 TEDM		Nao Bo Muted	
Cabasa 80R		Snare Gate 1 MD		Pai Gu 3	
Tom T8 1		Snare Elec 3 MD		Nao Bo	
Tom T8 2		Snare Gate 2 MD		Pai Gu 4	
Tom T8 3		Snare Elec 4 MD		Pai Gu 5	
Tom T8 4		Snare Bounce MD		Xiao Bo 1 Muted	
Tom T8 5		Snare T9 2 MD		Ban Gu Left	
Claves T8		Snare 33 PE		Xiao Bo 1	
Tom A6 80R		Clap 4 CL		Kuai Ban Big	
Tom A5 80R		Clap House 2 MD		Mu Yu 1	
Tom A4 80R		Clap 6 EK		Xiao Bo 2 Muted	
Tom A3 80R		Clap 1 EDM		Mu Yu 2	
Tom A2 80R		Clap 3 NT		Xiao Bo 2	
Tom A1 80R		Clap Hip Hop MD		Mu Yu 3	
Cabasa 81R		Snap 1 CH		Xiao Luo 2	
		Snap 1 PE		Mu Yu 4	
		Snap 3 NT		Mu Yu 5	
		Snap Hip Hop MD		Jing Luo 1	
		Tambourine Op MD		Shou Gu 2 Center	
		Tambourine Hit		Jing Luo 2	
		Tambourine H PE		Shou Gu 1 Center	
		Tambourine 82P		Jingle Bells	
		HatCIs HipHop MD		Jing Luo 3	
		HatOp HipHop MD		Wind Chimes	
		Hat Close R&B MD			
		Hat Open R&B MD			
		HatCIs Elect MD			
		HatOp Elect MD			
		Tom Gate 1 MD			
		Tom Gate 2 MD			
		Tom Gate 3 MD			
		Tom PopRock 1 MD			
		Tom PopRock 2 MD			
		Tom PopRock 3 MD			
		Cabasa 81P			
		Shaker 1 SC			
		Shaker 3 SC			
		Claves 83P			
		Triangle Mute MD			
		Triangle Open MD			
		Cowbell MD			
		Wind Chime Dn MD			
		Wind Chime Up MD			
		Vocal 1 MD			
		Vocal 2 MD			
		Vocal 3 MD			
		Beat Box 1 MD			
		Beat Box 2 MD			
		Beat Box 3 MD			
		Reverse Cym 1 MD	*		
		Reverse Cym 2 MD	*		
		RevFlngrSnare DS	*		
		Brush Snare PE	*		
		Reverse 1 TEDM	*		
		Reverse 2 TEDM	*		
		Rev BD Electro	*		
		Rev BD Analog90	*		
		Percussion 6 CH			
		Clock Tick MD			
		Clock Tack MD			

Lower
Keyboard

Upper
Keyboard

Oct.-1

SFX [1]					
Live! SFX Kit 2	Key off	Noise Kit	Key off	VocalEffects Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1				
D-1	D#-1				
E-1					
F-1	F#-1				
G-1	G#-1				
A-1	A#-1				
B-1					
C0	C#0				
D0	D#0				
E0					
F0	F#0				
G0	G#0				
A0	A#0				
B0					
C1	C#1	Phone Call 2	*	White Noise	*
D1	D#1	Door Squeak 2	*	Pink Noise	*
E1		Door Slam 2	*	WhiteNoiseDown 1	*
F1	F#1	Scratch Cut	*	PinkNoise Down 1	*
G1	G#1	Scratch Split	*	WhiteNoiseDown 2	*
A1	A#1	Wind Chimes	*	PinkNoise Down 2	*
B1		Telephone Ring 2	*	White Noise Up 2	*
C2	C#2			White Noise Up 1	*
D2	D#2			Pink Noise Up	*
E2				WhiteNoiseUp Rel	*
F2	F#2			PinkNoise Up Rel	*
G2	G#2			WhiteNoiseUp LFO	*
A2	A#2			PinkNoise Up LFO	*
B2					
		CarEngn Ignition	*		
		Car Tires Squeal	*		
		Car Passing	*		
		Car Crash	*		
		Siren 2	*		
		Train 2	*		
		Jet Plane 2	*		
		Starship	*		
				Male Ha 1	*
				Female Ha 1	*
				Male Ha 2	*
				Male Ha 3	*
				Male Bh 1	*
				Female Bh 1	*
				Male Kh 1	*
				Female Kh 1	*
				Male Ph 1	*
				Female Ph 1	*
				Male Th 1	*
				Female Th 1	*
				Male Bh 2	*
				Female Bh 2	*
				Male Kh 2	*
				Female Kh 2	*
				Male Ph 2	*
				Female Ph 2	*
				Male Th 2	*
				Female Th 2	*
				Male Ha 4	*
				Female Ha 2	*
				Male Ha 5	*
				Male Ha 6	*

Lower
Keyboard

Upper
Keyboard

Oct.–1

SFX [1]					
Cuban Kit	Key off	Arabic Kit	Key off	Turkish Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1			Asma Davul L	
D-1	D#-1			Asma Davul R	
E-1				Asma Davul Side	
F-1	F#-1			Asma Davul Both	
G-1	G#-1			KoltukDavul Flam	
A-1	A#-1			KoltukDavul Teke	
B-1				Koltuk Davul Tek	
				Koltuk Davul Dum	
				Bendir Teke Flam	
				Bendir Teke Dead	
				Bendir Tek Dead	
C0	C#0	Conga H Tip			
D0	D#0	Conga H Heel			
E0		Conga H Open	Nakarazan Dom		
F0	F#0	Conga H Mute	Cabasa		
G0	G#0	Conga H SlapOpen	Nakarazan Edge		
A0	A#0	Conga H Slap	Hager Dom		
B0		Conga H SlapMute	Hager Edge		
		Conga L Tip	Bongo H		
		Conga L Heel	Bongo L		
		Conga L Open	Conga H Mute		
		Conga L Mute	Conga H Open		
		Conga L SlapOpen	Conga L		
		Conga L Slap	Zagrouda H		
		Conga L Slide	Zagrouda L		
		Bongo H Open 1 f	Kick Soft		
		Bongo H Open 3 f	Side Stick		
		Bongo H Rim	Snare Soft		
		Bongo H Tip	Arabic Hand Clap		
		Bongo H Heel	Snare Drum		
		Bongo H Slap	Floor Tom L		
		Bongo L Open 1 f	Hi-Hat Closed		
		Bongo L Open 3 f	Floor Tom H		
		Bongo L Rim	Hi-Hat Pedal		
		Bongo L Tip	Low Tom		
		Bongo L Heel	Hi-Hat Open		
		Bongo L Slap	Mid Tom L		
		Timbale L	Mid Tom H		
			Crash Cymbal 1		
			High Tom		
			Ride Cymbal 1		
			Crash Cymbal 2		
		Paila L	Duhulla Dom		
		Timbale H	Tambourine		
			Duhulla Tak		
			Cowbell		
			Duhulla Sak		
			Claves		
		Paila H	Doff Dom		

Lower
KeyboardUpper
Keyboard

Oct.–1

SFX [1]				SFX [2]		
Chinese Kit	Key off	Orchestra Perc	Key off	Ambi Cinematic	Key off	Revo
C-2	C#-2			Bow Low	*	
D-2	D#-2			Tam-tam		
E-2				Tam-tam High		
F-2	F#-2			Tam-tam Low		
G-2	G#-2			Handmade Tam-tam		
A-2	A#-2			Asian Tam-tam		
B-2				Gong		
C-1	C#-1			Crash Low		
D-1	D#-1			Splash Cymbal		
E-1				Splash Short		
F-1	F#-1			Ride Top		
G-1	G#-1			Ride Cup		
A-1	A#-1			Cymbal Roll Low	*	
B-1				Cymbal Top Low		
C0	C#0	Symphonic Gong 1		Cymbal Roll Med	*	
D0	D#0	Symphonic Gong L	*	Cymbal Top Med		
E0		Symphonic Gong 2		Cymbal Roll High	*	
F0	F#0	Timpani E		Cymbal Top High		
G0	G#0	Timpani F		Hand Cym Low		
A0	A#0	Timpani F#		Hand Cym Low S		
B0		Timpani G		Hand Cym Med		
C1	C#1	Timpani G#		Hand Cym Med S		
D1	D#1	Timpani A		Hand Cym High		
E1		Timpani A#		Hand Cym High S		
F1	F#1	Da Cha 2		Hammer Low		
G1	G#1	Da Gu mp		Hammer Med Low		
A1	A#1	Da Gu Rim		Hammer Med High		
B1		Da Gu f		Hammer High		
C2	C#2	Da Gu Hand		Taiko Gong Front		
D2	D#2	Da Gu Roll	*	Taiko Gong Back		
E2		Pai Gu 4		Taiko Low		
F2	F#2	Pai Gu 4 High		Taiko Medium		
G2	G#2	Pai Gu 3		Taiko High		
A2	A#2	Pai Gu 3 High		GranCassa L Soft		
B2		Pai Gu 2		GranCassa L Lthr		
C2	C#2	Pai Gu 2 High		GranCassa L Wood		
D2	D#2	Pai Gu 1		GranCassa M Soft		
E2		Luo High 1		GranCassa M Wood		
F2	F#2	Gong Batter		GranCassa H Soft		
G2	G#2	Jin Luo		GranCassa H Lthr		
A2	A#2	Luo High 2		GranCassa H Wood		
B2		Luo Mid-Low		Floor Tom Low		
C2	C#2	Luo		Floor Tom High		
D2	D#2	Jin Luo Low		Mid Tom Low		
E2		Da Cha 1		Mid Tom High		
F2	F#2	Da Cha Effect		High Tom		
G2	G#2	Zhong Cha		Roto Tom Low L		
A2	A#2	Xiao Cha Effect		Roto Tom Low		
B2		Xiao Cha		Roto Tom Med L		
C2	C#2	Mang Luo Low		Roto Tom Med H		
D2	D#2	Mang Luo Mid		Roto Tom High		
E2		Qing		Orch Snare RH		
F2	F#2	Finger Bell		Orch Snare LH		
G2	G#2	Luo Big		Orch Snare Roll	*	
A2	A#2	Mu Yu Low		Orch Snare Flam		
B2		Mu Yu Mid-Low		Orch Snare Stick		
C2	C#2	Mu Yu Mid		March Snare LH		
D2	D#2	Mu Yu High		March Snare RH		
E2		Nan Bang Zi Roll	*	March Snare Roll	*	
F2	F#2	Nan Bang Zi		March Snare Flam		
G2	G#2	Ban Gu				
A2	A#2					
B2						

Lower
Keyboard

Upper
Keyboard

C3	C#3
D3	D#3
E3	
F3	F#3
G3	G#3
A3	A#3
B3	
C4	C#4
D4	D#4
E4	
F4	F#4
G4	G#4
A4	A#4
B4	
C5	C#5
D5	D#5
E5	
F5	F#5
G5	G#5
A5	A#5
B5	
C6	C#6
D6	D#6
E6	
F6	F#6
G6	G#6
A6	A#6
B6	
C7	C#7
D7	D#7
E7	
F7	F#7
G7	G#7
A7	A#7
B7	
C8	C#8
D8	D#8
E8	
F8	F#8
G8	

Oct.+1

Oct.+2

Oct.+3

SFX [1]				SFX [2]		
Chinese Kit	Key off	Orchestra Perc	Key off	Ambi Cinematic	Key off	Revo
Ban		Bongo H Stick		March Snare Stck		
Ban Gu Roll	*	Bongo L Stick		Snare LH		
ChineseOperaVo 1	*	Conga H Stick		Snare RH		
ChineseOperaVo 2	*	Conga L Stick		Snare Roll	*	
ChineseOperaVo 3	*	Whip		Snare Flam		
Yun Luo F		Rotating Tom 1		Sidestick		
Yun Luo F#		Tubular Bell L		Piccl Snare LH		
Yun Luo G		Rotating Tom 2		Piccl Snare RH		
Yun Luo G#		Tubular Bell M		Piccl Snare Roll	*	
Yun Luo A		Rotating Tom 3		Piccl Snare Flam		
Yun Luo A#		Tubular Bell H		Piccl Snare Stck		
Yun Luo B		Rotating Tom 4		Snare Ensemble		
Yun Luo C		Rotating Tom 5		Snare Ens Flam		
Yun Luo C#		Temple Block H		Snare Ens Roll	*	
Yun Luo D		Temple Block L		Snare Ens Cresc		
Yun Luo D#		Claves		Whip L		
Yun Luo E		Wood Block H		Whip H		
Yun Luo High F		Wood Block L		Wood Block L		
Yun Luo High F#		Anvil		Wood Block H		
Yun Luo High G		Triangle Roll	*	Block		
Yun Luo High G#		Triangle Mute		Boobam Tuned 1		•
Yun Luo High A		Triangle Open		Boobam Tuned 2		•
Yun Luo High A#		Bell Tree		Boobam Tuned 3		•
Yun Luo High B		Sleigh Bells		Boobam Tuned 4		•
Yun Luo High C		Wind Chimes		Boobam Tuned 5		•
				Boobam Tuned 6		•
				Boobam Tuned 7		•
				Boobam Tuned 8		•
				Boobam Tuned 9		•
				Bongo H		
				Bongo L		
				Conga H		
				Conga L		
				Triangle		
				Triangle Mute		
				Triangle Roll 1	*	
				Triangle Roll 2		
				Wind Chimes 1		
				Wind Chimes 2		
				Bell Tree Down		
				Bell Tree Up		
				Sleigh Bells		
				Finger Cymbal		
				Fngr Cym Rub Tip		
				Fngr Cym Hammer		
				Fngr Cym Roll		
				Tambourine 1		
				Tambourine1 Roll		
				Tambourine 2		
				Tambourine2 Roll		
				Castanets		
				Castanets Roll	*	
				Anvil		
				Cowbell Top		
				Cowbell Tip		
				Cuica		•
				Lion's Roar		
				Shaker L		•
				Shaker H		•
				Metal Shaker		•
				Rainmaker Fast	*	
				Rainmaker Slow	*	
				Spiral		

Oct.+3149

Lower
Keyboard

Upper
Keyboard

Oct.–1

SFX [2]					
Bass Drum Kit		Key off	Reverse BD Kit		Key off
Cymbal Kit		Key off			
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1				
D-1	D#-1				
E-1					
F-1	F#-1				
G-1	G#-1				
A-1	A#-1				
B-1					
C0	C#0				
D0	D#0				
E0					
F0	F#0				
G0	G#0				
A0	A#0				
B0					
C1	C#1				
D1	D#1				
E1					
F1	F#1				
G1	G#1				
A1	A#1				
B1					
C2	C#2				
D2	D#2				
E2					
F2	F#2				
G2	G#2				
A2	A#2				
B2					
			BD Electro	Rev BD Electro	
			BD FX Gate	Rev BD Fx Gate	
			BD Hammer	Rev BD Hammer	
			BD Analog Power	Rev BD AnaPower	
			BD Analog Dist 5		
			BD Analog Dist 6	Rev BD AnaDist 4	
			BD Analog Dist 4		
			BD Analog Dist 3	Rev BD AnaDist 3	
			BD Analog Dist 2	Rev BD AnaDist 2	
			BD Analog Tight	Rev BD AnaTight	
			BD Analog 94	Rev BD Analog 94	
			BD Analog Blip 2	Rev BD AnaBlip 2	
			BD Analog Rubb 2	Rev BD AnaRubb 2	
			BD Analog 93	Rev BD Analog 93	
			BD Analog 90	Rev BD Analog 90	
			BD Analog 83	Rev BD Analog 83	
			BD Analog 82	Rev BD Analog 82	
			BD Analog 92		
			BD Analog 91	Rev BD Analog 91	
			BD Analog Deep	Rev BD AnaDeep	
			BD Analog Hard 2		
			BD Analog Hard 1	Rev BD AnaHard	
			BD Analog Blip 1	Rev BD AnaBlip 1	
			BD Analog Rubb 1	Rev BD AnaRubb 1	Kick A
			BD Analog Loose	Rev BD AnaLoose	Timbale A
			BD Synth 1	Rev BD Synth 1	China Cymbal A
			BD Synth 2	Rev BD Synth 2	Crash Cymbal A
			BD Analog Dist 1	Rev BD AnaDist 1	Ride Cymbal A
			Ripper	Reverse Ripper	Splash Cymbal A
			BD Analog 70 L		
			BD Analog 70	Rev BD Analog 70	
			BD Analog 80	Rev BD Analog 81	Crash Cymbal B1
			BD Analog 80Long		Crash Cymbal B2
			BD Dry	Reverse BD Dry	Ride Cymbal B
			BD Dry Hard		
			BD Room 1		
			BD Soft	Reverse BD Soft	Crash Cymbal C
			BD Room 2	Rev BD Room 1	Ride Cymbal C
			BD Break Lo-fi 2	Rev BD BrkLofi 2	Brush Ride Cym C
			BD Break Lo-fi 1	Rev BD BrkLofi 1	Brush SizzlCym C
			BD&Hi-Hat Open	Rev BD&HH Open	
			BD Jungle 2		
			BD Jungle 1		Crash Cymbal D1
			BD Jungle 3	Rev BD Jungle	Crash Cymbal D2
			BD D&B 1	Reverse BD D&B 1	Crash Cymbal D3
			BD D&B 2	Reverse BD D&B 2	Ride Cymbal D
			BD RX5 1	Reverse BD RX5 1	Splash Cymbal D

Lower
KeyboardUpper
Keyboard

Oct.–1

SFX [2]					
Industrial Kit	Key off	Vocal Beatbox	Key off	ElectroVocal&SFX	Key off
C-2	C#-2			Analog G 1 VX	*
D-2	D#-2			Pitch 1 VX	*
E-2				Dance 1 VX	*
				Dance 2 VX	*
F-2	F#-2			Analog J 1 VX	*
				Fantastic 1 VX	*
G-2	G#-2			Fantastic 2 VX	*
				Fantastic 3 VX	*
A-2				Pitch 2 VX	*
	A#-2			Pitch 3 VX	*
B-2				Pitch 4 VX	*
				Analog J 2 VX	*
C-1	C#-1	Plastic Box Kick		Analog G 2 VX	*
D-1	D#-1	Ladder Hit	Kick 3 Ftbm 2 BB	Trap 1 VX	*
E-1		Metal Spring	Kick 5 Throat BB	Pop Rock 1 VX	*
		Alpha Impact	Kick 4 Throat BB	Pitch 5 VX	*
F-1	F#-1	Bravo Impact	Scratch 10 BB	Analog J 3 VX	*
		Charlie Impact	Scratch 11 BB	Analog J 4 VX	*
G-1	G#-1	Duct Tape Rip	Scratch 3 BB	Analog J 5 VX	*
		Noise Sweep	Scratch 12 BB	Analog J 6 VX	*
A-1	A#-1	Metal Tom	Kick 3 Ftbm 1 BB	Analog M 1 VX	*
B-1		Cinematic Sweep	Kick 6 Elec 2 BB	Vocoder 1 VX	*
		Knuckle Hit	ZtkPauu 1 BB	Vocoder 2 VX	*
		Scifi Sweep	ZtkPauu 2 BB	Vocoder 3 VX	*
C0	C#0	Giant Bass Drum	Kick 7 Throat BB	Trap One VX	*
D0	D#0	Impact FX 1	Breath3 BB	Trap Two VX	*
		Impact FX 2	Breath2 BB	Trap Three VX	*
E0		Impact FX 3	Breath1 BB	Trap Come on VX	*
		Impact FX 4	Breath4 BB	Trap 2 VX	*
F0	F#0	Impact FX 5	Vibrato BB	Trap 3 VX	*
G0	G#0	Glass Break	Snare 4 T-Sty BB	M Dub Step VX	*
		Canned Kick	Snare 6 ISCH BB	M Electro VX	*
A0	A#0	Metal Door 1	Snare 2 Clap BB	M Future Bass VX	*
B0		Dist Bass Drum 3	Kick 6 Elec 1 BB	M Hip Hop VX	*
		Dist Bass Drum 2	Snare 7 TSCH BB	M House VX	*
		Dist Bass Drum 1	Kick 2 Class BB	M Lo-fi VX	*
C1	C#1	Woodbox Kick 1	Kick 1 Class BB	M One VX	*
D1	D#1	Click	Snare 3 Stick BB	M Two VX	*
		Woodbox Kick 2	Snare 1 Class BB	M Three VX	*
E1		Clock	Snare 5 KCH BB	M Feel it VX	*
F1	F#1	Boxplosion	Snare 8 KUCH BB	M DJ VX	*
		Woodbox Kick 3	Tom 6 Classic BB	M Some noise VX	*
G1	G#1	Metal HiHat 1	Hat 1 Z-Style BB	M Feels good VX	*
		Metal HiHat 2	Tom 5 Classic BB	M Turn it up VX	*
A1	A#1	Metal HiHat 3	Hat 5 Tch-Sty BB	M Popping VX	*
B1		Metal HiHat 4	Tom 4 Classic BB	M Louder VX	*
		Metal HiHat 5	Hat 7 Open BB	M Beat it VX	*
		Metal HiHat 6	Tom 3 Classic BB	M Fire VX	*
C2	C#2	Oil Barrell 1	Tom 2 Classic BB	M Stop VX	*
D2	D#2	Oil Barrell 2	Crash Hi 1 BB	M One more VX	*
		Oil Barrell 3	Tom 1 Classic BB	M Oh my Gosh VX	*
E2		Oil Barrell 4	Crash Hi 2 BB	M Fly away VX	*
F2	F#2	Oil Barrell 5	China Cym 1 BB	M Bring it VX	*
		Oil Barrell 6	China Cym 2 BB	M Congrats VX	*
G2	G#2	Oil Barrell 7	Hat 8 Pedal BB	M Birthday VX	*
		Oil Barrell 8	FX Cymbal Hi BB	M Heat it up VX	*
A2	A#2	Iron Filings	Hat 6 Wd-Sty BB	M Scratch VX	*
		Iron Spring	Crash Lo 1 BB	M Skrrr skrrr VX	*
B2		Ladder Clap	Scratch 5 BB	M What's up VX	*
		Barn Door	Crash Lo 2 BB	M Yo VX	*

Lower
Keyboard

Upper
Keyboard

Oct.+1	C3	C#3	Stone Bag		Tom 5 Rim BB		F One VX	*
	D3	D#3	Dancing Can		Tom 4 Rim BB		F Two VX	*
	E3		Duct Tape Rip		Tom 3 Rim BB		F Three VX	*
	F3	F#3	Wheelsweep		Tom 2 Rim BB		F Let's go VX	*
	G3	G#3	Iron Bar Hi		Tom 1 Rim BB		F Come on VX	*
	A3	A#3	Iron Bar Lo		Now BB	*	F All right VX	*
	B3		Iron Sledge		GetReady BB	*	F Hands up VX	*
	C4	C#4	T.Bell Soft		Fanfare BB	*	F Uh huh VX	*
	D4	D#4	T.Bell Rim		Trumpet BB	*	F Yeah VX	*
	E4		T.Bell Muffle		Shaker BB		F Ready go VX	*
	F4	F#4	T.Bell Hard		Hat 2 S-Style BB		F Ready? VX	*
	G4	G#4	Car Door Slam		Scratch 1 BB	*	F Clap your VX	*
	A4	A#4	Small Metal Box		Scratch 2 BB	*	F Jump VX	*
	B4		Mixed Hit 1		Hat 3 NZ-Sty BB		F Power VX	*
	C5	C#5	Mixed Hit 2		Scratch 4 BB	*	F Ok VX	*
	D5	D#5	Mixed Hit 3		Hat 4 F-Style BB		F Ahaha VX	*
	E5		Mixed Hit 4		Can 2 BB		F Good time VX	*
	F5	F#5	Mixed Hit 5		Can 1 BB		F Chill VX	*
	G5	G#5	Mixed Hit 6		Tom 5 Electro BB		F Click VX	*
	A5	A#5	Mixed Hit 7		Tom 4 Electro BB		F Close eyes VX	*
	B5		Metal Clap		Tom 3 Electro BB		F Day VX	*
	C6	C#6	Pump		Tom 2 Electro BB		F Fight VX	*
	D6	D#6	Metal Shot FX		Tom 1 Electro BB		F Future VX	*
	E6		Metal Sneeze FX		Scratch 6 BB	*	F Good VX	*
F6	F#6	Industrial Snare		Scratch 7 BB	*	F Hey VX	*	
G6	G#6	Woodlog 1		Scratch 8 BB	*	F What VX	*	
A6	A#6	Woodlog 2		Scratch 9 BB	*	F Sing it VX	*	
B6		Woodlog 3		Peepthp 1 BB	*	F Look at me VX	*	
C7	C#7	Water Drop		Peepthp 2 BB	*	F Ikuyo VX	*	
D7	D#7	Gas Lighter	*	Laughter BB	*	F Hai VX	*	
E7		Gas Lighter On				F Yoisho VX	*	
F7	F#7	Metal Door 2				F Huh VX	*	
G7	G#7	Key Chain				Hey! VX	*	
A7	A#7	Measure Tape				Accent VX	*	
B7		MeasureTape Snap				Dance Pop VX	*	
C8	C#8	Stone Shelf				Horn DJ VX		
D8	D#8	Metal Rainpipe				Dub Step 1 VX	*	
E8						Pitch 6 VX	*	
F8	F#8					Pitch 7 VX	*	
G8						Clap HipHop 1 VX	*	
						Clap House VX	*	
						Clap DancePop VX	*	
						Clap HipHop 2 VX	*	
						Impact 1 VX	*	
						Pop Rock 2 VX	*	
						House 1 VX	*	
						Big Room 1 VX	*	
						Dub Step 2 VX	*	
						Analog G 3 VX	*	
						Analog M 2 VX	*	
						Dance 3 VX	*	
						Synth VX	*	
						Big Room 2 VX	*	
						House 2 VX	*	
						Impact 2 VX	*	
						Raspberry VX	*	
						Pop Rock 3 VX	*	
						Analog J 7 VX	*	
						Analog J 8 VX	*	
						Pop Rock 4 VX	*	
						Analog J 9 VX	*	
						Horn Cheer VX	*	
						Question! VX		
						Right VX		
						Wrong VX		
						Applause VX	*	
						Cheers VX		
						Depressed VX		

Lower
Keyboard

Upper
Keyboard

Oct.–1

SFX [2]					
Pop Latin Kit 2	Key off	Pop Latin 2 Comp	Key off	Indian Kit	Key off
C-2	C#-2				
D-2	D#-2				
E-2					
F-2	F#-2				
G-2	G#-2				
A-2	A#-2				
B-2					
C-1	C#-1	Cajon Low	Cajon Low LC		
D-1	D#-1	Cajon Slap	Cajon Slap LC		
E-1		Cajon Tip	Cajon Tip LC	Indian Hand Clap	
F-1	F#-1	Claves High	Claves High LC	Dafli Open	
G-1	G#-1	Claves Low	Claves Low LC	Dafli Slap	
A-1	A#-1	Hand Clap	Hand Clap LC	Dafli Rim	
B-1				Duff Open	
C0	C#0	Finger Snap	Finger Snap LC	Duff Slap	
D0	D#0	Castanet	Castanet LC	Duff Rim	
E0		Conga H Tip	Conga H Tip LC	Hatheli Long	
F0	F#0	Conga H Heel	Conga H Heel LC	Hatheli Short	
G0	G#0	Conga H Open	Conga H Open LC	Baya ge	
A0	A#0	Conga H Mute	Conga H Mute LC	Baya ke	
B0		Conga H SlapOpen	Conga H SlpOp LC	Baya ghe	
C1	C#1	Conga H Slap	Conga H Slap LC	Baya ka	
D1	D#1	Conga H SlapMute	Conga H SlpMt LC	Tabla na	
E1		Conga L Tip	Conga L Tip LC	Tabla tin	
F1	F#1	Conga L Heel	Conga L Heel LC	Tablabaya dha	
G1	G#1	Conga L Open	Conga L Open LC	Dhol 1 Open	
A1	A#1	Conga L Mute	Conga L Mute LC	Dhol 1 Slap	
B1		Conga L SlapOpen	Conga L SlpOp LC	Dhol 1 Mute	
C2	C#2	Conga L Slap	Conga L Slap LC	Dhol 1 Open Slap	
D2	D#2	Conga L Slide	* Conga L Slide LC	* Dhol 1 Roll	
E2		Bongo H Open 1F	Bongo H Op 1F LC	Dandia Short	
F2	F#2	Bongo H Open 3F	Bongo H Op 3F LC	Dandia Long	
G2	G#2	Bongo H Rim	Bongo H Rim LC	Chutki	
A2	A#2	Bongo H Tip	Bongo H Tip LC	Chipri	
B2		Bongo H Heel	Bongo H Heel LC	Khanjira Open	
		Bongo H Slap	Bongo H Slap LC	Khanjira Slap	
		Bongo L Open 1F	Bongo L Op 1F LC	Khanjira Mute	
		Bongo L Open 3F	Bongo L Op 3F LC	Khanjira Bend Up	
		Bongo L Rim	Bongo L Rim LC	Khanjira Bend Dn	
		Bongo L Tip	Bongo L Tip LC	Dholak 1 Open	
		Bongo L Heel	Bongo L Heel LC	Dholak 1 Mute	
		Bongo L Slap	Bongo L Slap LC	Dholak 1 Slap	
		Timbale L	Timbale L LC	Dhol 2 Open	
				Dhol 2 Slap	
				Dhol 2 Rim	
				Mridangam na	
				Mridangam din	
		Paila L	Paila L LC	Mridangam ki	
		Timbale H	Timbale H LC	Mridangam ta	
		Hand Clap Mute 1	Clap Mute 1 LC	Mridangam Chapu	
		Hand Clap Mute 2	Clap Mute 2 LC	Mridangam Lo Cls	
		Hand Clap Open 1	Clap Open 1 LC	Mridangam Lo Op	
		Hand Clap Open 2	Clap Open 2 LC	Chimta Normal	
		Paila H	Paila H LC	Chimta Ring	

Oct.+3

Lower Keyboard	Upper Keyboard	SFX [2]	
		Chinese Percus	Key off
Oct.-1	C-2		
	D-2	C#-2	
	E-2	D#-2	
	F-2		
	G-2	F#-2	
	A-2	G#-2	
	B-2	A#-2	
	C-1		
	D-1	C#-1	Xiao Luo 1
	E-1	D#-1	XiaoLuo 1 Muffle
	F-1		Xiao Luo 2
	G-1	F#-1	XiaoLuo 2 Muffle
	A-1	G#-1	Zhong Luo 1
	B-1	A#-1	Zhong Luo 2
	C0		Da Luo
	D0	C#0	Da Luo Stick
	E0	D#0	Mang Luo 1
	F0		Mang Luo 2
	G0	F#0	Mang Luo 3
	A0	G#0	Mang Luo 4
	B0	A#0	Xiao Gu
	C1		Da Gu Ens Center
	D1	C#1	Da Gu Ens Rim
	E1	D#1	Da Gu Ens Shout
	F1		Shou Gu 1 Side
	G1	F#1	Shou Gu 1 Center
	A1	G#1	Shou Gu 1 Edge
	B1	A#1	Da Gu 1 Rim
	C2		Da Gu 1
	D2	C#2	Da Gu 2 Rim
	E2	D#2	Da Gu 2 Soft
	F2		Da Gu 2 Hard
	G2	F#2	Shou Gu 2 Center
	A2	G#2	Shou Gu 2 Edge 1
	B2	A#2	Shou Gu 2 Edge 2
			Shou Gu 2 Edge 3
			Pai Gu 1
			Da Bo Muted
			Pai Gu 2
			Da Bo Effect
			Pai Gu 3
			Da Bo
			Pai Gu 4
			Pai Gu 5
			Da Luo Crash
			Da Luo Effect 1
			Da Luo Effect 2
			Da Luo Effect 3
			Zhong Bo 1 Soft
			Zhong Bo 1 Hard
			Zhong Bo 2 Soft
			Zhong Bo 2 Hard
			Peng Ling
			Nao Bo
			Nao Bo Muted

Lower Keyboard	Upper Keyboard	SFX [2]				
		Chinese Percus	Key off			
		C3	Xiao Bo 1			
		C#3	Xiao Bo 1 Muted			
		D3	Xiao Bo 2			
		D#3	Xiao Bo 2 Muted			
		E3	Jing Luo 1			
		F3	Jing Luo 1 Muted			
		F#3	Jing Luo 2			
		G3	Jing Luo 2 Muted			
		G#3	Jing Luo 3			
		A3	Jing Luo 3 Muted			
		A#3	Pai Ban 1			
		B3	Pai Ban 2			
		C4	Ban Gu Left			
		C#4	Ban Gu Roll	*		
		D4	Ban Gu Right			
		D#4	Kuai Ban Big			
		E4	Kuai Ban Small			
		F4	Mu Yu 1			
		F#4	Mu Yu 2			
		G4	Mu Yu 3			
		G#4	Mu Yu 4			
		A4	Mu Yu 5			
		A#4	Shi Mian Luo 1			
B4	Shi Mian Luo 2					
Oct.+1		C5	Shi Mian Luo 3			
		C#5	Shi Mian Luo 4			
		D5	Shi Mian Luo 5			
		D#5	Shi Mian Luo 6			
		E5	Shi Mian Luo 7			
		F5	Shi Mian Luo 8			
		F#5	Shi Mian Luo 9			
		G5	Shi Mian Luo 10			
		G#5				
		A5				
		A#5				
		B5				
		C6				
		C#6				
		D6				
		D#6				
		E6				
		F6				
		F#6				
		G6				
		G#6				
		A6				
		A#6				
B6						
Oct.+2		C7				
		C#7				
		D7				
		D#7				
		E7				
		F7				
		F#7				
		G7				
		G#7				
		A7				
		A#7				
		B7				
		C8				
		C#8				
		D8				
		D#8				
		E8				
		F8				
		F#8				
		G8				
		Oct.+3				

Effect Type List

The numbers on the left side of each column in this list correspond to the page numbers shown on the Electone display.

REVERB

1	Hall 1
	Hall 2
	Hall 3
	Hall M
	Hall L
	XG Hall 1
	XG Hall 2
	Room 1
	Room 2
	Room 3
	Room 4
	Room S
	Room M
	Room L
	XG Room 1
	XG Room 2
2	XG Room 3
	Stage 1
	Stage 2
	XG Stage 1
	XG Stage 2
	Plate 1
	Plate 2
	XG Plate
	GM Plate
	White Room
	Atmosphere Hall
	Acoustic Room
	Drums Room
	Percussion Room
	Tunnel
	Canyon
3	Basement

ER/KARAOKE

1	Early Reflection 1
	Early Reflection 2
	Gate Reverb 1
	Gate Reverb 2
	Reverse Gate
	Karaoke 1
	Karaoke 2
2	Karaoke 3

CHORUS

1	Chorus 1
	Chorus 2
	XG Chorus 1
	XG Chorus 2
	XG Chorus 3
	XG Chorus 4
	GM Chorus 1
	GM Chorus 2
	GM Chorus 3
	GM Chorus 4
	Feedback Chorus
	Chorus Fast
	Chorus Lite
	Ambience Chorus
	Celeste 1
	Celeste 2
2	Celeste 3
	Celeste 4
	Ambience Celeste
	Symphonic
	XG Symphonic
	Ambi Symphonic
	EnsembleDetune 1
3	EnsembleDetune 2

PHASER

1	Phaser 1
	Phaser 2
	Phaser 3
	EP Phaser 1
	EP Phaser 2
	EP Phaser 3
	Tempo Phaser 1
	Tempo Phaser 2
	Dynamic Phaser
	Vintage Phaser 1
	Vintage Phaser 2
	Vin Phaser ST 1
2	Vin Phaser ST 2
	Vin Phaser ST 3
	Vin Phaser ST 4

TREMOLO/AUTO PAN

1	Tremolo 1
	Tremolo 2
	XG Tremolo
	EP Tremolo
	Guitar Tremolo 1
	Guitar Tremolo 2
	Organ Tremolo
	Vibraphone Rotor
	Tempo Tremolo
	Auto Pan
	XG Auto Pan 1
	XG Auto Pan 2
	EP Auto Pan
	Tempo Auto Pan 1
2	Tempo Auto Pan 2

DISTORTION

1	DistortionHard 1
	DistortionHard 2
	DistortionSoft 1
	DistortionSoft 2
	Stereo Dist Hard
	Stereo Dist Soft
	Overdrive
	Stereo Overdrive
	XG Distortion
	XG Stereo Dist
	V Dist Hard
	V Dist Soft
	Compressor+Dist
	XG Comp+Dist
	V Dist Warm
2	V Dist Cls Hard
	V Dist Cls Soft
	V Dist Metal
	V Dist Crunch
	V Dist Blues
	V Dist Edgy
	V Dist Solid
	V Dist Clean 1
	V Dist Clean 2
	V Dist Twin
3	V DistRockabilly
	V Dist JazzClean
	V Dist Fusion

DISTORTION+

1	Distortion+Delay
	Overdrive+Delay
	XG Dist+Delay
	XG OD+Delay
	Comp+Dist+Delay
	Comp+OD+Delay
	XG Comp+Dist+Dly
	XG Comp+OD+Delay
	V DistHard+Delay
	V DistSoft+Delay
	Dist+Tempo Delay
	OD+Tempo Delay
2	Comp+Dist+TmptDly
	Comp+OD+TmptDly 1
	Comp+OD+TmptDly 2
	Comp+OD+TmptDly 3
	Comp+OD+TmptDly 4
	Comp+OD+TmptDly 5
	Comp+OD+TmptDly 6
	V Dist H+TmptDly1
	V Dist H+TmptDly2
	V Dist S+TmptDly1
3	V Dist S+TmptDly2

DELAY

1	Delay LCR
	XG Delay LCR
	Delay LR
	Echo
	Cross Delay 1
	Cross Delay 2
	Tempo Delay 1
	Tempo Delay 2
	Tempo Echo
	Tempo Cross 1
	Tempo Cross 2
	Tempo Cross 3
	Tempo Cross 4
2	Tempo Cross 5

FLANGER

1	Flanger 1
	Flanger 2
	XG Flanger 1
	XG Flanger 2
	XG Flanger 3
	GM Flanger
	V Flanger
	Tempo Flanger
	Dynamic Flanger
	Vintage Flanger1
	Vintage Flanger2
2	Ambience Flanger

ROTARY SPEAKER

1	XG RotarySpeaker
	Rotary Speaker 1
	Rotary Speaker 2
	Rotary Speaker 3
	Rotary Speaker 4
	Rotary Speaker 5
	2way Rotary SP
	Dual Rotary SP 1
	Dual Rotary SP 2
	DualRotarySP BRT
	DualRotarySP WRM
	Real Rotary
	Dist+Rotary SP
	OD+Rotary SP
	AmpSim+Rotary SP
2	Dist+2 Rotary SP
	OD+2 Rotary SP
	AmpSim+2RotarySP

AMP SIMULATOR

1	Amp Simulator
	XG Amp Simulator
	ST AmpSimulator1
	ST AmpSimulator2
	ST AmpSimulator3
	ST AmpSimulator4
	ST AmpSimulator5
	XG ST Amp Sim
	ST Amp Sim Solid
	ST AmpSim Crunch
	ST Amp Sim Blues
	ST Amp Sim Clean
	ST Amp Sim Harp
	SML ST Dist
	SML ST Overdrive
	SML ST Vin Amp
2	SML ST HeavyDist
	B Combo Classic
	B Combo TopBoost
	B Combo Custom
	B Combo Heavy
	B Legend Blues
	B Legend Heavy 1
	B Legend Heavy 2
	B Legend Clean
	B LGND Dirty Cln
	US Combo Twin
	US CMB Rich Cln
	US CMB Thin Cln
	US Combo Crunch
	Jazz Combo Basic
	Jazz Combo Warm
3	US Hi Gain Dirty
	US Hi Gain Riff
	US Hi Gain Burn
	US Hi Gain Solo
	BritishLeadDirty
	BritishLeadDrive
	B Lead Gainer
	BritishLead Hard
	TweedGuyWarmBass
	TweedGuyLiveBass
	TweedGuyRockBass
	Tweed Guy Clean
	TweedGuy Vintage
	Tweed Guy Combo
	Tweed Guy Heavy
	BoutiqueDC Clean
4	BoutiqueDC Dirty
	BoutiqueDC Blues
	BoutiqueDC Clasc
	Y-Amp Live Clean
	Y-Amp B Crunch
	Y-Amp Sweet Dist
	Y-Amp ModernLead
	DistompMildDrive
	Distomp ZZ Dist
	Distomp HighGain
	Distomp Metal
	80sSmallBox Warm
	80s SBoxFullDist
	MFX Dist Solo
	MFX Dist Basic
	MFX OD Chorus
5	MFX Crunch Wah
	MFX Oldies Delay
	MFX Vintage Echo

WAH

1	Auto Wah
	XG Auto Wah
	V Auto Wah
	Touch Wah 1
	Touch Wah 2
	Touch Wah 3
	V Touch Wah
	Auto Wah+Dist
	XG Auto Wah+Dist
	AutoWah+DistHard
	AutoWah+Dist Hvy
	AutoWah+Dist Lt
	Auto Wah+OD
	XG Auto Wah+OD
	Auto Wah+OD Hard
	AutoWah+OD Heavy
2	AutoWah+OD Light
	Touch Wah+Dist
	XG TouchWah+Dist
	TouchWah+DistHrd
	TouchWah+DistHvy
	Touch Wah+DST Lt
	Touch Wah+OD
	XG Touch Wah+OD
	Touch Wah+OD Hrd
	Touch Wah+OD Hvy
	Touch Wah+OD Lt
	Clavi Touch Wah
3	EP Touch Wah
	Wah+Dist+Tmp Dly
	Wah+OD+Tmp Dly 1
	Wah+OD+Tmp Dly 2
	Wah+Dist+Delay
	XG Wah+Dist+Dly
	Wah+OD+Delay
	XG Wah+OD+Delay
	Tempo Auto Wah
	TmpAutoWah+Dist
	TmpAutoWah+DistH
	TmpAtWah+DistHvy
	TmpAtWah+DistLt
	TmpAutoWah+OD
	TmpAutoWah+OD H
	TmpAtWah+OD Hvy
	TmpAutoWah+OD Lt

DYNAMIC

1	M BandCompressor
	M BandComp Basic
	M BandCmp Dr Aco
	M BandCmp DrElec
	M BandCmpBassAco
	M BandCmp BsElec
	Compressor
	Compressor Med
	Compressor Heavy
	Compressor Melo
	Compressor Bass
	V Compressor
	Uni Comp Basic
	Uni Comp Dr Aco
	Uni Comp Dr Elec
2	Uni Comp Perc
	UniComp ClipDist
	Uni Comp BassAco
	Uni Comp Bs Elec
	Uni Comp Gtr Aco
	Uni Comp GtrElec
	Uni Comp EP&Syn
	Noise Gate

EQ/ENHANCER

1	Stereo 2Band EQ
	Stereo 3Band EQ
	XG 3Band EQ
	EQ Disco
	EQ Telephone
	HarmonicEnhancer
	XG HarmoEnhancer

PITCH CHANGE

1	Pitch Change
	XG PitchChange 1
	XG PitchChange 2

MISCELLANEOUS

1	Ambience
	Impulse Expander
	Resonator
	Voice Cancel
	Talking Mod
	Lo-Fi
	Dynamic Filter
	Dynamic Ring Mod
	Ring Modulator
	Isolator
	Loop FX 1
	Loop FX 2
	Lo-Fi Drum 1
	Lo-Fi Drum 2
	Lo-Fi Drum 3
2	Lo-Fi Drum 4
	Presence C Ntrl
	PresenceBsKeeper
	PresenceCrspThin
	Damper Resonance

THRU

1	Thru
---	------

Chorus Type List

The numbers on the left side of each column in this list correspond to the page numbers shown on the Electone display.

1	Chorus 1	5	Hall 1
	Chorus 2		Hall 2
	XG Chorus 1		Hall 3
	XG Chorus 2		Hall M
	XG Chorus 3		Hall L
	XG Chorus 4		XG Hall 1
	GM Chorus 1		XG Hall 2
	GM Chorus 2		Room 1
	GM Chorus 3		Room 2
	GM Chorus 4		Room 3
	FB Chorus		Room 4
	Chorus Fast		Room S
	Chorus Lite		Room M
	Celeste 1		Room L
	Celeste 2		XG Room 1
	Celeste 3		XG Room 2
	Celeste 4		XG Room 3
2	Symphonic	6	Stage 1
	XG Symphonic		Stage 2
	EnsembleDetune 1		XG Stage 1
	EnsembleDetune 2		XG Stage 2
	Flanger 1		Plate 1
	Flanger 2		Plate 2
	XG Flanger 1		XG Plate
	XG Flanger 2		GM Plate
	XG Flanger 3		Atmosphere Hall
	GM Flanger		Acoustic Room
	Tempo Flanger		Drums Room
	Phaser 1		Percussion Room
	Phaser 2		Early Reflection 1
	Phaser 3		Early Reflection 2
	EP Phaser 1		Karaoke 1
	EP Phaser 2		Karaoke 2
	EP Phaser 3		Karaoke 3
	Tempo Phaser 1	7	Tempo Delay 1
	Tempo Phaser 2		Tempo Delay 2
3	Tremolo 1		Tempo Echo
	Tremolo 2		Tempo Cross 1
	XG Tremolo		Tempo Cross 2
	EP Tremolo		Tempo Cross 3
	Guitar Tremolo 1		Tempo Cross 4
	Guitar Tremolo 2		Pitch Change
	Vibraphone Rotor		XG PitchChange 1
	Tempo Tremolo		XG PitchChange 2
	Auto Pan		No Effect
	XG Auto Pan 1		
	XG Auto Pan 2		
	EP Auto Pan		
	Tempo Auto Pan 1		
	Tempo Auto Pan 2		
4	XG RotarySpeaker		
	Rotary Speaker 1		
	Rotary Speaker 2		
	Rotary Speaker 3		
	Rotary Speaker 4		
	Organ Tremolo		
	Rotary Speaker 5		
	2way Rotary SP		
	Dual Rotary SP 1		
	Dual Rotary SP 2		
	DualRotarySP BRT		
	DualRotarySP WRM		

Variation Effect Type List

The numbers on the left side of each column in this list correspond to the page numbers shown on the Electone display.

REVERB

1	Hall 1
	Hall 2
	Hall 3
	Hall M
	Hall L
	XG Hall 1
	XG Hall 2
	Room 1
	Room 2
	Room 3
	Room 4
	Room S
	Room M
	Room L
	XG Room 1
	XG Room 2
2	XG Room 3
	Stage 1
	Stage 2
	XG Stage 1
	XG Stage 2
	Plate 1
	Plate 2
	XG Plate
	GM Plate
	White Room
	Atmosphere Hall
	Acoustic Room
	Drums Room
	Percussion Room
	Tunnel
	Canyon
3	Basement

DELAY

1	Delay LCR
	XG Delay LCR
	Delay LR
	Echo
	Cross Delay 1
	Cross Delay 2
	Tempo Delay 1
	Tempo Delay 2
	Tempo Echo
	Tempo Cross 1
	Tempo Cross 2
	Tempo Cross 3
	Tempo Cross 4

ER/KARAOKE

1	Early Reflection 1
	Early Reflection 2
	Gate Reverb 1
	Gate Reverb 2
	Reverse Gate
	Karaoke 1
	Karaoke 2
2	Karaoke 3

CHORUS

1	Chorus 1
	Chorus 2
	XG Chorus 1
	XG Chorus 2
	XG Chorus 3
	XG Chorus 4
	GM Chorus 1
	GM Chorus 2
	GM Chorus 3
	GM Chorus 4
	Feedback Chorus
	Chorus Fast
	Chorus Lite
	Ambience Chorus
	Celeste 1
	Celeste 2
2	Celeste 3
	Celeste 4
	Ambience Celeste
	Symphonic
	XG Symphonic
	Ambi Symphonic
	EnsembleDetune 1
3	EnsembleDetune 2

FLANGER

1	Flanger 1
	Flanger 2
	XG Flanger 1
	XG Flanger 2
	XG Flanger 3
	GM Flanger
	V Flanger
	Tempo Flanger
	Dynamic Flanger
	Vintage Flanger1
	Vintage Flanger2
	Ambience Flanger

PHASER

1	Phaser 1
	Phaser 2
	Phaser 3
	EP Phaser 1
	EP Phaser 2
	EP Phaser 3
	Tempo Phaser 1
	Tempo Phaser 2
	Dynamic Phaser
	Vintage Phaser 1
	Vintage Phaser 2
	Vin Phaser ST 1
2	Vin Phaser ST 2
	Vin Phaser ST 3
	Vin Phaser ST 4

TREMOLO/AUTO PAN

1	Tremolo 1
	Tremolo 2
	XG Tremolo
	EP Tremolo
	Guitar Tremolo 1
	Guitar Tremolo 2
	Organ Tremolo
	Vibraphone Rotor
	Tempo Tremolo
	Auto Pan
	XG Auto Pan 1
	XG Auto Pan 2
	EP Auto Pan
	Tempo Auto Pan 1
2	Tempo Auto Pan 2

ROTARY SPEAKER

1	XG RotarySpeaker
	Rotary Speaker 1
	Rotary Speaker 2
	Rotary Speaker 3
	Rotary Speaker 4
	Rotary Speaker 5
	2way Rotary SP
	Dual Rotary SP 1
	Dual Rotary SP 2
	DualRotarySP BRT
	DualRotarySP WRM
	Real Rotary
	Dist+Rotary SP
	OD+Rotary SP
	AmpSim+Rotary SP
	Dist+2 Rotary SP
2	OD+2 Rotary SP
	AmpSim+2RotarySP

DISTORTION

1	DistortionHard 1
	DistortionHard 2
	DistortionSoft 1
	DistortionSoft 2
	Stereo Dist Hard
	Stereo Dist Soft
	Overdrive
	Stereo Overdrive
	XG Distortion
	XG Stereo Dist
	V Dist Hard
	V Dist Soft
	Compressor+Dist
	XG Comp+Dist
2	V Dist Warm
	V Dist Cls Hard
	V Dist Cls Soft
	V Dist Metal
	V Dist Crunch
	V Dist Blues
	V Dist Edgy
	V Dist Solid
	V Dist Clean 1
	V Dist Clean 2
3	V Dist Twin
	V DistRockabilly
	V Dist JazzClean
4	V Dist Fusion

DISTORTION+

1	Distortion+Delay
	Overdrive+Delay
	XG Dist+Delay
	XG OD+Delay
	Comp+Dist+Delay
	Comp+OD+Delay
	XG Comp+Dist+Dly
	XG Comp+OD+Delay
	V DistHard+Delay
	V DistSoft+Delay
	Dist+Tempo Delay
	OD+Tempo Delay
	Comp+Dist+TmPDly
2	Comp+OD+TmPDly 1
	Comp+OD+TmPDly 2
	Comp+OD+TmPDly 3
	Comp+OD+TmPDly 4
	Comp+OD+TmPDly 5
	Comp+OD+TmPDly 6
	V Dist H+TmPDly1
	V Dist H+TmPDly2
	V Dist S+TmPDly1
	V Dist S+TmPDly2

AMP SIMULATOR

1	Amp Simulator
	XG Amp Simulator
	ST AmpSimulator1
	ST AmpSimulator2
	ST AmpSimulator3
	ST AmpSimulator4
	ST AmpSimulator5
	XG ST Amp Sim
	ST Amp Sim Solid
	ST AmpSim Crunch
	ST Amp Sim Blues
	ST Amp Sim Clean
	ST Amp Sim Harp
	SML ST Dist
	SML ST Overdrive
	SML ST Vin Amp
2	SML ST HeavyDist
	B Combo Classic
	B Combo TopBoost
	B Combo Custom
	B Combo Heavy
	B Legend Blues
	B Legend Heavy 1
	B Legend Heavy 2
	B Legend Clean
	B LGND Dirty Cln
	US Combo Twin
	US CMB Rich Cln
	US CMB Thin Cln
	US Combo Crunch
	Jazz Combo Basic
	Jazz Combo Warm
3	US Hi Gain Dirty
	US Hi Gain Riff
	US Hi Gain Burn
	US Hi Gain Solo
	BritishLeadDirty
	BritishLeadDrive
	B Lead Gainer
	BritishLead Hard
	TweedGuyWarmBass
	TweedGuyLiveBass
	TweedGuyRockBass
	Tweed Guy Clean
	TweedGuy Vintage
	Tweed Guy Combo
	Tweed Guy Heavy
	BoutiqueDC Clean
4	BoutiqueDC Dirty
	BoutiqueDC Blues
	BoutiqueDC Clasc
	Y-Amp Live Clean
	Y-Amp B Crunch
	Y-Amp Sweet Dist
	Y-Amp ModernLead
	DistompMildDrive
	Distomp ZZ Dist
	Distomp HighGain
	Distomp Metal
	80sSmallBox Warm
	80s SBoxFullDist
	MFX Dist Solo
	MFX Dist Basic
	MFX OD Chorus
5	MFX Crunch Wah
	MFX Oldies Delay
	MFX Vintage Echo

WAH

1	Auto Wah
	XG Auto Wah
	V Auto Wah
	Touch Wah 1
	Touch Wah 2
	Touch Wah 3
	V Touch Wah
	Auto Wah+Dist
	XG Auto Wah+Dist
	AutoWah+DistHard
	AutoWah+Dist Hvy
	AutoWah+Dist Lt
	Auto Wah+OD
	XG Auto Wah+OD
	Auto Wah+OD Hard
	AutoWah+OD Heavy
2	AutoWah+OD Light
	Touch Wah+Dist
	XG TouchWah+Dist
	TouchWah+DistHrd
	TouchWah+DistHvy
	Touch Wah+DST Lt
	Touch Wah+OD
	XG Touch Wah+OD
	Touch Wah+OD Hrd
	Touch Wah+OD Hvy
	Touch Wah+OD Lt
	Clavi Touch Wah
3	EP Touch Wah
	Wah+Dist+Tmp Dly
	Wah+OD+Tmp Dly 1
	Wah+OD+Tmp Dly 2
	Wah+Dist+Delay
	XG Wah+Dist+Dly
	Wah+OD+Delay
	XG Wah+OD+Delay
	Tempo Auto Wah
	TmpAutoWah+Dist
	TmpAutoWah+DistH
	TmpAtWah+DistHvy
	TmpAtWah+DistLt
	TmpAutoWah+OD
	TmpAutoWah+OD H
	TmpAtWah+OD Hvy
	TmpAutoWah+OD Lt

DYNAMIC

1	M BandCompressor
	M BandComp Basic
	M BandCmp Dr Aco
	M BandCmp DrElec
	M BandCmpBassAco
	M BandCmp BsElec
	Compressor
	Compressor Med
	Compressor Heavy
	Compressor Melo
	Compressor Bass
	V Compressor
	Uni Comp Basic
	Uni Comp Dr Aco
	Uni Comp Dr Elec
2	Uni Comp Perc
	UniComp ClipDist
	Uni Comp BassAco
	Uni Comp Bs Elec
	Uni Comp Gtr Aco
	Uni Comp GtrElec
	Uni Comp EP&Syn
	Noise Gate

EQ/ENHANCER

1	Stereo 2Band EQ
	Stereo 3Band EQ
	XG 3Band EQ
	EQ Disco
	EQ Telephone
	HarmonicEnhancer
	XG HarmoEnhancer

PITCH CHANGE

1	Pitch Change
	XG PitchChange 1
	XG PitchChange 2

MISCELLANEOUS

1	Ambience
	Voice Cancel
	Talking Mod
	Lo-Fi
	Dynamic Filter
	Dynamic Ring Mod
	Ring Modulator
	Isolator
	Loop FX 1
	Loop FX 2
	Lo-Fi Drum 1
	Lo-Fi Drum 2
	Lo-Fi Drum 3
	Lo-Fi Drum 4
	Presence C Ntrl
2	PresenceBsKeeper
	PresenceCrspThin

THRU

1	Thru
	No Effect

Reverb Type List

The numbers on the left side of each column in this list correspond to the page numbers shown on the Electone display.

1	REV Large Hall	4	Warm Room
	REV Church		Woody Room
	REV Cathedral		Stage 1
	REV Concert Hall		Stage 2
	REV Medium Hall		XG Stage 1
	REV Small Hall		XG Stage 2
	REV Live Stage		Real Large Plate +
	REV Echo Chamber		Real Medium Plate +
	REV Large Studio		Real Large Plate
	REV Scoring Stage		Real Medium Plate
	REV Large Room		Real Rattle Plate
	REV Medium Room		Large Plate +
	REV Small Room		Rich Plate
	REV Concert Chamber		Plate 1
	REV Medium Studio		Plate 2
	REV Small Studio		XG Plate
	REV Drum Cave		GM Plate
	REV Ambience		White Room
	REV Plate Reverb		Atmosphere Hall
	REV Spring Reverb		Acoustic Room
2	REV Gated Ambience	5	Drums Room
	REV Chorus Large		Percussion Room
	REV Chorus Medium		Tunnel
	REV Chorus Small		Canyon
	REV Reverse Ambience		Basement
	REV Complex Echos		
	Real Large Hall +		
	Real Medium Hall +		
	Real Small Hall +		
	Real Large Hall		
	Real Medium Hall		
	Real Bright Hall		
	Large Hall		
	Medium Hall		
	Ballad Hall		
	Piano Hall		
	Hall 1		
	Hall 2		
	Hall 3		
	Hall M		
3	Hall L		
	XG Hall 1		
	XG Hall 2		
	Basic Hall		
	Light Hall		
	Vocal Hall 1		
	Vocal Hall 2		
	Real Room +		
	Real Room		
	Real Power Room		
	Room 1		
	Room 2		
	Room 3		
	Room 4		
	Room S		
	Room M		
	Room L		
	XG Room 1		
	XG Room 2		
	XG Room 3		

Vocal Harmony Type List

Chordal

Harmony Type	Description
Duet Harmony	Standard setting for lead vocal plus 1 harmony part with vibrato. Useful for many music genres.
Standard Harmony	Standard setting for lead vocal plus 2 or 3 harmony parts with vibrato. Useful for many music genres.
Easy Harmony	Standard setting for lead vocal plus 2 simple harmony parts with vibrato. Useful for many music genres.
Light Harmony	A light sound with 2 or 3 harmony parts on the lead vocal pitch.
Studio Singers	Ideal for lead vocals with suitable EQ and 3 harmony settings. Excellent for studio productions.
Quartet Harmony	Standard setting for lead vocal plus 3 harmony parts with vibrato. Useful for many music genres.
Big Harmony	3 harmony parts overlap the lead vocals, makes a powerful harmony. Useful for many music genres.
Big Acapella	Characteristic acapella sound of lead vocal plus 3 voice open harmony (2 voice harmony plus bass part.)
Big Choir	A powerful sound with 2 or 3 harmony parts on the lead vocal pitch.
Standard Duet	Standard setting for lead vocal plus 1 harmony part. Useful for many music genres.
Standard Trio	Standard setting for lead vocal plus 2 harmony parts. Useful for many music genres.
Standard Quartet	Standard setting for lead vocal plus 3 harmony parts. Useful for many music genres.
Studio Vocals	Excellent for studio productions with appropriate EQ and harmony settings.
Jazzy Quartet	Good for Bass, Tenor and Alto singers; for Jazz repertoire. You will hear additional 6th notes.
Schlager Trio	Good for standard Schlager repertoire with simple harmony chords.
Session Vocals	Good for female singers with lead vocal plus 2 harmony parts above; for female Pop and R&B repertoire.
Telephone Choir	Typical Lo-fi vocal ensemble; use as old fashioned ensemble sound or exciting effect in Rock, Pop and Jazz.
Like The 80s	Good for 80's Pop with typical reverb image.
Gramophone	Typical 30's vocal ensemble; use as old fashioned gramophone sound.
Phaser Voice	Good for modern Pop songs using phaser effect for lead vocal.
Detune Voice	Lead vocal plus two additional detuned harmony parts for exciting detuned sound.
Perfect Fourth	Quartet singing only perfect fourths; parallel movement of all parts.
Sing Cmaj Scale	When you sing according to the C major scale, harmony parts will be created with suitable chord notes based on the C major scale.
Ballad Choir	Good for Ballad backing vocals with long reverb time.
Church Choir	Good for standard church songs and Christmas songs with long reverb time; recommended for Bass, Tenor and Alto voice.
Gregorian Choir	Good for rubato Gregorian-chant-type monophonic songs with large reverb; parallel movement of all parts.
Gospel Choir	Good for Gospel songs with long reverb on harmony parts and dominant 7th feel.
Cosmic Choir	Extreme phasing vocals; useful for exciting effects in Dance and Modern Music.
Alpen Girls	Good for male singer with 2 female harmony parts above lead vocal.
Country Rock	Typical Country Rock quartet; recommended range is tenor/alto.
R&B Diva	Good for female alto singer for R&B repertoire; also usable with Tenor lead vocal.
Closed PopChicks	Ideal for a female singer, featuring two harmony parts below.
Bob -> Mary	Allows a male singer to sound like a female, and features long romantic reverb.
Mary -> Bob	Allows a female singer to sound like a male.
Jazzy Singers	Good for Bass and Tenor Singers. Harmony parts add 3 female Jazz singers.
Quartet On Stage	Good for Rock and Pop Music. Harmony parts make up a quartet.
Delayed Harmony	Useful in several genres with a tempo-synced delay choir as background.
Kids Choir	Want to be a child again? Use this preset type and sing with your friends...
Chorus Choir	The chorus effect adds a rich and exciting characteristics to your voice and the harmony parts.
Robot Voice	Robotic vocal sound.

Vocoder

Harmony Type	Description
Vocoder Schlager	Vocoder sound for harmony in Schlager music.
Vocoder VH	Standard vocoder setting.
Vocoder Mono	Standard vocoder setting that enables you to play mono (single-note) melodies.
Mixed Vocoder	Tempo flanging Vocoder Type; good for Rock or Pop songs and Intros.

Synth Vocoder

Harmony Type	Description
Monster Pad	Big vocoder sound with added octave for playing single notes in the lower keyboard range.
Digi Stack	Classic soft vocoder sound with added noise for better speech intelligibility.
Reflecting	Strong detuned effect makes atmospheric vocoder sound.
Monster FX	Vocoder sound with phaser for vocal sound effects.
Phat Stack	Strongly detuned vocoder sound with a mixture of natural and electronic vocal sound.
Uni VCO	Spacious ensemble vocoder sound with added noise for better speech intelligibility.
JP Saw	Slightly detuned vocoder sound for vocal sound effects.
Pulse Wave 10	Classic vocoder sound with a mixture of natural and electronic vocal sound.
Pulse Wave 25	Classic vocoder sound with phaser.
Digi Wave	Classic vocoder sound with upshifted formants for vocal sound effects.
Fat Saw	Fat synth vocoder sound with fat saw tooth wave sound.
Simple Saw	Simple synth vocoder sound with simple saw tooth wave sound.
Sync Saw	Sync sound image. You can feel the phaser sound as well.
Strong Detune	Strong detuned Sound.
VP Pad	Pad oriented synth vocoder sound.
Choir With You	Choir oriented synth vocoder. You can hear your own voice as well.
Organ	Organ oriented synth vocoder sound.
Sweeping	Produces a sweeping sound image.
Atmosphere	Pad oriented synth vocoder sound with soft pad sound.
Ambient FX	Richly textured sound.

Vocal Effect

Harmony Type	Description
Vocal Doubler	Use this preset to overdub your singing in real time.
Rock&Roll	Ideal for 50's and 60's songs with typical delay sound.
Tempo Cross	Tempo Cross Delay on lead vocal.
Heavy Voice	Good for Rock and Pop with overdriven vocal.
Delay Pop	Good for Pop and R&B songs using Tempo Delay.
Flanging Vocals	Useful for modern Pop, Rock and Dance music.

Thru

Harmony Type	Description
Thru	Bypass without any harmonies and effects.