





# USB AUDIO INTERFACE URX44V URX44 URX22 Block Diagram

## Block Diagram (URX44V, URX44)




\*1) INS FX are available for sampling frequencies below 96 kHz  
\*2) FX2 are available for sampling frequencies below 96 kHz

# DAW Integration Block Diagram (URX44V, URX44)




\*1) INS FX are available for sampling frequencies below 96 kHz  
 \*2) FX2 are available for sampling frequencies below 96 kHz

# Block Diagram (URX22)



\*1) INS FX are available for sampling frequencies below 96 kHz  
 \*2) FX2 are available for sampling frequencies below 96 kHz

# DAW Integration Block Diagram (URX22)



\*1) INS FX are available for sampling frequencies below 96 kHz  
 \*2) FX2 are available for sampling frequencies below 96 kHz